

Jojoka 15 dresser for bedroom

Jojoka 15-Drawer Dresser (White) Instruction Manual

Model: 15 dresser for bedroom | Brand: Jojoka

INTRODUCTION

Thank you for choosing the Jojoka 15-Drawer Dresser. This storage unit is designed to provide versatile organization for various items in your bedroom, hallway, or entryway. Featuring a sturdy metal frame, a durable wood tabletop, and 15 fabric drawers of varying sizes, this dresser combines functionality with a clean aesthetic. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.

SAFETY INFORMATION

To prevent injury or damage, please observe the following safety precautions:

- **Anti-Tip Kit:** Always install the included anti-tip kit to secure the dresser to a wall. This is crucial to prevent tipping, especially in households with children or pets.
- **Weight Distribution:** Do not overload drawers. Distribute weight evenly to maintain stability. Place heavier items in lower drawers.
- **Level Surface:** Ensure the dresser is placed on a flat, level surface. Use the adjustable feet to stabilize the unit and prevent wobbling.
- **Small Parts:** Keep all small parts and packaging materials away from children during assembly.
- **Assembly:** Follow all assembly instructions carefully. Do not use power tools for tightening screws, as this may damage components.



Image: Detail of the anti-tip kit for wall mounting and the water-resistant wooden top.

PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Metal Frame Components

- Wooden Tabletop
- Fabric Drawers (4 small, 7 medium, 4 large)
- Adjustable Feet
- Anti-Tip Kit
- Assembly Hardware (screws, bolts, Allen wrench)
- Instruction Manual

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the steps below. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

- 1. Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out and compare them against the parts list in your detailed instruction sheet to ensure everything is accounted for.
- 2. Assemble the Metal Frame:** Connect the metal frame components according to the diagrams in your instruction sheet. Ensure all connections are secure but do not overtighten screws until the frame is fully assembled.
- 3. Attach the Wooden Tabletop:** Once the frame is stable, place the wooden tabletop onto the top of the frame and secure it using the provided hardware.
- 4. Install Adjustable Feet:** Screw the adjustable feet into the bottom of the dresser frame. Adjust them as needed to ensure the dresser is level and stable on your floor.
- 5. Insert Fabric Drawers:** Unfold the fabric drawers and insert the bottom panels. Place the drawers into their designated slots within the metal frame.
- 6. Install Anti-Tip Kit:** Secure the dresser to the wall using the anti-tip kit. This step is critical for safety. Refer to the specific instructions provided with the anti-tip kit for proper installation.



Image: Illustration of the dresser's solid metal frame and adjustable feet for stability.



Image: Close-up of key structural features: thickened wooden board, easy pull handles, adjustable feet, and the stable metal frame.

OPERATING INSTRUCTIONS

The Jojoka 15-Drawer Dresser is designed for easy and efficient storage.

- Drawer Use:** Gently pull the arch handles to open drawers. Push them back in until they are fully closed. Avoid forcing drawers open or shut.
- Storage Capacity:** The dresser features 4 small, 7 medium, and 4 large fabric drawers. Utilize the different sizes to organize various items such as clothing, accessories, linens, or office supplies.
- Versatility:** This dresser is suitable for bedrooms, living rooms, nurseries, hallways, and entryways. Its design allows it to complement various interior styles.



Image: The dresser with drawers open, demonstrating storage capabilities for various items.



MAINTENANCE

Proper care will extend the life and appearance of your Jojoka dresser.

- **Cleaning the Wooden Top:** Wipe the wooden tabletop with a dry cloth to remove dust and spills. Avoid abrasive cleaners or excessive moisture.
- **Cleaning Fabric Drawers:** For fabric drawers, spot clean with a damp cloth and mild detergent if necessary. Allow to air dry completely. Do not machine wash.
- **Frame Care:** The metal frame can be wiped clean with a damp cloth.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.



Image: Detail of the sturdy, protective, and wear-resistant wooden top.



Image: Exploded view illustrating the three-layer construction of the fabric drawers.

TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

- **Dresser is Wobbly:**
Solution: Ensure the dresser is on a level surface. Adjust the leveling feet at the bottom of the frame until the unit is stable. Check all frame connections and tighten any loose screws.
- **Drawers Do Not Slide Smoothly:**
Solution: Ensure drawers are not overloaded. Check that the fabric drawers are fully unfolded and their bottom panels are correctly inserted. Verify that the metal frame is assembled squarely and not twisted.
- **Missing Parts:**
Solution: Double-check all packaging materials. If parts are genuinely missing, contact customer support with your purchase details.

SPECIFICATIONS

Feature	Detail
Brand	Jojoka
Model Name	15 dresser for bedroom
Product Dimensions	11.8"D x 39"W x 48"H
Color	White
Material	Fabric, Metal
Finish Type	Painted (Frame)
Number of Drawers	15

Item Weight	43.2 pounds
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth

Image: Detailed dimensions of the dresser and its various drawer sizes.

SUPPORT

Your satisfaction is our priority. If you have any questions regarding the quality of our products, assembly, or any other inquiries during your purchase or use, please do not hesitate to contact our customer support team. For assistance, please refer to the contact information provided with your purchase or visit the Jojoka brand store online. *Please retain this manual for future reference.*

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CRT2RCRW>

More documents and user manuals: <https://manuals.plus/>