Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MageGee K1 violet

MageGee K1 RGB LED Backlit Gaming Keyboard and Mouse Combo User Manual

Model: K1 violet

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your MageGee K1 RGB LED Backlit Gaming Keyboard and Mouse Combo. This combo is designed for efficient typing and gaming, featuring a full-size keyboard with RGB backlighting and a high-resolution mouse.



Figure 1: MageGee K1 Gaming Keyboard and Mouse Combo.

Setup

The MageGee K1 Keyboard and Mouse Combo is designed for plug-and-play functionality, requiring no additional drivers or software installation.

Connecting the Devices:

1. Locate an available USB-A port on your computer (PC or Laptop).
2. Plug the USB connector of the keyboard into the USB port.
3. Plug the USB connector of the mouse into another available USB port.
4. The operating system will automatically detect and configure the devices.

The devices are compatible with Windows XP/Vista/Win7/Win8/Win10, MAC, and Linux operating systems.

Operation

Keyboard Functions:

The K1 keyboard features a standard 104-key layout, including F-keys (function keys) and a number pad.

- **RGB LED Backlight:** The keyboard offers a vibrant RGB backlight with 8 distinct light colors and 5 different light modes. Brightness levels and light speeds are adjustable. The backlight can also be turned off.
- **Multimedia Shortcuts:** Utilize the FN key in combination with F1-F12 keys for various multimedia functions.




Figure 2: Keyboard Multimedia Functions (FN + F-keys).

- FN + F1: Mute
- FN + F2: Volume Down
- FN + F3: Volume Up
- FN + F4: Player
- FN + F5: Play/Pause
- FN + F6: Previous Track
- FN + F7: Next Track
- FN + F8: Stop
- FN + F9: Email
- FN + F10: Web Browser
- FN + F11: Lock Keyboard

- FN + F12: Lock Windows Key

- **Anti-Ghosting:** The keyboard supports 19-key anti-ghosting, allowing multiple keys to be pressed simultaneously without conflict, which is beneficial for gaming.
- **WASD and Arrow Key Swap:** Hold down **FN + W** to swap the functionality of the WASD keys with the arrow keys. Repeat the combination to revert.

Mouse Functions:

The accompanying mouse features high-resolution tracking and customizable settings.

- **DPI Adjustment:** The mouse offers 6 levels of adjustable DPI (Dots Per Inch) settings: 600, 800, 1200, 1600, 2400, and 3200. Use the DPI button (typically located behind the scroll wheel) to cycle through these settings to match your preference for speed and accuracy.
- **LED Backlight:** The mouse features a 7-color breathing LED backlight. To lock the backlight to your favorite color, press the side button (forward or back button) and the middle button (scroll wheel click) simultaneously.



Figure 3: Mouse LED Lighting Options.

Maintenance

Proper care and maintenance will extend the lifespan of your gaming combo.

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the keyboard and mouse. For deeper cleaning, the keyboard's floating keycaps are removable, allowing access to clean underneath. Use compressed air to remove dust and debris.
- **Splash-Resistant Design:** The keyboard features a splash-resistant design to help prevent damage from accidental spills. However, it is not fully waterproof. In case of a spill, immediately disconnect the keyboard and allow it to dry completely before reconnecting.
- **Storage:** Store the devices in a cool, dry place away from direct sunlight and extreme temperatures.



Figure 4: Keyboard with Clear Housing, facilitating cleaning.



Figure 5: Keyboard Keycaps and Backlight.



Figure 6: Product Dimensions.

Troubleshooting

If you encounter issues with your MageGee K1 Gaming Keyboard and Mouse Combo, please refer to the following common solutions:

Problem	Possible Solution
Keyboard/Mouse not responding	• Ensure both USB cables are securely plugged into the computer's USB ports. • Try plugging the devices into different USB ports on your computer. • Restart your computer. • Test the devices on another computer to determine if the issue is with the devices or your computer.
Keyboard backlight not working or incorrect colors	• Check the keyboard's lighting controls (refer to the "Operation" section for specific key combinations to adjust modes, brightness, or turn lights on/off). • Ensure the keyboard is properly connected.

Problem	Possible Solution
Mouse cursor is erratic or not moving smoothly	• Clean the optical sensor on the bottom of the mouse. • Ensure you are using the mouse on a suitable surface (e.g., a mouse pad). • Adjust the DPI setting of the mouse to a different level. • Try plugging the mouse into a different USB port.
Multimedia keys (FN+F keys) not working	• Ensure you are pressing the FN key simultaneously with the desired F-key. • Check if any software conflicts are present on your operating system.

Specifications

Feature	Detail
Brand	MageGee
Model	K1 violet
Connectivity Technology	Wired (USB 2.0)
Keyboard Layout	104 Keys, Full Size
Keyboard Backlight	RGB LED (8 colors, 5 modes, adjustable brightness/speed)
Mouse DPI Levels	600/800/1200/1600/2400/3200
Mouse Backlight	7-Color Breathing LED
Special Features	Backlit, Ergonomic, Hotkeys and Media Keys, Splash-Resistant, Transparent Base, 19-Key Anti-Ghosting
Compatible Devices	Laptop, Personal Computer
Operating Systems	Windows XP/Vista/Win7/Win8/Win10, MAC, Linux
Product Dimensions	5.51 x 2.36 x 0.79 inches
Item Weight	2.2 pounds
Material	ABS Engineering Plastic

Refer to Figure 6 for detailed dimensions of the keyboard and mouse.

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official MageGee website. Contact information for customer service can typically be found on the product packaging or the manufacturer's website.

This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CRT3ZYZX

More documents and user manuals: **https://manuals.plus/**