Soundcore A3959

Soundcore P30i by Anker Noise Cancelling Earbuds User Manual

Model: A3959 | Brand: Soundcore

Introduction

Welcome to the user manual for your Soundcore P30i Noise Cancelling Earbuds. These earbuds are designed to provide a superior audio experience with advanced noise cancellation, powerful bass, and convenient features like a 2-in-1 charging case that doubles as a phone stand. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new earbuds.

1. Setup and First Use

1.1 What's in the Box

Upon unboxing your Soundcore P30i earbuds, please ensure all components are present:

- Soundcore P30i Earbuds
- USB-C Charging Cable
- Charging Case
- S/L Ear Tips (M size pre-installed)



Figure 1.1: Included components of the Soundcore P30i package.

1.2 Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case. Connect the USB-C charging cable to the charging port on the case and to a power source. The LED indicator on the case will show charging status.

1.3 Pairing with Your Device (One-Step Pairing)

The Soundcore P30i earbuds feature one-step pairing for convenience:

1. Ensure your device's Bluetooth is enabled.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device, search for "Soundcore P30i" in the Bluetooth settings and select it to connect.
4. Once connected, a voice prompt will confirm successful pairing.



Figure 1.2: One-step pairing process with a mobile device.

2. Operating Your Soundcore P30i Earbuds

2.1 Wearing the Earbuds

Select the ear tips that provide the most comfortable and secure fit for optimal sound quality and noise cancellation. Gently insert the earbuds into your ear canals and twist slightly to secure them.



Figure 2.1: Proper wearing of the Soundcore P30i earbuds for comfort and sound.

2.2 Key Features and Functions

2.2.1 Strong and Smart Noise Cancelling

The earbuds feature an advanced active noise cancelling system that can reduce noise by up to 42dB. Adaptive technology detects external sound and automatically selects an optimized noise cancelling level for your environment.



Figure 2.2: Visual representation of the 42dB noise reduction capability.

2.2.2 Transparency Mode

Switch to Transparency Mode to hear your surroundings without removing the earbuds. This is useful for awareness in busy environments or for quick conversations.

2.2.3 Powerful Bass with BassUp Technology

Experience deep, punchy bass delivered by 10mm drivers, enhanced by Soundcore's exclusive BassUp technology for an immersive audio experience.




Figure 2.3: Enjoying powerful sound from the 10mm drivers.

2.2.4 Long-Lasting Playtime

The earbuds offer up to 10 hours of playtime on a single charge (6 hours with ANC). With the charging case, total playtime extends up to 45 hours (25 hours with ANC). A quick 10-minute charge provides 2 hours of use.



Figure 2.4: Battery life details for Soundcore P30i earbuds.

2.2.5 2-in-1 Charging Case and Phone Stand

The innovative charging case features a built-in phone stand. Simply open the back panel to prop up your phone for hands-free viewing.



Figure 2.5: The versatile 2-in-1 charging case and phone stand.

2.2.6 4-Mic AI Enhanced Calls

Enjoy clear calls with 4 built-in microphones and an AI algorithm that precisely picks up your voice, reducing background noise.



Figure 2.6: Enhanced call clarity with AI-powered microphones.

2.2.7 Soundcore App for Customization

Personalize your listening experience using the Soundcore app. Customize touch controls, adjust EQ settings, activate 3D sound, and find your device.



Figure 2.7: The Soundcore app offers extensive customization options.

2.2.8 Single Earbud Compatible

Use either earbud independently for calls or music, allowing you to stay aware of your surroundings.



Figure 2.8: Flexibility of using a single earbud.

2.2.9 Multipoint Connection

Connect to two devices simultaneously and seamlessly switch between them without re-pairing. Activate this feature through the Soundcore app.



Figure 2.9: Seamless switching between two connected devices.

2.2.10 IP54 Splashproof and Dustproof

The earbuds are rated IP54, providing protection against water splashes and dust, making them suitable for various environments.



Figure 2.10: The IP54 rating ensures durability against splashes and dust.

2.3 Touch Controls

The Soundcore P30i earbuds feature touch-sensitive controls. You can customize these controls via the Soundcore app.

Action	Function (Default)

Action	Function (Default)
Single Tap	Play/Pause, Answer/End Call
Double Tap (Left/Right)	Next Track / Previous Track
Tap and Hold (Left/Right)	Switch Noise Cancelling/Transparency Mode / Activate Voice Assistant

3. Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your Soundcore P30i earbuds.

3.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove ear tips and clean them with mild soap and water. Ensure they are completely dry before reattaching.
- Gently clean the charging contacts on both the earbuds and the case using a dry cotton swab to prevent charging issues.

3.2 Storage

When not in use, always store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from extreme temperatures.

3.3 Battery Care

To maximize battery lifespan, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not in constant use.

4. Troubleshooting

If you encounter issues with your Soundcore P30i earbuds, refer to the following common solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Place them back in the case, close, then open again to re-enter pairing mode. Check your device's Bluetooth settings.
Only one earbud working	Place both earbuds back in the charging case, close the lid, wait a few seconds, then open it again. This often re-syncs them.
Poor sound quality / Low volume	Ensure ear tips are correctly sized and sealed in your ear. Clean any debris from the earbud nozzles. Adjust volume on both earbuds and connected device.
Charging issues	Clean the charging contacts on both earbuds and case. Try a different USB-C cable and power adapter.
Noise cancellation not effective	Ensure a proper seal with the correct ear tip size. Adjust ANC levels in the Soundcore app.

4.1 Resetting the Earbuds

If issues persist, a factory reset may resolve them. Refer to the Soundcore app or the official Soundcore support website for specific reset instructions for the P30i model.

5. Specifications

Feature	Detail
Model Name	P30i
Noise Control	Active Noise Cancellation
Connectivity Technology	Wireless (Bluetooth 5.4)
Playtime (Single Charge)	Up to 10 hours (Normal Mode), 6 hours (ANC Mode)
Total Playtime (with Case)	Up to 45 hours (Normal Mode), 25 hours (ANC Mode)
Quick Charge	10 minutes for 2 hours playtime
Drivers	10mm Dynamic Drivers
Microphones	4-Mic AI Enhanced Calls
Water Resistance	IP54 Splashproof and Dustproof
Charging Port	USB-C
Dimensions	4.25 x 4.25 x 1.42 inches
Item Weight	1.76 ounces
Manufacturer	Anker
UPC	194644193485

6. Warranty and Support

Soundcore products come with a limited warranty. For detailed warranty information, product support, and FAQs, please visit the official Soundcore website or refer to the user guide PDF.

- Official User Guide (PDF): Download PDF
- Soundcore Brand Store: Visit Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question