

[Manuals.plus](#) /

› [MAIDeSiTe](#) /

› MAIDeSiTe Electric Floor Lift User Manual

MAIDeSiTe AX-05

MAIDeSiTe Electric Floor Lift User Manual

Model: AX-05

INTRODUCTION

The MAIDeSiTe Electric Floor Lift (Model AX-05) is designed to provide safe and convenient assistance for individuals who need help standing up independently from the floor. This device is particularly beneficial for the elderly, those recovering from surgery, or individuals with limited mobility. Its robust construction and user-friendly features ensure reliable support and ease of use in various home and care center environments.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the MAIDeSiTe Electric Floor Lift. Failure to follow these safety guidelines may result in injury or damage to the product.

- Do not exceed the maximum weight capacity of 440 lbs (200 kg).
- Ensure the lift is placed on a stable, level surface before and during use.
- Follow all assembly instructions precisely to ensure proper and safe operation.
- Always review usage instructions and precautions, especially when assisting elderly or fall-prone individuals.
- Keep hands and clothing clear of moving parts during operation.
- Do not allow children or unauthorized persons to operate the device.

PRODUCT OVERVIEW

The MAIDeSiTe Electric Floor Lift is engineered for durability and user comfort. It features a robust carbon steel frame and soft, eco-friendly PU leather cushions. The design prioritizes ease of movement and storage, making it a practical solution for home use.




Figure 1: MAiDeSiTe Electric Floor Lift (Model AX-05)

Heavy Duty Moveable Floor Lift



Easy
to move



440LBS
Capacity



Foldable
Storage



Soft
and Comfortable



Figure 2: Key features including 440 LBS capacity and foldable design.

SETUP AND ASSEMBLY

The MAIDeSiTe Electric Floor Lift comes largely pre-assembled. Follow these steps for initial setup:

1. **Unboxing:** Carefully remove the lift from its packaging. It is recommended to have two people for this step due to the product's weight (approximately 48 pounds).
2. **Unfolding:** Gently unfold the lift into its operational position. Ensure all locking mechanisms (if any) are securely engaged.
3. **Attaching Support Legs:** The support legs are designed to be attached before use. Ensure they are firmly in place to provide stability. *Note: Some users have reported that the legs may detach if bumped; ensure they are securely fitted.*

4. **Charging the Remote Control:** The remote control contains rechargeable batteries. Connect the remote to the provided charger and plug it into a power outlet. It is recommended to fully charge the remote before first use.

Easy Transportation

Foldable and wheeled design for easy mobility



Figure 3: The lift in its folded state, highlighting the wheels for transport.

Elderly-friendly Design

Convenient one-button lift and wireless design



Figure 4: The rechargeable remote control and its charging setup.

OPERATING INSTRUCTIONS

The MAiDeSiTe Electric Floor Lift is operated using a simple remote control. Always ensure the user is safely positioned before operating the lift.

1. **Positioning the User:** Carefully assist the individual to sit on the lift's seat while it is in its lowest position.
2. **Secure the Safety Belt:** Fasten the buckle seat belt around the user for added safety and stability during the lift.
3. **Lower the Safety Handrail:** Ensure the safety handrails are in the lowered position to provide support and prevent accidental movement.

4. **Operate with Remote Control:** Use the "Up" button on the remote control to slowly raise the chair to the desired height. Use the "Down" button to lower it. The "Stop Immediately" button can be used for immediate halt.
5. **Assisting the User:** Once the user is at a comfortable standing height, assist them in safely transitioning off the lift.



Video 1: Demonstration of the MAIDeSITe Electric Floor Lift in operation, showing how to assist an elderly person from the floor to a standing position.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your MAIDeSITe Electric Floor Lift, regular maintenance is recommended:

- **Cleaning:** Wipe down the carbon steel frame and PU leather cushions with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Battery Care:** Keep the remote control battery charged. If storing for an extended period, ensure the battery is partially charged and recharge periodically.
- **Inspection:** Periodically inspect all moving parts, fasteners, and electrical connections for any signs of wear or damage. Do not use the lift if any components appear damaged.
- **Storage:** When not in use, the lift can be folded for compact storage. If support legs are removable, ensure the seat side is placed against a wall for stability during storage to prevent tipping.

Details



Figure 5: Detailed dimensions of the lift, useful for storage planning.

TROUBLESHOOTING

If you encounter issues with your MAIDeSiTe Electric Floor Lift, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Lift does not operate.	Remote control battery is low or uncharged.	Ensure the remote control is fully charged.

Problem	Possible Cause	Solution
Lift operates slowly or inconsistently.	Low battery charge; weight exceeds capacity.	Recharge the remote control. Verify user weight is within the 440 lbs limit.
Lift feels unstable.	Support legs not properly attached or surface is uneven.	Ensure support legs are securely attached. Move the lift to a flat, stable surface.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	MAIDeSITe
Model Name	AX-05
Product Dimensions	12.2"D x 18.9"W x 30.7"H
Maximum Weight Recommendation	440 Pounds
Item Weight	48 pounds
Material	Carbon Steel Frame, PU Leather Cushions
Special Feature	Foldable, Rechargeable Remote Control
Lifting Range	2.5" to 22.2"
Included Components	Remote

WARRANTY AND SUPPORT

MAIDeSITe provides a returnable service and stands behind the quality of its products. If the chair lift is damaged in transit or if you experience any issues, please contact customer support directly.

For assistance, please contact the seller, Maidesite-QB, through your purchase platform or refer to the contact information provided with your product packaging.

We are committed to providing quality products and excellent customer support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do you keep the right leg from popping off the MAIDeSITe AX-05 Electric Floor Lift?

The MAIDeSITe AX-05 Electric Floor Lift manual notes that "some users have reported that the legs may detach if bumped." To prevent the right leg (or any support leg) from popping off, you should...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0CRYLC24S>

More documents and user manuals: <https://manuals.plus/>