

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Devoko](#) /
- › [Devoko 180 x 70 cm Ergonomic Gaming Desk User Manual](#)

Devoko 180 x 70 cm

Devoko 180 x 70 cm Ergonomic Gaming Desk User Manual

Model: 180 x 70 cm

[Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#) [Support](#)

1. PRODUCT OVERVIEW

The Devoko 180 x 70 cm Ergonomic Gaming Desk is designed to provide a comfortable and efficient workspace for gaming or professional use. Its spacious carbon fiber tabletop, ergonomic design, and practical accessories enhance user experience.



Image 1.1: The Devoko 180 x 70 cm Gaming Desk in a typical gaming setup, showcasing its spacious design and ability to accommodate multiple monitors and peripherals.

Key Features:

- **Spacious Tabletop:** A generous 180 x 70 cm surface provides ample room for computers, monitors, keyboards, mice, and other accessories.
- **Practical Accessories:** Includes a cup holder, headphone hook, and a large mouse pad to maintain a tidy and organized workspace.
- **Ergonomic Design:** Features a curved edge near the user's body to promote comfortable arm positioning and a relaxed sitting posture.
- **Durable Carbon Fiber Surface:** The tabletop is anti-slip, waterproof, scratch-resistant, and easy to clean, offering both durability and a sleek aesthetic.
- **Easy Assembly:** Designed for straightforward assembly, allowing quick setup.

2. SETUP AND ASSEMBLY

Please follow these instructions carefully for safe and correct assembly. It is recommended to have a second person assist with assembly due to the size and weight of the components. Ensure all parts are present before beginning.

2.1 Safety Information

- Always follow the assembly instructions provided with the product.
- Do not overtighten screws during initial assembly; tighten them firmly once all components are aligned.
- Keep small parts away from children.
- Ensure the desk is placed on a level surface after assembly to prevent instability.
- Do not exceed the recommended weight capacity (approximately 30 kg).

2.2 Package Contents

Verify that all components listed in the included parts list are present. If any parts are missing or damaged, please contact customer support.

2.3 Assembly Steps

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Frame:** Attach the main support beams to the desk legs using the provided screws and tools. Ensure all connections are secure but do not fully tighten yet.
3. **Attach Tabletop Sections:** The tabletop may consist of multiple sections. Align these sections and secure them together using the wooden dowels and connectors. Then, attach the assembled tabletop to the frame.
4. **Install Accessories:** Mount the cup holder and headphone hook to the designated locations on the desk frame.
5. **Final Tightening:** Once the entire desk is assembled and aligned, firmly tighten all screws.
6. **Apply Mouse Pad:** Place the large mouse pad on the tabletop.



Image 2.1: Underside view of the desk, illustrating the robust frame structure and potential cable management features that contribute to stability.

3. OPERATION AND USAGE

The Devoko Gaming Desk is designed for optimal comfort and functionality. Here's how to make the most of its features:

3.1 Utilizing the Workspace

- **Spacious Surface:** Arrange your monitors, keyboard, mouse, and other peripherals on the 180 x 70 cm tabletop. The ample space allows for a multi-monitor setup and comfortable arm movement.
- **Ergonomic Curve:** Position yourself so that the curved front edge of the desk aligns with your body. This design helps relax your arms and wrists during extended use.

3.2 Using Integrated Accessories

- **Cup Holder:** Use the integrated cup holder to keep your beverages secure and prevent spills on your equipment.
- **Headphone Hook:** Hang your headphones on the dedicated hook when not in use to keep them easily accessible and off the desk surface.
- **Large Mouse Pad:** The included full-surface mouse pad provides a consistent and smooth tracking surface for your mouse, enhancing precision and comfort.



Image 3.1: A diagram highlighting the 70 cm depth of the desk and the ergonomic curve designed for arm relaxation and comfortable seating.

4. CARE AND MAINTENANCE

Proper care will ensure the longevity and appearance of your Devoko Gaming Desk.

4.1 Cleaning the Tabletop

- The carbon fiber surface is waterproof and easy to clean. Use a soft, damp cloth with mild soap and water to wipe down the surface.
- Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- For spills, wipe immediately to prevent any potential staining, although the surface is designed to be resistant.

4.2 Frame and Accessories

- Wipe the metal frame and plastic accessories with a damp cloth.
- Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.

4.3 Mouse Pad Care

- The large mouse pad can be cleaned with a damp cloth. For deeper cleaning, hand wash with mild soap and air dry. Do not machine wash or tumble dry.



Image 4.1: Close-up view of the carbon fiber tabletop, demonstrating its scratch-resistant and waterproof properties, making it easy to maintain.

5. TROUBLESHOOTING

If you encounter any issues with your Devoko Gaming Desk, refer to the following common problems and solutions:

5.1 Desk Instability / Wobbling

- **Check all Screws:** Ensure all assembly screws are fully tightened. Loose connections are a common cause of instability.
- **Level Surface:** Verify that the desk is placed on a flat and level floor. Uneven surfaces can cause wobbling.
- **Re-assembly:** If instability persists, carefully disassemble and re-assemble the desk, paying close attention to aligning all parts correctly before tightening screws.
- **Weight Distribution:** Ensure weight is evenly distributed on the desk surface and that the maximum weight capacity is not exceeded.

5.2 Parts Missing or Damaged

- **Contact Support:** If you find any parts missing or damaged upon unboxing, do not proceed with assembly. Contact Devoko customer support immediately for assistance.

5.3 Difficulty with Assembly

- **Review Instructions:** Double-check the assembly manual to ensure all steps are being followed correctly.
- **Seek Assistance:** Some steps may be easier with two people.

6. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Devoko
Model	180 x 70 cm Ergonomic Gaming Desk

Feature	Detail
Color	Black
Product Dimensions (L x W x H)	180 x 70 x 75 cm (approx. 80P x 180L x 75H cm as per some specs)
Material	Carbon Fiber (tabletop), Metal (frame)
Special Features	Compact, Ergonomic, Scratch-resistant, Rust-resistant
Desk Design	Computer Desk
Shape	Rectangular with ergonomic curve
Maximum Weight Capacity	Approximately 30 kg (as per user reviews)

7. WARRANTY INFORMATION

Devoko products are manufactured to high-quality standards. Specific warranty terms and conditions may vary by region and retailer. Please retain your proof of purchase for any warranty claims.

For detailed warranty information, please refer to the documentation included with your product or contact Devoko customer support.

8. CUSTOMER SUPPORT

If you require further assistance, have questions about assembly, operation, or need to report a missing/damaged part, please contact Devoko customer support.

Please have your product model number (180 x 70 cm Ergonomic Gaming Desk) and proof of purchase ready when contacting support.

For the most up-to-date contact information, please visit the official Devoko website or refer to the contact details provided by your retailer.