CalExotics SE-0001-15-3

CalExotics Connect Contoured G-Spot Vibrator Wand User Manual

Model: SE-0001-15-3 | Brand: CalExotics

Introduction

The CalExotics Connect Contoured G-Spot Vibrator Wand is designed for precise G-spot stimulation and internal pleasure. This device features a gently curved tip, body-safe silicone, multiple vibration modes, and app remote control capabilities. Please read this manual thoroughly before use to ensure proper operation and care.



Image: Front view of the CalExotics Connect Contoured G-Spot Vibrator. The device is purple, sleek, and ergonomically curved.

Setup

1. Charging the Device

Before first use, fully charge your device. A complete charge takes approximately 2 hours.

- Connect the included USB charging cord to the device's charging port.
- Plug the USB end into a compatible USB power source (e.g., computer, USB wall adapter).
- The LED light on the device will flash while charging.
- The LED light will glow solid when fully charged.



Image: The vibrator connected via its USB charging cable to a laptop, illustrating the charging process.

2. App Download and Connection (Love Spouse App)

The device can be controlled via the Love Spouse app for enhanced features and remote play.

1. Download and install the "Love Spouse" app from your device's app store (available for both Android and iOS).
2. Open the app and complete the new user registration.
3. To add your device, tap "add a device" within the app.
4. Enter the device code found in the product packaging or instruction manual.
5. Press and hold the power button on the device for 3 seconds to activate it. The LED light will indicate activation.
6. Once successfully bound, you can access various control modes.

Your browser does not support the video tag.

Video: This video demonstrates how to download the Love Spouse app, register, bind your device, and activate it for app control. It covers Classic, Game, Video, Music, Draw, Shake, and Interactive modes.

Operation

1. Independent Use (Without App)

- **To Unlock/Lock:** Press and hold the power button for 3 seconds. This activates the security travel lock feature.
- **To Turn ON Vibration:** Once unlocked, press the power button again.
- **To Cycle Modes:** Continue to press the power button to cycle through the 9 functions of vibration, pulsation, and escalation.
- **To Turn OFF:** Press and hold the power button for 3 seconds.
- The device features a memory chip that resumes on the last function used.

2. App Control (Love Spouse App)

After binding your device to the Love Spouse app, you can explore various interactive modes:

- **Classic Mode:** Tap icons to cycle through 9 functions of vibration.
- **Game Mode:** Interact with games in the app to control vibration patterns.
- **Video Mode:** Select a local video from your mobile device and explore the 9 functions of vibration while your video plays.
- **Music Mode (Android):** Open a music player to play music, then return to the Love Spouse app and tap play.

The device will vibrate along with the music.

- **Music Mode (iOS):** Tap "WiFi Import" on your mobile device. On a computer connected to the same network, enter the provided URL and upload a music file. Then, go back to the app and tap play. The device will vibrate along with the music.
- **Draw Something:** Draw anything you desire on the screen, and the vibration levels will follow your drawing.
- **Shake:** Shake your phone to control the vibration intensity.
- **Interactive Mode:** Select a friend to interact with. You can invite them to a video or voice chat and play together using Classic Mode, Draw Something, or Shake.

3. Record Feature

The app allows you to record custom vibration patterns:

- Choose from Classic Mode, Music Mode, Draw Something, or Shake.
- Tap the green icon to start recording your desired vibration frequency.
- Explore different vibration functions while recording.
- To stop recording, tap the green icon again and then the pause button.
- Give your recorded file a name to save it.
- You can share your recorded vibration frequency with others by tapping the share option.
- Use your recorded vibration frequency at any time by tapping the icon in the top right corner of the Classic Mode screen.

Maintenance

Cleaning

The device is waterproof (IPX7 submersible), making cleaning simple.

- Always clean the device thoroughly before and after each use.
- Wash with warm water and a toy cleaner or mild soap.
- Rinse thoroughly and pat dry with a lint-free cloth.
- Avoid using cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.



Image: The vibrator submerged in water, highlighting its waterproof design for easy cleaning.

Storage

- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- Keep it separate from other toys made of different materials to prevent damage or reactions.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is low or depleted; device is locked.	Charge the device fully. Press and hold the power button for 3 seconds to unlock.
App cannot connect to the device.	Bluetooth is off; device is not activated; incorrect device code.	Ensure Bluetooth is enabled on your phone. Activate the device by holding the power button for 3 seconds. Re-enter the device code carefully.
Vibrations are weak or inconsistent.	Low battery; device malfunction.	Recharge the device. If the problem persists after charging, contact customer support.

Specifications

- **Model Name:** CalExotics Connect Contoured G
- **Item Model Number:** SE-0001-15-3
- **Brand:** CalExotics
- **Material:** Silicone
- **Color:** Purple
- **Product Dimensions:** 7 x 1.25 x 1.25 inches; 11.84 ounces
- **Batteries:** 1 Lithium Polymer battery required (included)
- **Charging:** USB rechargeable (cord included)
- **Charge Time:** Approximately 2 hours for a complete charge
- **Run Time:** 40 minutes on high speed, 60 minutes on low speed
- **Waterproof Rating:** IPX7 Submersible
- **Features:** 9 functions of vibration, pulsation, and escalation; memory chip; security travel lock; APP controlled.



Image: Side view of the CalExotics Connect Contoured G-Spot Vibrator, illustrating its ergonomic shape and approximate dimensions.

Warranty

This product comes with a**1-year limited manufacturer warranty**. Please retain your proof of purchase for warranty claims. For details regarding the warranty coverage and process, refer to the information provided in your product packaging or contact CalExotics customer support.

Support

For further assistance, technical support, or warranty inquiries, please contact CalExotics customer service. Refer to the contact information provided in your product packaging or visit the official CalExotics website.
Important Note: California Exotic Novelties LLC, as a third-party user of the Love Spouse application, does not assume any responsibility for any losses or damages that users may incur because of any transmissions, communications, or actions conducted through the application. Users are encouraged to review and adhere to the service terms and privacy policies of the application provider.

Safety Information

- For adult use as a non-medical pleasure device only. Not for medical use.
- Discontinue use in the event of any medical condition or pain.
- Consult a healthcare professional if you have any concerns.