Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CalExotics SE-0609-65-3

CalExotics Jack Rabbit Signature Silicone Wave Motion Rabbit Vibrator User Manual

Model: SE-0609-65-3

Product Overview

Thank you for choosing the CalExotics Jack Rabbit Signature Silicone Wave Motion Rabbit Vibrator. This manual provides essential information for the safe and effective use, care, and maintenance of your device. Please read it thoroughly before first use and retain it for future reference.

Key Features:

- Sensual wavy action combined with flickering rabbit ears.
- 3 distinct speeds for wavy action.
- 7 functions of vibration, pulsation, and escalation in the rabbit ears.
- Constructed from body-safe silicone.
- 100% waterproof design (IPX7 rated).
- Intuitive push-button controls with LED indicators.
- Security travel lock feature.
- USB rechargeable with included charging cord.



Image: The CalExotics Jack Rabbit Signature Vibrator in blue, displayed alongside its retail packaging which highlights features like 7 functions, 3 wavy speeds, silicone material, IPX7 waterproof rating, USB rechargeable, 1-year warranty, and ease of use.

Product Demonstration Video:

Your browser does not support the video tag.

Video: An overview of the CalExotics Jack Rabbit Signature, showcasing its design and various features in action. This video provides a visual introduction to the product's capabilities.

Setup and First Use

Charging the Device

Your Jack Rabbit Signature Vibrator is USB rechargeable. For optimal performance, fully charge the device before its first use and after each subsequent use.

1. Locate the charging port on the device. This port is typically found near the base of the handle.
2. Connect the small end of the included USB charging cord to the device's charging port.
3. Connect the larger USB end of the cord to a compatible USB power source, such as a computer USB port or a USB wall adapter.
4. The LED lights on the device will illuminate or change color to indicate that charging is in progress.
5. A complete charge typically takes approximately **2 hours**.
6. Once fully charged, the device will run for about **90 minutes on high speed** and **110 minutes on low speed**.
7. Disconnect the charging cable once charging is complete. Ensure the charging port is dry before and after charging.



Image: The CalExotics Jack Rabbit Signature Vibrator in blue, demonstrating the connection of the USB charging cable to the device's base for recharging.

Operating Instructions

Power On/Off

1. To **power on** the device, press and hold the power button (marked with a circular power symbol) for a few seconds until the device activates and the LED lights illuminate.
2. To **power off** the device, press and hold the power button for approximately**3 seconds** until the device stops and the LED lights turn off.

Controlling Functions

The Jack Rabbit Signature features intuitive push-button controls for its various functions:

- **Wavy Action Control:** Use the button marked with a wave symbol (often 'M' or similar) to cycle through the **3 speeds** of sensual wavy action. Each press will advance to the next speed.
- **Rabbit Ear Vibration Control:** Use the button marked with a vibration symbol (often a lightning bolt or 'S') to cycle through the **7 functions** of vibration, pulsation, and escalation in the rabbit ears. Each press will change the pattern.
- The main shaft's wavy action and the rabbit ears' vibration can be operated **independently or simultaneously**, allowing for a customizable experience.

Security Travel Lock

To prevent accidental activation during storage or travel, the device includes a security travel lock feature. To activate or deactivate this feature, refer to the specific instructions provided on the product packaging or the manufacturer's website. Typically, this involves holding down two buttons simultaneously for a few seconds.






Image: A detailed graphic of the CalExotics Jack Rabbit Signature Vibrator, illustrating its dimensions, the location of the control buttons, and visual cues for the 3 speeds of wavy action and 7 functions of the flickering bunny ears.

Operating Controls Demonstration Video:

Your browser does not support the video tag.

Video: A demonstration of the CalExotics Jack Rabbit Signature's controls, showing how to power on/off and cycle through the various vibration and wavy action modes.

Care and Maintenance

Cleaning

Proper cleaning is essential for hygiene and to extend the lifespan of your device:

1. Always clean the device thoroughly before and after each use.
2. Wash the device with warm water and a mild, toy-safe soap or a specialized toy cleaner.
3. Rinse thoroughly with clean water, ensuring no soap residue remains.
4. Pat dry with a lint-free cloth or allow it to air dry completely before storing.
5. **Do not** use cleaners containing alcohol, petroleum, or acetone, as these chemicals can damage the silicone material.

Storage

Store your device in a clean, dry, and dust-free environment. Keep it away from direct sunlight and extreme temperatures. To prevent potential material degradation, store it separately from other toys made of different materials.

Waterproof Ability

The device is **100% waterproof (IPX7 rated)**, making it suitable for use in wet environments and ensuring easy cleaning. Always ensure the charging port is completely dry before connecting the charging cable.

Troubleshooting

If you encounter any issues with your device, please refer to the following common troubleshooting steps:

- **Device not turning on:** Ensure the device is fully charged. Connect it to the charger for at least 2 hours.
- **Device not holding a charge:** Verify that the charging cable and power source are functioning correctly. Check the charging port for any debris that might obstruct the connection.
- **Weak or inconsistent vibration/wavy action:** This often indicates a low battery. Recharge the device fully.
- **Buttons unresponsive:** Check if the security travel lock feature is engaged. Refer to the operating instructions to deactivate it.
- **Unusual noise or smell:** Discontinue use immediately. If the issue persists, contact customer support.

Product Specifications

Feature	Detail
Model Name	Jack Rabbit Signature
Item Model Number	SE-0609-65-3
Brand	CalExotics
Material	Silicone
Color	Blue
Product Dimensions	9 x 3 x 1.75 inches; 1.2 pounds
Battery Type	1 Lithium Ion battery (included)
Charge Time	Approximately 2 hours
Run Time	90 minutes (high speed), 110 minutes (low speed)
Waterproof Rating	100% Waterproof (IPX7)

Warranty Information

This CalExotics Jack Rabbit Signature Vibrator is covered by a**1-year limited manufacturer warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your original proof of purchase for any warranty claims.
For detailed warranty terms, conditions, and exclusions, please refer to the official CalExotics website or contact customer support directly.

Customer Support

For further assistance, questions, or to make a warranty claim, please contact CalExotics customer support:

- **Manufacturer:** California Exotic Novelties
- **Official Website:** calexotics.com
- **QR Code for more information:** Scan for additional language and information
- **Contact Information:** Please visit the official CalExotics website for the most current contact details, including phone numbers and email addresses.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CS1RB3J8

More documents and user manuals: **https://manuals.plus/**