

[Manuals.plus](#) /

› [Berilona](#) /

› Berilona X60 4G Kids Smartwatch Phone User Manual

Berilona X60

Berilona X60 4G Kids Smartwatch Phone User Manual

Model: X60 | Brand: Berilona

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Berilona X60 4G Kids Smartwatch Phone. Please read this guide thoroughly to ensure proper use and to maximize the features of your device.



Image: The Berilona X60 4G Kids Smartwatch Phone in Navy Blue, showcasing its design and screen.

WHAT'S INCLUDED

- 1 x 4G Kids Smartwatch Phone (Berilona X60)
- 1 x Charging Cable
- 1 x User Manual (this document)
- 1 x Watch Band (pre-installed)
- 1 x 4G SIM Card (pre-installed, requires activation)

SETUP GUIDE

1. Charging the Smartwatch

Before initial use, fully charge the smartwatch using the provided charging cable. Connect the magnetic end of the cable to the charging port on the back of the watch and the USB end to a compatible power adapter (not included) or computer USB port. A full charge typically takes 2-3 hours.

2. SIM Card Activation

The smartwatch includes a pre-installed 4G SIM card. To enable calling features, the SIM card must be activated. Follow these steps:

1. Visit the activation page: activate.speedtalkmobile.com
2. Input the 19-digit SIM card number.
3. Enter your email address and get a verification PIN.
4. Enter the ZIP code and choose your service plan.
5. Enter customer information.
6. Enter billing information.

Once activated, power off the device, insert the SIM card (if not already inserted), and then power it back on to connect to the network.



Image: Visual guide for activating the included 4G SIM card.

3. Initial Power On and Basic Navigation

Press and hold the power button (usually on the side) to turn on the smartwatch. The touchscreen allows for intuitive navigation. Swipe left/right or up/down to browse through applications and settings.

Your browser does not support the video tag.

Video: An overview of the Berilona X60 Kids Smart Watch, demonstrating its features and interface. This video shows the watch powering on, navigating menus, and setting time/date.

Setting Date and Time:

Navigate to the 'Settings' menu. Locate 'Date' and 'Time' options to adjust them as needed. Use the up/down arrows on the screen to set the correct values.

Changing Wallpapers:

The smartwatch offers multiple customizable wallpapers. Access the 'Theme' or 'Wallpaper' setting to select a preferred background for the watch face.



Image: A selection of colorful and engaging wallpapers available for the smartwatch.

OPERATING INSTRUCTIONS

1. Communication Features

Two-Way Calling:

After SIM card activation, the smartwatch supports two-way calling. You can make and receive calls from pre-approved contacts. Ensure contacts are saved in the watch's phonebook.

SOS Emergency Call:

In an emergency, press and hold the SOS button for 3-5 seconds. The watch will automatically dial up to 3 pre-set SOS numbers in two rounds and send messages to guardians, ensuring timely assistance.



Image: An overview of the smartwatch's main functions, highlighting communication and utility features.

2. Parental Controls and Class Mode

The smartwatch features parental control options to manage game time and activate 'Class Mode'. This allows parents to set specific hours during which games are disabled, preventing distractions during study or sleep times.

3. Multimedia and Entertainment

Camera and Photo Album:

Use the built-in camera to take photos. Captured images are stored in the photo album, which can be accessed directly from the watch.

Video and Music Player:

The smartwatch supports video and music playback. Files can be loaded onto the device for entertainment. Ensure files are in compatible formats.



Image: Depiction of the camera function and available audio books on the smartwatch.

4. Educational and Utility Features

Pedometer:

The integrated pedometer tracks daily steps, encouraging physical activity.

Habit Tracking & Alarm Clock:

Set alarms for various activities like waking up, brushing teeth, or homework. The habit tracking feature helps children develop routines.



Image: Visual representation of the habit tracking and alarm clock interface.

Learning Cards:

Engage with interactive learning cards designed to help children learn about animals, food, plants, shapes, and vehicles.



Image: Example of learning cards for various categories like animals, food, and vehicles.

Other Applications:

The smartwatch also includes a calculator, calendar, recorder, and daily schedule management tools.

MAINTENANCE

- **Cleaning:** Wipe the watch screen and strap with a soft, dry cloth. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the smartwatch in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The device has an IPX7 waterproof rating, meaning it can withstand splashes but is not suitable for swimming or prolonged submersion. Avoid exposing it to hot water or steam.

TROUBLESHOOTING

- **Device not turning on:** Ensure the watch is fully charged. If it still doesn't turn on, try holding the power button for an extended period (10-15 seconds).
- **No network signal/calling issues:** Verify that the SIM card is correctly inserted and activated. Check for network coverage in your area.
- **Screen unresponsive:** Restart the device. If the issue persists, ensure the screen is clean and dry.
- **Battery draining quickly:** Reduce screen brightness, close unused applications, and limit game time.

SPECIFICATIONS

Model Name	X60
Screen Size	1.57 Inches
Display Type	LCD
Resolution	240 x 280
Connectivity Technology	Bluetooth, 4G Cellular
Battery Cell Composition	Lithium Polymer
Water Resistance Level	IPX7 (Not Water Resistant for swimming/submersion)
Item Dimensions	1.97 x 1.57 x 0.39 inches
Band Material Type	Silicone
Supported Application	Pedometer
Compatible Phone Models	Compatible with iOS and Android devices

WARRANTY INFORMATION

The Berilona X60 4G Kids Smartwatch Phone comes with **No Warranty** as per product specifications. Please refer to your retailer's return policy for any issues.

SUPPORT

For further assistance or inquiries regarding your Berilona X60 Smartwatch, please contact the manufacturer or your point of purchase. Keep your purchase receipt handy for any support requests.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question