

## Feelfunn ZX-BR-55H

# Feelfunn 1.3 Cu.Ft Beverage Refrigerator Cooler Instruction Manual

Model: ZX-BR-55H

## 1. INTRODUCTION AND OVERVIEW

---

This manual provides essential information for the safe and efficient operation of your Feelfunn 1.3 Cu.Ft Beverage Refrigerator Cooler, Model ZX-BR-55H. Please read these instructions thoroughly before installation and use, and retain them for future reference.

**Reminder: For peak performance, maintain the fridge upright for 24 hours before initial use.**

## 2. SAFETY INFORMATION

---

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch cold surfaces, especially when the appliance is operating.
- Ensure proper grounding.
- Unplug the appliance before cleaning or performing any maintenance.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- The appliance uses R600A refrigerant, which is flammable. Handle with care and ensure proper ventilation.
- This appliance is UL certified for safety standards.

## 3. PRODUCT FEATURES

---

Your Feelfunn beverage cooler is designed with several features to enhance convenience and

performance:

- **Compact Capacity:** 1.3 Cubic Feet, accommodating up to 50 standard cans or 12 bottles.
- **Precision Temperature Control:** Digital touchscreen display with a temperature range of 40°F to 61°F.
- **Advanced Cooling System:** 3D circulating air cooling and frost-free technology for consistent temperatures.
- **Energy Efficient:** Operates with low noise ( $\leq 38\text{dB}$ ) and an estimated energy cost of approximately \$0.07 per day.
- **Premium Design:** Double-layer glass door with LOW-E coating for insulation and visibility.
- **Flexible Installation:** Reversible door hinge and adjustable feet.
- **Interior Lighting:** Soft blue LED lighting.



Figure 1: Front view of the Feelfunn 1.3 Cu.Ft Beverage Refrigerator Cooler with various drinks.

# Optimal Storage Capacity

Never run out of your favorite chilled drinks, perfectly organized for any occasion



1.3 Cu.Ft



55  
Cans  
330 mL

OR



12  
Bottles  
750 mL



Figure 2: Optimal storage capacity and dimensions of the beverage cooler (16.9"W x 16.3"D x 18.3"H).

# Touchscreen Temperature Control

Chill to perfection with tailored temperature settings for every drink



Figure 3: Touchscreen temperature control panel with LED light switch and temperature display.

## 4. SETUP AND INSTALLATION

### 4.1 Unpacking

Carefully remove all packaging materials. Inspect the appliance for any shipping damage. If damage is found, do not plug in the unit and contact customer support immediately.

### 4.2 Placement

This appliance is designed for freestanding or under-counter installation. Ensure adequate ventilation around the unit. Allow at least 2-3 inches of space at the back and sides for proper air circulation. Avoid placing the unit in direct sunlight or near heat sources.

### 4.3 Leveling

Adjust the leveling feet at the bottom of the unit to ensure it is stable and level. A level appliance operates more efficiently.

### 4.4 Initial Power-On

After placement, allow the refrigerator to stand upright for at least 24 hours before plugging it into a power outlet. This allows the refrigerant to settle, preventing potential damage to the cooling system.

## 4.5 Reversible Door

The door hinge is reversible, allowing you to change the door swing direction to suit your space. Refer to the detailed instructions in the included user manual for the reversal process.



Figure 4: The reversible door feature allows for flexible placement.

## 5. OPERATING INSTRUCTIONS

### 5.1 Powering On/Off

Plug the unit into a standard 115V electrical outlet. The unit will power on automatically. To turn off, unplug the unit.

### 5.2 Temperature Control

Use the touchscreen controls located on the top panel to adjust the temperature. The digital display shows the current temperature. Use the '+' and '-' buttons to set your desired temperature between 40°F and 61°F.

### 5.3 Interior LED Light

Press the light bulb icon on the touchscreen panel to turn the interior blue LED light on or off.

## **5.4 Loading Beverages**

Arrange beverages on the removable shelves. Do not overload the shelves or block the internal air circulation vents. For optimal cooling, allow space between items.

## **6. MAINTENANCE AND CLEANING**

---

### **6.1 Frost-Free Operation**

The appliance features frost-free technology, minimizing ice buildup and eliminating the need for manual defrosting under normal operating conditions.

### **6.2 Cleaning the Interior**

Unplug the unit before cleaning. Use a soft cloth dampened with a mild detergent solution to clean the interior surfaces. Rinse with clean water and dry thoroughly. Do not use abrasive cleaners or harsh chemicals.

### **6.3 Cleaning the Exterior**

Wipe the exterior surfaces with a soft, damp cloth. For the glass door, use a glass cleaner. Ensure no water enters the control panel or electrical components.

### **6.4 Removable Shelves**

The shelves can be removed for cleaning. Wash them with mild soap and water, then dry completely before returning them to the unit.

# Product Details



Soft LED Light



Removable Shelves



Adjustable Feet



Reversible Hinge



Figure 5: Key product details including removable shelves and adjustable feet.

## 7. TROUBLESHOOTING GUIDE

Before contacting customer support, review the following common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate	Not plugged in; circuit breaker tripped; power outage.	Ensure plug is secure; check circuit breaker; verify power supply.
Temperature is not cold enough	Door not closed properly; excessive door openings; warm items added; poor ventilation; temperature setting too high.	Check door seal; reduce door openings; allow warm items to cool before loading; ensure proper clearance around unit; lower temperature setting.
Appliance is noisy	Unit not level; loose parts; normal compressor operation.	Adjust leveling feet; check for loose items inside; compressor noise is normal.

Problem	Possible Cause	Solution
Water on floor	Drain pan overflowing; high humidity.	Check and empty drain pan if accessible; this is rare with frost-free units.

If the problem persists after checking these solutions, please contact customer support.

## 8. SPECIFICATIONS

Specification	Detail
Brand	Feelfunn
Model Number	ZX-BR-55H
Capacity	1.3 Cubic Feet (approx. 50 cans / 12 bottles)
Dimensions (W x D x H)	16.9" x 16.3" x 18.3"
Item Weight	33.2 Pounds
Temperature Range	40°F to 61°F
Noise Level	≤38 dB
Voltage	115 Volts
Defrost System	Frost Free
Refrigerant	R600A
Installation Type	Under-Counter/Freestanding
Certification	UL
Included Components	Beverage Fridge, Removable Shelves, User Manual

## 9. WARRANTY AND SUPPORT

### 9.1 Warranty Information

This Feelfunn beverage refrigerator cooler comes with a 1-year accessory maintenance service. Please retain your proof of purchase for warranty claims.

### 9.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact Feelfunn customer support. Refer to the contact information provided with your purchase or on the official Feelfunn website.