

EDYELL V1

EDYELL V1 Wireless Earbuds User Manual

Model: V1

INTRODUCTION

The EDYELL V1 Wireless Earbuds offer a high-quality audio experience with advanced features designed for comfort and convenience. These half-in-ear headphones feature 13mm drivers for rich sound, Bluetooth 5.3 for stable connectivity, and extended battery life. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your earbuds.

WHAT'S IN THE BOX

Upon opening your EDYELL V1 Wireless Earbuds package, you will find the following components:

- 1 pair of EDYELL V1 Earbuds
- 1 Earbud Charging Case
- 1 Type-C Charging Cable
- 1 User's Manual (this document)
- 1 Warranty Card / 1 Earphone storage bag



Image: The EDYELL V1 Wireless Earbuds, their charging case, and the included protective storage bag.

Your browser does not support the video tag.

Video: An overview of the EDYELL V1 Wireless Earbuds, demonstrating unboxing and key features.

SETUP

Initial Charging

Before first use, ensure the charging case and earbuds are fully charged. Connect the provided Type-C charging cable to the charging port on the case and plug the other end into a USB power source. The LED display on the case will indicate the charging status and battery percentage. A full charge is recommended for optimal battery performance.

LED Battery Power Display



Image: The EDYELL V1 charging case connected via a Type-C cable, displaying its battery level on the LED screen.

Bluetooth Pairing

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. **Activate Bluetooth:** On your device (smartphone, tablet, computer), enable Bluetooth.
3. **Select Device:** In your device's Bluetooth settings, look for "V1" in the list of available devices and select it to connect.
4. **Confirmation:** Once connected, you will hear an audio prompt from the earbuds, and "V1" will show as "Connected" on your device.

The earbuds support one-step pairing and will automatically reconnect to the last paired device when removed from the case, provided Bluetooth is enabled on the device.

One-step Pairing

Earbuds will auto power on and pairing when open the case



Image: A visual representation of the one-step pairing process, showing the earbuds and a phone's Bluetooth menu.



Image: Illustration highlighting the Type-C charging interface and the automatic quick pairing feature of the earbuds.

OPERATING INSTRUCTIONS

Touch Controls

The EDYELL V1 earbuds feature intuitive touch controls on each earbud for managing audio playback, calls, and voice assistant activation.

Action	Control
Play/Pause	Single tap on either earbud
Next Track	Double tap on the Right earbud
Previous Track	Double tap on the Left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Press and hold either earbud for 2 seconds
Activate Voice Assistant (Siri/Google Assistant)	Triple tap on either earbud



Image: Depiction of the touch control functionality and compatibility with voice assistants like Siri and Google Assistant.

Battery Life

The EDYELL V1 earbuds provide up to 6 hours of music time and 5 hours of talk time on a single charge. The charging case extends the total playtime to over 48 hours. The LED display on the charging case indicates the remaining battery percentage of the case and the charging status of each earbud.



Image: A visual emphasizing the extended 48-hour total playtime provided by the earbuds and their charging case.



Image: Detailed view of the charging case's dual LED display and battery life metrics for music, talk, and total playtime.

MAINTENANCE

Cleaning

To maintain optimal sound quality and hygiene, regularly clean your earbuds and charging case. Use a soft, dry, lint-free cloth to wipe down the surfaces. For the earbud grilles, gently use a cotton swab or a soft brush to remove any earwax or debris. Avoid using abrasive materials or harsh chemicals.

Storage

When not in use, store the earbuds in their charging case to protect them from dust, scratches, and accidental damage. Keep the case and earbuds in a cool, dry place, away from extreme temperatures and direct sunlight.

EDYELL Earbud case

Lightweight and portable



Image: The compact and portable EDYELL earbud case, demonstrating its ease of carrying and protective features.

Great Solution for Gadgets

- 🔑
- 🔌
- 📄
- 📱
- 🔧
- 👛
- 📁
- 📀



Portable Size

Convenient to take your accessories anywhere



Image: The versatile EDYELL earbud case, suitable for protecting various small gadgets and designed for easy portability.

Water Resistance

The EDYELL V1 earbuds feature IPX7 splash and sweat resistance. This means they are protected against immersion in water up to 1 meter for up to 30 minutes. However, they are not designed for swimming or

prolonged submersion. Ensure the earbuds are dry before placing them back in the charging case to prevent damage.



Image: Visual representation of the earbuds' IPX7 splash and sweat resistance.

TROUBLESHOOTING

If you encounter any issues with your EDYELL V1 Wireless Earbuds, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing/connecting	<ul style="list-style-type: none">◦ Ensure earbuds are charged and out of the case.◦ Turn off and on Bluetooth on your device.◦ Forget "V1" from your device's Bluetooth list and re-pair.◦ Try pairing with a different device to rule out device issues.
Only one earbud working	<ul style="list-style-type: none">◦ Place both earbuds back in the charging case, close the lid, wait a few seconds, then open again.◦ Ensure both earbuds have sufficient charge.◦ Reset the earbuds (refer to specific reset instructions if available in a full manual, otherwise try re-pairing).
Low volume or poor sound quality	<ul style="list-style-type: none">◦ Clean the earbud grilles to remove any obstructions.◦ Adjust the volume on both your device and the earbuds.◦ Ensure the earbuds are properly seated in your ears for optimal sound.◦ Move closer to your connected device to avoid interference.
Charging case not charging	<ul style="list-style-type: none">◦ Check the Type-C cable and power adapter for damage.◦ Try a different charging cable or power source.◦ Ensure the charging port on the case is clean and free of debris.

SPECIFICATIONS


Feature	Detail
Model Name	V1
Connectivity Technology	Wireless (Bluetooth 5.3)
Audio Driver Size	13mm Dynamic Driver
Battery Life (Earbuds)	Up to 6 hours (Music), 5 hours (Talk)
Total Playtime (with Case)	48+ Hours
Charging Port	Type-C
Water Resistance Level	IPX7 (Splash & Sweat Resistant)
Earpiece Shape	Semi-in-ear
Control Method	Touch Control, Voice Control
Frequency Range	20 Hz - 20,000 Hz
Noise Control	Sound Isolation (ENC for calls)
Earbud Weight	3.7g (one earbud)
Material	EVA Hard Shell (case)

Ultra light + Comfortable to Wear

Each earbud weighs only **3.7g**



3.7g Single Earbud



Ergonomic Design

Ultra lightweight design for a comfortable fit
No pain for long time wear

Image: The lightweight and ergonomic design of the EDYELL V1 earbuds, emphasizing comfort for extended wear.

HiFi Stereo Sound

13mm driver for immersive stereo music



Image: The 13mm drivers of the EDYELL V1 earbuds providing HiFi stereo sound for an immersive audio experience.



Image: An illustration detailing the benefits of Bluetooth 5.3 technology in the earbuds, including faster speed, more stable connection, and lower latency.




Image: Explanation of the Quad Mic with ENC (Environmental Noise Cancellation) technology for clear call quality.

