

[Manuals.plus](#) /

› [BingoPaw](#) /

› BingoPaw Dog Playpen Instruction Manual (Model P-XE172-XIN-US)

BingoPaw P-XE172-XIN-US

BingoPaw Dog Playpen Instruction Manual

Model: P-XE172-XIN-US

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your BingoPaw 8-Panel Metal Pet Playpen. This versatile enclosure is designed for use as a whelping box for puppies, a secure play area for pets, or a protective garden fence. It is suitable for small to medium-sized dogs, puppies, bunnies, chicks, ducks, and kittens, offering a safe and comfortable environment both indoors and outdoors.

2. SAFETY INSTRUCTIONS

- Always ensure all panels are securely connected and the gate latch is properly engaged to prevent pet escape.
- Do not leave pets unattended for extended periods, especially young puppies or animals prone to chewing.
- Regularly inspect the playpen for any damaged parts, sharp edges, or loose connections. Discontinue use if damage is found.
- Ensure the playpen is placed on a stable, level surface. When used outdoors, utilize the ground stakes for added stability.
- Keep children away from the playpen during assembly and disassembly.
- This product is designed for pets. Do not use it for purposes other than its intended use.
- The wire gap is 15mm to prevent pets from escaping or getting their feet stuck.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 8 x Metal Playpen Panels (each 24"W x 31.5"H)
- 1 x Instruction Manual (this document)
- 1 x Waterproof Fertility Pad
- Connecting Rods/Prongs (for assembly and outdoor staking)

Note: The waterproof fertility pad helps absorb leaks and protect floors.

4. SETUP AND ASSEMBLY

The BingoPaw playpen is designed for easy assembly without tools. Follow these steps:

4.1 Unpacking

Carefully remove all components from the packaging. Lay them out on a clean, flat surface to identify each part.

4.2 Panel Connection

1. Stand two panels upright, aligning their edges.
2. Insert a connecting rod through the loops on the adjacent edges of the two panels. Push the rod down until both panels are securely joined.
3. Repeat this process for all 8 panels, connecting them in your desired configuration (e.g., octagonal, square, L-shaped).
4. Ensure the panel with the gate is positioned for easy access.




Image: Various configurations possible with the 8 panels.

4.3 Securing the Playpen (Outdoor Use)

For outdoor use, the connecting rods also serve as ground stakes. Push the pointed end of the rods firmly into the ground to stabilize the playpen and prevent movement.



Image: Detail of the connecting rods (prongs) for ground insertion.

4.4 Installing the Waterproof Pad

If using as a whelping box or indoors, place the waterproof fertility pad inside the assembled playpen. The pad features a Velcro design for easy removal and cleaning.




Image: A mother dog and puppies inside the playpen with the waterproof pad.

4.5 Assembly Video Guide

Your browser does not support the video tag.

Video: Demonstrates the assembly process for the BingoPaw Multifunction Whelping Box Fence.

Your browser does not support the video tag.

Video: Shows the dual functionality and assembly of the Heavy Duty Dog Playpen as a whelping box.

5. OPERATING INSTRUCTIONS

5.1 Using the Gate

The playpen includes a panel with a safety latch for easy pet entry and exit. To open, lift the latch and swing the door open. To close, swing the door shut and ensure the latch securely engages.



Image: Detail of the safety door latch mechanism.

Your browser does not support the video tag.

Video: Demonstrates the use of the gate and general setup of the BingoPaw Dog Whelping Playpen.

5.2 Configuring Shapes

The 8 panels can be arranged into various shapes such as an octagon, square, or L-shape to fit your space and pet's needs. For larger areas, additional sets of panels can be purchased and connected.




Image: Dimensions and examples of various playpen shapes.

5.3 Indoor and Outdoor Use

This playpen is suitable for both indoor and outdoor environments. When used outdoors, ensure the ground stakes are firmly inserted into the soil for maximum stability. For indoor use, the waterproof pad helps protect flooring.



Image: Playpen set up indoors.



Image: Playpen used as an outdoor fence.

6. MAINTENANCE AND CARE

- **Cleaning the Panels:** Wipe metal panels with a damp cloth and mild soap. Rinse thoroughly and dry completely to prevent rust. Avoid abrasive cleaners.
- **Cleaning the Waterproof Pad:** The waterproof fertility pad can be easily removed for cleaning. Hand wash or machine wash on a gentle cycle with mild detergent. Air dry completely before re-inserting.
- **Storage:** When not in use, the playpen can be disassembled and folded flat for convenient storage and transport.
- **Regular Inspection:** Periodically check all connections, latches, and panel surfaces for wear, damage, or sharp edges. Address any issues promptly.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Playpen is unstable or wobbly.	Panels not fully connected; uneven surface; insufficient ground staking (outdoor).	Ensure all connecting rods are fully inserted. Place on a flat, level surface. For outdoor use, push ground stakes deeper into the soil.
Pet escapes or pushes through panels.	Gate not latched; panels not securely joined; pet is too large or strong for the enclosure.	Verify the gate latch is closed. Re-check all panel connections. Consider purchasing additional panels to create a larger, more secure space, or ensure the playpen size is appropriate for your pet.
Waterproof pad leaks or is damaged.	Pad is worn out; improper cleaning; excessive chewing.	Inspect the pad for tears. Replace if significantly damaged. Follow cleaning instructions carefully. Provide chew toys to redirect chewing behavior.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	P-XE172-XIN-US
Material	Iron Metal
Color	Black
Number of Panels	8
Individual Panel Dimensions (W x H)	24" x 31.5" (61cm x 80cm)
Overall Product Dimensions (L x W x H)	49.6" x 49.6" x 31.2" (126cm x 126cm x 88cm) <i>-for square configuration</i>
Wire Gap	15mm
Frame Thickness	13mm
Item Weight	40.65 Pounds
Assembly Required	Yes
Included Components	8 Metal Playpen Panels, 1 Instruction, 1 Waterproof Fertility Pad

9. WARRANTY AND SUPPORT

BingoPaw is committed to providing comfortable and durable necessities for pets. If you encounter any problems with your product, please contact BingoPaw customer support via email. We aim to resolve any issues within 24 hours. For further assistance or to explore other BingoPaw products, visit the official [BingoPaw Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question