

[Manuals.plus](#) /

› [Rowenta](#) /

› Rowenta Turbo Silence VU5650F0 Pedestal Fan User Manual

Rowenta VU5650F0

Rowenta Turbo Silence VU5650F0 Pedestal Fan User Manual

Model: VU5650F0 | Brand: Rowenta

PRODUCT OVERVIEW

The Rowenta Turbo Silence VU5650F0 Pedestal Fan is designed to provide powerful and quiet cooling for your living spaces. Featuring advanced Effitech motor technology, it offers significant energy savings while delivering intense airflow. With multiple speed settings, automatic oscillation, and convenient remote control, this fan ensures customized comfort and ease of use.



Image: Front view of the Rowenta Turbo Silence VU5650F0 Pedestal Fan, showcasing its white body, blue fan blades, and digital control panel.

SETUP AND ASSEMBLY

Before operating your Rowenta Turbo Silence fan, please follow these assembly instructions carefully. Assembly is designed to be straightforward.

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components listed in the packing list are present.
2. **Assemble the Base:** Attach the fan pole to the base. Ensure it is securely fastened.
3. **Attach the Motor Unit:** Mount the motor unit onto the top of the fan pole.
4. **Install Rear Grille:** Place the rear protective grille onto the motor unit, aligning it correctly.
5. **Mount Fan Blades:** Secure the fan blades onto the motor shaft.
6. **Install Front Grille:** Attach the front protective grille, ensuring it clips securely to the rear grille. Some users have noted that securing the grilles may require careful alignment or gentle pressure.
7. **Position the Fan:** Place the fan on a stable, flat surface, away from curtains or other objects that could obstruct airflow.
8. **Connect to Power:** Plug the power cord into a suitable electrical outlet.






Image: Diagram illustrating the dimensions of the Rowenta Turbo Silence VU5650F0 fan, showing a height of 144 cm, width of 60 cm, and depth of 50 cm.

OPERATING INSTRUCTIONS

Your Rowenta Turbo Silence fan offers a range of settings for optimal comfort.

Control Panel and Remote Control

The fan can be operated using the digital LED display on the unit or the compact remote control. The remote control provides full accessibility from a distance.

COMFORT DI UTILIZZO

telecomando compatto



Image: A hand holding the compact remote control for the Rowenta fan, with the fan visible in the background, demonstrating ease of use.

Modes and Speed Settings

- **Power On/Off:** Press the power button on the control panel or remote to turn the fan on or off.
- **Speed Adjustment:** Select from 12 adjustable speeds to achieve your desired airflow, ranging from a gentle breeze to a powerful air stream.
- **Silent Night Mode:** For quiet operation during sleep, activate the Silent Night mode. This mode ensures intense yet quiet cooling at only 35 dB(A). Note that a small LED light on the unit may remain illuminated in this mode.
- **Natural Breeze Mode:** Simulates a natural outdoor breeze with varying fan speeds.
- **Intelligent Mode:** Automatically adjusts fan speed based on ambient conditions.
- **Oscillation:** Activate automatic oscillation for wider air distribution across the room.
- **Timer Function:** Set the fan to operate for a specific duration using the timer function.



Image: Visual representation of the Rowenta fan generating powerful airflow, extending up to 7.2 meters across a room.

SILENZIO ASSOLUTO
a soli 35 dB(A)



Image: The Rowenta fan positioned in a bedroom, illustrating its quiet operation at 35 dB(A), suitable for undisturbed sleep.



Image: The Rowenta fan in a living room setting, depicting its ability to provide customized cooling with 12 different speed settings.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your fan.

- **Cleaning:** Always unplug the fan before cleaning. Use a soft, damp cloth to wipe down the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Grille Cleaning:** Periodically remove the front grille to clean the fan blades. Dust and debris can accumulate on the blades, reducing airflow efficiency.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging.

TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; power outlet malfunction; power button not pressed.	Ensure the fan is securely plugged into a working outlet. Press the power button firmly.
Weak airflow.	Fan blades are dirty; fan speed is too low; obstructions.	Clean the fan blades and grilles. Increase the fan speed. Remove any objects blocking the airflow.
Fan is noisy.	Loose parts; fan not on a stable surface; debris in blades.	Check for any loose components and tighten them. Place the fan on a flat, stable surface. Clean the fan blades.
LED light is too bright in Silent Night mode.	Design feature.	This is a known characteristic. If bothersome, consider placing a small, opaque cover over the LED.

SPECIFICATIONS

Feature	Detail
Brand	Rowenta
Model Number	VU5650F0
Dimensions (L x W x H)	50 x 60 x 144 cm
Item Weight	5.83 Kilograms
Power	32 Watts
Voltage	230 Volts
Material	Plastic, Metal
Number of Speeds	12
Noise Level	35 dB(A) (in Silent Night mode)
Special Features	12 speed levels, Oscillating, Silent, Compact remote control, Digital LED display
Recommended Use	Cooling
Power Source	Corded Electric
Energy Saving	55% energy saving with Effitech motor (compared to VU5640F2)

MOTORE EFFITECH

55%

RISPARMIO ENERGETICO
PER LE STESSA PRESTAZIONI

VENTILATORE 27,5W vs 55W per 50m³/min*

*Prestazioni del flusso d'aria misurate internamente, secondo lo standard EN/IEC 60879:2019 e calibrate su 50 m³ /min, rispetto alla versione VU5640F2

Image: Graphic illustrating the Effitech motor technology, highlighting a 55% energy saving for the same performance compared to previous models.

WARRANTY AND SUPPORT

Rowenta is committed to product durability and customer satisfaction.

- **Repairability:** Rowenta commits to keeping spare parts available for 15 years after purchase for the majority of its products, at a fair price.
- **Customer Service:** For further assistance, technical support, or warranty claims, please visit the official Rowenta website or contact their customer service department.



Image: Logo indicating Rowenta's commitment to 15 years of repairability at a fair price, featuring a screwdriver icon.

© 2025 Rowenta. All rights reserved.

For the latest information and updates, please visit www.rowenta.com