

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Olvy](#) /

› [Olvy Carpet and Upholstery Spot Cleaner B-PRO12 Instruction Manual](#)

Olvy B-PRO12

Olvy Carpet and Upholstery Spot Cleaner

MODEL: B-PRO12

Introduction

Thank you for choosing the Olvy Carpet and Upholstery Spot Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your device. Please read it thoroughly before first use and keep it for future reference.

This 3-in-1 cleaner is designed for effective spot cleaning, combining vacuuming, scrubbing, and spraying functions to tackle tough stains on various surfaces.



Image: The Olvy Spot Cleaner demonstrating its 3-in-1 functionality with a user interacting with the control panel.

Safety Information

- Always disconnect the appliance from the power supply before cleaning or maintenance.
- Do not immerse the appliance in water or other liquids.

- Keep hands, hair, and loose clothing away from moving parts.
- Do not use the appliance to pick up flammable or combustible liquids, or anything that is burning or smoking.
- Use only Olvy cleaning solutions or recommended alternatives.
- Ensure all tanks are properly secured before operation.
- Supervise children and individuals with reduced capabilities when near the appliance.

Package Contents

Verify that all items are present in the package:

- Olvy Spot Cleaner Main Unit
- Flexible Hose with Integrated Brush Head
- Clean Water Tank (2000 ml capacity)
- Dirty Water Tank (1400 ml capacity)
- Olvy Spot & Stain Remover (600ml bottle)
- Power Cord (5m length)



Image: The Olvy Spot Cleaner shown with the included cleaning solution and visible water tanks.

Product Features

- **Powerful Suction:** 15,000 Pa for effective liquid extraction.
- **Large Tank Capacity:** 2000 ml clean water tank and 1400 ml dirty water tank.
- **Versatile Cleaning:** Suitable for carpets, car upholstery, stairs, sofas, and other fabric surfaces.
- **Dual Cleaning Modes:** Normal and Turbo modes for varying cleaning needs.
- **Integrated Brush and Spray:** Brush head with automatic and even water distribution for deep cleaning.
- **Self-Cleaning Hose:** Designed to prevent residue buildup and maintain hygiene.

- **High Water Extraction:** Extracts up to 98% of applied water directly.



Image: Demonstrating the versatility of the Olvy Spot Cleaner on various surfaces.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Fill Clean Water Tank:** Remove the clean water tank. Fill it with warm water (max 40°C) up to the MAX line. Add 1/8 part of Olvy Spot & Stain Remover to the water. Securely reattach the tank to the main unit.
3. **Attach Hose:** Connect the flexible hose to the designated port on the main unit until it clicks into place.
4. **Position Unit:** Place the unit on a stable, flat surface near the area to be cleaned.
5. **Plug In:** Insert the power cord into a suitable electrical outlet.

ZELFREINIGENDE SLANG

De slang reinigt zichzelf, waardoor vuil niet blijft plakken. Dit zorgt ervoor dat je altijd met een schone lei begint.



Image: The Olvy Spot Cleaner with its hose and brush head stored, illustrating its compact design for easy storage.

Operating Instructions

- Pre-test:** Before cleaning, test the solution on an inconspicuous area of the fabric for colorfastness.
- Power On:** Press the power button on the main unit to turn on the cleaner.
- Select Mode:** Choose between Normal or Turbo mode depending on the severity of the stain. Turbo mode provides stronger suction.
- Spray and Scrub:** Hold the brush head over the stained area. Press the spray trigger on the handle to release cleaning solution. Gently scrub the stain with the brush head.
- Extract:** Release the spray trigger and continue to move the brush head over the wet area to vacuum up the dirty solution. The powerful suction will extract up to 98% of the water.
- Repeat:** Repeat the spray, scrub, and extract steps until the stain is removed and the extracted water appears clean.
- Empty Dirty Water Tank:** Monitor the dirty water tank. Empty it when it reaches the MAX fill line or after each cleaning session.

GROOTSTE OPSLAGCAPACITEIT

voor schoon en vies water op de hele markt.



Image: Detailed view of the brush head, illustrating its combined spray and scrub functionality.

Maintenance

- Empty and Clean Dirty Water Tank:** After each use, remove the dirty water tank, empty its contents, and rinse it thoroughly with clean water. Allow it to air dry before reattaching.
- Clean Clean Water Tank:** Rinse the clean water tank if any solution remains or before storing.
- Self-Cleaning Hose:** The hose features a self-cleaning function. After use, run clean water through the hose by spraying into a sink or bucket while the suction is active. This helps prevent blockages and odors.
- Clean Brush Head:** Remove any debris or hair from the brush head. Rinse it under running water.
- Wipe Down Unit:** Wipe the exterior of the main unit with a damp cloth.
- Storage:** Store the cleaner in a dry place. The hose and brush head can be neatly stored on the unit for compact storage.

Troubleshooting

Problem	Possible Cause	Solution
No spray from brush head	Clean water tank empty; spray nozzle clogged; pump malfunction.	Refill clean water tank; clean spray nozzle with a small brush; contact customer support if pump issue persists.
Low suction power	Dirty water tank full; hose/nozzle clogged; tank not properly sealed.	Empty dirty water tank; clear any blockages in hose/nozzle; ensure tanks are securely attached.
Water leaking from unit	Tanks not properly seated; seals damaged; unit damaged.	Ensure both clean and dirty water tanks are correctly and firmly seated; check seals for damage and replace if necessary; if damage to unit, contact customer support.

Problem	Possible Cause	Solution
Unit does not turn on	No power; power cord damaged; internal fault.	Check power outlet; inspect power cord for damage; contact customer support.

Specifications

- Brand:** Olvy
- Model Number:** B-PRO12
- Color:** Black
- Power Source:** Corded Electric
- Suction Power:** 15,000 Pa
- Clean Water Tank Capacity:** 2000 ml
- Dirty Water Tank Capacity:** 1400 ml
- Cord Length:** 5 meters
- Hose Length:** 1.5 meters
- Date First Available:** January 11, 2024

Warranty and Support

For warranty information, product support, or to purchase replacement parts, please refer to the official Olvy website or contact Olvy customer service directly. Contact details can typically be found on the product packaging or the brand's official online presence.