Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- BaByliss /
- BaByliss T996E Super-X Metal Beard Trimmer User Manual

BaByliss T996E

BaByliss T996E Super-X Metal Beard Trimmer User Manual

Model: T996E

IMPORTANT SAFETY WARNINGS

WARNING: Do not use this appliance on children. Keep it away from water. Always follow the cleaning and maintenance instructions provided in this manual to ensure safe operation and product longevity.

PRODUCT OVERVIEW

The BaByliss T996E Super-X Metal Beard Trimmer is designed for precise and effortless beard trimming. It features a powerful High Torque motor and advanced Japanese steel blades for optimal cutting performance on all beard types.



Image: The BaByliss T996E trimmer shown on its USB charging stand, accompanied by two adjustable guide combs.

Key Features:

- Lithium-ion Battery: Provides exceptional cordless performance with up to 180 minutes of runtime.
- Quick Charge System: A full 3-hour charge provides 5 hours of cordless use. A 20-minute quick charge offers 40 minutes of use.
- Robust Metallic Design: Ensures durability and a premium feel.
- Japanese Steel T-Blade: Ultra-sharp for precise 0.2mm finishing, ideal for contours and details.
- Adjustable Guide Combs: Two combs for short beards (1-6mm) and longer beards (7-12mm).
- 100% Waterproof: Suitable for wet or dry use and easy cleaning.
- USB Charging Stand: Convenient charging and storage.

1. Initial Charging

Before first use, fully charge the trimmer for 3 hours. The digital indicator will show the battery level. Place the trimmer on the USB charging stand or connect the USB cable directly to the trimmer.



Image: The trimmer securely placed on its charging stand, with the battery indicator illuminated.

2. Attaching Guide Combs

The trimmer comes with two adjustable guide combs:

- One comb for lengths 1-6mm.
- One comb for lengths 7-12mm.

To attach a comb, align it with the trimmer head and push gently until it clicks into place. To remove, pull the comb away from the trimmer head.







Image: The two adjustable guide combs, one set for 1-6mm and the other for 7-12mm, displayed separately.

OPERATING INSTRUCTIONS

1. Powering On/Off

Press the power button located on the trimmer handle to turn the appliance on or off.

2. Adjusting Cutting Length

With a guide comb attached, use the integrated dial on the comb to select your desired cutting length. Ensure the comb is securely locked at the chosen setting before trimming.




Image: Trimmer with the 1-6mm guide comb, suitable for shorter beard styles.



Image: Trimmer with the 7-12mm guide comb, ideal for maintaining longer beard lengths.

3. Trimming Technique

For best results, ensure your beard is clean and dry. Trim against the direction of hair growth, using smooth, even strokes. For detailing and outlining, remove the guide comb and use the bare blade.

MAINTENANCE

1. Cleaning the Trimmer

The BaByliss T996E is 100% waterproof, allowing for easy cleaning. After each use, turn off the trimmer and rinse the blade head and guide combs under running water. For a more thorough clean, you can detach the blade head (refer to specific instructions in the full manual if available) and rinse it separately. Ensure all parts are dry before reassembling or storing.



Image: The trimmer being held under a stream of water, illustrating its waterproof design for easy cleaning.

2. Blade Care

Regularly oil the blades to maintain their sharpness and performance. Apply a small drop of lubricating oil (typically included with the product) to the blades after cleaning and before storage. Run the trimmer for a few seconds to distribute the oil.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--------------------------------------|--|--|
| Trimmer does not turn on. | Battery is depleted. | Charge the trimmer fully for 3 hours. |
| Trimmer pulls hair or cuts unevenly. | Blades are dull or clogged with hair. Guide comb is not securely attached or is damaged. | Clean and oil the blades. Ensure the guide comb is correctly attached and undamaged. Consider replacing blades if dullness persists. |

| Problem | Possible Cause | Solution |
|---------------------------------------|--|---|
| Guide comb detaches during use. | Comb not properly secured or damaged. | Ensure the comb clicks firmly into place. Inspect the comb for any damage and replace if necessary. |
| Reduced motor speed or power. | Low battery or excessive hair buildup. | Recharge the trimmer. Clean the blades and motor area thoroughly. |

SPECIFICATIONS

| Feature | Detail |
|--------------------------------|--|
| Model Number | T996E |
| Brand | BaByliss |
| Power Source | Battery Powered (Lithium-ion) |
| Battery Life | Up to 180 minutes cordless runtime |
| Charge Time | 3 hours for full charge, 20 minutes for quick charge |
| Blade Material | Japanese Steel / Alloy Steel |
| Minimum Cutting Length | 0.2 mm (without comb) |
| Adjustable Comb Lengths | 1-6 mm, 7-12 mm |
| Special Feature | Waterproof |
| Product Dimensions (L x W x H) | 3.8 x 3.5 x 18 cm (1.5 x 1.4 x 7.1 inches) |
| Item Weight | 264 Grams (0.58 lbs) |
| Country of Origin | China |

WARRANTY AND SUPPORT

The BaByliss T996E Super-X Metal Beard Trimmer comes with a **3-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty service, please contact BaByliss Customer Service through their official website or the retailer where the product was purchased. Refer to the packaging for specific contact details in your region.