

PIC PIC-GO

PIC Portable Mosquito Botanical Repellent

Model: PIC-GO
60 Hour Cartridge Included

INTRODUCTION

The PIC Portable Mosquito Botanical Repellent is a cordless device designed to create a 15-foot zone of protection against mosquitoes. It utilizes a blend of natural essential oils, including Clove, Geraniol, Lemongrass, and Citronella, to deter mosquitoes. This device is suitable for outdoor activities and provides long-lasting protection.

This manual provides instructions for the proper setup, operation, maintenance, and troubleshooting of your PIC Portable Mosquito Botanical Repellent.

SAFETY INFORMATION

- **Read all instructions:** Before using the device, carefully read and understand all instructions provided in this manual.
- **Use as directed:** This device is safe for use around children and pets *when used as directed*. Do not allow children or pets to handle the device or cartridges.
- **Ventilation:** Use in well-ventilated outdoor areas. Avoid using in enclosed spaces.
- **Cartridge handling:** Avoid direct contact with the repellent liquid. Wash hands thoroughly after handling cartridges.
- **Storage:** Store the device and cartridges in a cool, dry place, away from direct sunlight and out of reach of children and pets.
- **Disposal:** Dispose of used cartridges and the device according to local regulations.

PRODUCT OVERVIEW

Components

- 1 x Rechargeable Vaporizer Unit
- 1 x 60 Hour Repellent Cartridge
- 1 x USB-C Charging Cord

Key Features

- **Portable & Cordless:** Designed for easy transport and use without power outlets.
- **15-Foot Protection Zone:** Creates a wide area of mosquito deterrence.
- **Botanical Formulation:** Contains Clove, Geraniol, Lemongrass, and Citronella oils.
- **Fast Acting:** Provides protection within 10 minutes of activation.
- **Long-Lasting Charge:** Up to 4.5 hours of use on a single charge.
- **60-Hour Cartridge:** Each repellent cartridge provides up to 60 hours of use.



Figure 1: The PIC Portable Mosquito Repellent device highlighting its key features and components.

SETUP

1. Charge the Device

1. Connect the provided USB-C charging cord to the charging port on the device.
2. Plug the other end of the USB-C cord into a compatible USB power source (e.g., wall adapter, power bank, computer USB port).
3. The LED indicator light will illuminate during charging. Allow approximately 3 hours for a full charge.
4. A full charge provides up to 4.5 hours of continuous use.

2. Install the Repellent Cartridge

1. Ensure the device is turned off.
2. Locate the cartridge slot at the bottom of the device.
3. Remove the cap from the repellent cartridge.
4. Insert the cartridge into the slot and twist it clockwise until it is securely in place.



Figure 2: The portable device with its carabiner clip, ready for attachment to bags or gear.

OPERATING INSTRUCTIONS

1. Power On/Off

- To turn on the device, press and hold the power button for a few seconds until the blue LED indicator light illuminates.
- To turn off the device, press and hold the power button again until the LED indicator light turns off.

2. Placement for Optimal Coverage

- For best results, activate the device approximately 10 minutes before entering the area you wish to protect.
- Place the device on a flat surface or hang it using the integrated carabiner clip in the center of your desired 15-foot protection zone.
- Ensure there are no obstructions blocking the vapor dispersion from the top vents of the device.
- Avoid placing the device directly in strong winds, as this may reduce the effectiveness of the repellent zone.



Figure 3: Visual representation of the 15-foot mosquito protection zone provided by the device.



Figure 4: The device in an outdoor environment, demonstrating typical placement for use.

MAINTENANCE

Cartridge Replacement

- Each repellent cartridge provides up to 60 hours of mosquito deterrence.
- When the cartridge is empty or its effectiveness diminishes, replace it with a new PIC 60 Hour Repellent Refill.
- To replace, turn off the device, twist the old cartridge counter-clockwise to remove, and insert a new cartridge by twisting clockwise until secure.

Cleaning

- Ensure the device is turned off and unplugged before cleaning.
- Wipe the exterior of the device with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Do not submerge the device in water or any other liquid.

GET OUT, THEN GET IN THE 15FT ZONE



Figure 5: The device shown with its packaging, illustrating the availability of 60-hour refill cartridges.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not turning on	Low battery or no charge	Charge the device using the USB-C cord. Ensure the LED indicator lights up during charging.
Repellent not effective	Empty or expired cartridge; improper placement; strong wind conditions	Replace the repellent cartridge. Ensure the device is placed centrally in the desired area, away from strong winds. Allow 10 minutes for the zone to establish.
Device making unusual noise	Internal fan obstruction or malfunction	Turn off the device and check for any visible obstructions in the vents. If the issue persists, contact customer support.

SPECIFICATIONS

- **Brand:** PIC
- **Model Number:** PIC-GO
- **Scent:** Citronella, Lemongrass
- **Item Volume:** 0.1 Fluid Ounces (per cartridge)
- **Material Feature:** Natural
- **Item Form:** Vaporizer
- **Number of Items:** 1 (device + 1 cartridge)

- **Unit Count:** 1 Count (Pack of 1)
- **Target Species:** Mosquito
- **Item Weight:** 0.19 Kilograms

WARRANTY AND SUPPORT

For warranty information, product registration, or customer support, please refer to the manufacturer's official website or contact their customer service department directly. Keep your purchase receipt for warranty claims.

© 2024 PIC. All rights reserved.