

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LIVOO](#) /
- › [Livoo DOD200N Electric Coffee Maker User Manual](#)

LIVOO DOD200N

Livoo DOD200N Electric Coffee Maker

User Instruction Manual

INTRODUCTION

Thank you for purchasing the Livoo DOD200N Electric Coffee Maker. This appliance is designed to brew delicious coffee efficiently. Please read this instruction manual carefully before using the appliance to ensure safe operation and optimal performance. Keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the coffee maker.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycle.

- The appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Livoo DOD200N coffee maker.



Image 1: Front view of the Livoo DOD200N Electric Coffee Maker, showing the water reservoir, filter basket area, glass carafe, and control button.

1. Lid
2. Water Reservoir with Level Indicator
3. Filter Basket Holder
4. Removable Reusable Filter
5. Glass Carafe with Handle
6. Warming Plate
7. Power Switch / Indicator Light

8. Power Cord



Image 2: Close-up of the glass carafe with handle, designed for serving and keeping coffee warm.



Image 3: The removable reusable filter and its holder, which simplifies cleaning and eliminates the need for disposable filters.

SETUP

Before first use, follow these steps:

1. Unpack the coffee maker and remove all packaging materials.
2. Wipe the exterior of the coffee maker with a damp cloth.
3. Wash the glass carafe, lid, and reusable filter in warm, soapy water. Rinse thoroughly and dry.
4. Place the coffee maker on a flat, stable, heat-resistant surface.

5. For the first use, it is recommended to run two full cycles with only water to clean the internal components. Fill the water reservoir to the MAX level, place the empty filter in the filter basket, and run a brew cycle. Discard the water and repeat once more.

OPERATING INSTRUCTIONS

Follow these steps to brew coffee:

1. **Fill Water Reservoir:** Open the lid and fill the water reservoir with fresh, cold water. Use the water level indicator on the side of the coffee maker to measure the desired amount of cups (1.25L capacity for up to 12 cups). Do not exceed the MAX fill line.
2. **Add Coffee Grounds:** Place the reusable filter into the filter basket holder. Add the desired amount of ground coffee into the filter. A general guideline is one tablespoon of ground coffee per cup, but adjust to your taste.
3. **Position Carafe:** Ensure the glass carafe with its lid is correctly placed on the warming plate. The anti-drip mechanism will not function if the carafe is not properly seated.
4. **Start Brewing:** Close the lid securely. Plug the power cord into a suitable electrical outlet. Press the Power Switch. The indicator light will illuminate, indicating that the brewing cycle has started.
5. **Serving:** Once the brewing cycle is complete, the coffee maker will automatically switch to the "keep warm" function. The indicator light will remain on. You can remove the carafe to pour coffee. The anti-drip feature will temporarily stop coffee flow.
6. **Keep Warm Function:** The warming plate will keep the coffee hot for a period after brewing. The appliance features an automatic shut-off for safety and energy saving.
7. **Turn Off:** To turn off the coffee maker manually, press the Power Switch again. Unplug the appliance from the wall outlet when not in use.

Note: For best results, use fresh, cold water and quality ground coffee. Do not open the lid during the brewing process as hot steam may escape.

CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

Daily Cleaning:

1. Always unplug the coffee maker and allow it to cool completely before cleaning.
2. Remove the glass carafe, its lid, and the reusable filter. Wash these parts in warm, soapy water. The filter holder with handle is dishwasher-safe. Rinse thoroughly and dry.
3. Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
4. Do not immerse the main unit, cord, or plug in water or any other liquid.

Descaling (Every 2-4 months, depending on water hardness):

Mineral deposits from water can build up in your coffee maker, affecting its performance. Descale regularly:

1. Fill the water reservoir with a mixture of white vinegar and water (1 part vinegar to 2 parts water).
2. Place the empty reusable filter in the filter basket and the empty carafe on the warming plate.
3. Run a brewing cycle. After about half the mixture has brewed through, turn off the coffee maker and let it sit for 15-20 minutes to allow the descaling solution to work.
4. Turn the coffee maker back on and let the remaining mixture brew through.

5. Discard the vinegar solution. Run 2-3 cycles with fresh, clean water to rinse out any residual vinegar taste.

TROUBLESHOOTING

If you encounter issues with your coffee maker, refer to the following table:

Problem	Possible Cause	Solution
Coffee does not brew.	Coffee maker not plugged in; Power switch not turned on; Water reservoir empty.	Ensure the appliance is plugged in; Press the Power Switch; Fill the water reservoir.
Coffee tastes weak.	Not enough coffee grounds; Coffee grounds too coarse; Water-to-coffee ratio incorrect.	Add more coffee grounds; Use finer ground coffee; Adjust ratio to taste.
Coffee overflows from filter basket.	Too much coffee grounds; Filter clogged; Carafe not properly seated.	Reduce coffee grounds; Clean the reusable filter; Ensure carafe is correctly positioned on the warming plate.
Brewing is slow.	Mineral deposits (scale) built up in the system.	Perform a descaling cycle as described in the "Cleaning and Maintenance" section.
Coffee is not hot enough.	Warming plate not functioning; Appliance needs descaling.	Ensure the warming plate is on; Descal the coffee maker.

SPECIFICATIONS

Feature	Detail
Brand	LIVOO
Model Number	DOD200N (Also referred to as DOD200W in some specifications)
Color	White
Capacity	1.25 Liters (approx. 10-12 cups)
Power	750 W
Voltage	220 Volts (AC)
Product Dimensions (L x W x H)	19.1 x 23.8 x 30.9 cm
Product Weight	1.3 kg
Special Features	Removable reusable filter, Keep warm function, Automatic shut-off
Material	Glass, Stainless Steel
Coffee Maker Type	Drip Coffee Maker

WARRANTY AND SUPPORT

Livoo products are manufactured with quality in mind. For warranty information, please refer to the warranty card

included with your purchase or visit the official Livoo website. If you have any questions or require technical support, please contact Livoo customer service through their official channels.

Website: www.livoo.fr (Example, actual website may vary)

Email: support@livoo.fr (Example, actual email may vary)