

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [Outsunny](#) /

> Outsunny Wooden Garden Shed Instruction Manual

Outsunny 84H-060V00ND

Outsunny Wooden Garden Shed Instruction Manual

Model: 84H-060V00ND

Brand: Outsunny

INTRODUCTION

Thank you for purchasing the Outsunny Wooden Garden Shed. This outdoor storage cabinet is designed to provide a practical and secure solution for organizing your garden tools, toys, and other outdoor essentials. Featuring a durable fir wood construction, a waterproof galvanized metal roof, and internal shelving, this shed offers reliable storage while complementing your outdoor space. Please read this manual carefully before assembly and use to ensure proper installation and safe operation.

SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the product:

- Always assemble the shed on a flat, stable, and level surface.
- Ensure all parts are present and undamaged before beginning assembly. Do not attempt to assemble if parts are missing or broken.
- Assembly requires two people. Attempting to assemble alone may result in injury or damage.
- Wear appropriate safety gear, such as gloves, during assembly.
- Securely fasten the shed to the ground using the included expansion screws to prevent tipping, especially in windy conditions.
- Do not overload the shelves. Each shelf has a maximum load capacity of 55 lbs. The floor has a maximum load capacity of 88 lbs.
- Keep children and pets away from the assembly area.
- Regularly inspect the shed for any signs of wear, damage, or loose fasteners. Address any issues promptly.
- Do not climb on or lean against the shed.

PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

Item	Description	Quantity
Wooden Panels	Side, back, door, and roof panels	Various
Galvanized Metal Roof	Waterproof roof section	1
Shelves	Internal storage shelves	3
Hardware Kit	Screws, hinges, handles, latch, expansion screws	1 Set
Instruction Manual	This document	1

SETUP AND ASSEMBLY

Assembly requires two people. Please follow these steps carefully:

- 1. Prepare the Area:** Choose a flat, level, and stable outdoor location for the shed. Ensure there is enough space around the assembly area.
- 2. Unpack and Identify Parts:** Carefully unpack all components and lay them out. Refer to the parts list to identify each piece.
- 3. Assemble the Base:** Connect the base frame components according to the diagrams in your separate assembly guide (not included in this manual).
- 4. Attach Side and Back Panels:** Securely attach the side and back wooden panels to the assembled base. Ensure they are aligned correctly.
- 5. Install Shelves:** Insert the three internal shelves into the designated slots or attach them using the provided hardware.



Image: The shed with its doors open, revealing three internal shelves for organized storage of various items like garden tools, ropes, and potted plants.

6. **Attach the Roof:** Place the galvanized metal roof onto the top of the shed, ensuring the slanted side faces the back to allow for water runoff. Secure it with the appropriate screws.

GALVANISED METAL ROOF

Waterproof



Scratch Resistant



Anti-Corrosion




Image: A close-up view of the shed's galvanized metal roof, highlighting its waterproof, scratch-resistant, and anti-corrosion properties, designed to protect contents from the elements.

- 7. Install Doors, Handles, and Latch:** Attach the wooden doors to the front of the shed using the provided hinges. Install the handles and the latch mechanism.



Handles make opening and closing convenient

A latch keeps all your garden tools safe

Image: Detail of the shed's doors, showing the black handles for convenient opening and closing, and the secure latch mechanism designed to keep stored items safe.

8. **Secure to Ground:** Use the included expansion screws to firmly mount the shed to the ground or an existing structure. This provides additional stability and prevents tipping.

STABLE STANDING

With expansion screws to connect the shed to the ground firmly



Image: A close-up showing the expansion screws used to firmly connect the shed to the ground, ensuring stable standing and preventing movement.

OPERATING INSTRUCTIONS

The Outsunny Garden Shed is designed for straightforward use:

- **Opening and Closing:** Use the integrated handles to open and close the double doors. Ensure the latch is fully engaged when closing to secure the contents.
- **Storage:** Utilize the three internal shelves to organize various items such as garden tools, small equipment, potting supplies, or outdoor toys. Distribute weight evenly across the shelves and floor.
- **Security:** The built-in latch provides basic security. For enhanced security, a padlock (not included) can be added to the latch mechanism to prevent unauthorized access.



Image: The Outsunny wooden garden shed with its doors open, showcasing the spacious interior with three shelves, ideal for organizing garden tools, toys, and other outdoor supplies.

MAINTENANCE

To ensure the longevity and optimal performance of your Outsunny Garden Shed, follow these maintenance guidelines:

- **Regular Cleaning:** Clean the exterior of the shed periodically with a damp cloth to remove dirt, dust, and debris. Avoid harsh chemicals that may damage the wood finish.
- **Wood Treatment:** As the shed is made of fir wood, consider applying a wood sealant or stain annually to protect it from weathering and prolong its life, especially in harsh climates.
- **Roof Inspection:** Periodically check the galvanized metal roof for any signs of damage, corrosion, or loose fasteners. Ensure it remains waterproof.
- **Hardware Check:** Inspect all screws, hinges, and the latch regularly. Tighten any loose fasteners to maintain structural integrity and door functionality.
- **Drainage:** Ensure the area around the shed has proper drainage to prevent water accumulation at the base, which could lead to wood rot.

TROUBLESHOOTING

Here are some common issues and their potential solutions:

Problem	Possible Cause	Solution
Doors do not close properly or are misaligned.	Uneven ground; loose hinges; warped wood.	Ensure the shed is on level ground. Tighten hinge screws. If wood is warped, consider applying a wood conditioner or contacting support.
Shed feels unstable or wobbly.	Not properly secured to the ground; loose frame connections.	Verify the shed is securely anchored with expansion screws. Check and tighten all frame connection screws.
Water leakage inside the shed.	Damaged roof; improper roof installation; gaps in panels.	Inspect the galvanized roof for damage and ensure it is properly sealed and installed. Check for any gaps between panels and seal if necessary.
Wood splitting during assembly.	Over-tightening screws; pre-drilled holes not used.	Always use pre-drilled holes. Do not over-tighten screws. If minor splitting occurs, wood glue can be used. For significant damage, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Outsunny
Model Number	84H-060V00ND
Color	Natural Wood
Material	Fir wood, Galvanized metal
Overall Dimensions	31.5" W x 15.75" D x 62.25" / 63" H
Door Size	13.5" W x 56" H
Item Weight	52.8 Pounds
Max Load (Per Shelf)	55 lbs
Max Load (Floor)	88 lbs
Assembly Required	Yes (2 people recommended)
Water Resistance	Water Resistant (Galvanized Metal Roof)
UV Protection	Yes



Image: A detailed diagram illustrating the overall dimensions of the Outsunny wooden garden shed, including width, depth, and height, as well as internal shelf and door measurements.

WARRANTY AND SUPPORT

Outsunny products are manufactured by Aosom LLC. For any questions, concerns, or to report missing/damaged parts, please contact Aosom LLC customer support.

- **Returns:** This product is eligible for 30-day easy returns. Please refer to your purchase platform's return policy for detailed instructions.
- **Customer Support:** For assistance, please visit the Aosom LLC website or contact their customer service department directly. Contact information can typically be found on your purchase receipt or the Aosom LLC official website.