Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl 1

onerbl 14V AC/DC Adapter User Manual

For IRIS USA IC-H50, IC-H50-B, ICH50, IC-H50B Handheld Vacuum Cleaners

1. Introduction

This manual provides essential instructions for the safe and effective use of your onerbl 14V AC/DC Adapter. Please read this manual thoroughly before using the product and retain it for future reference.

2. Product Overview

The onerbl 14V AC/DC Adapter is a high-quality replacement power supply designed for specific handheld vacuum cleaner models. It features robust construction and multiple safety protections.

2.1 Key Features

- **Input:** AC 100-240V 50/60Hz (Worldwide AC Input)
- **Output:** DC 14V 1.0A
- Designed for compatibility with IRIS USA IC-H50, IC-H50-B, ICH50, IC-H50B handheld vacuum cleaners.
- Equipped with a smart chip for enhanced electricity safety.
- Multiple protection features: Over Voltage Protection, Over Heat Protection, Short-Circuit Protection, Over-Current Protection.
- Durable design with quality control measures, including copper wire and PVC jacket.
- Extended cord design for flexible placement.

2.2 Product Components



Image 1: Front and side view of the onerbl 14V AC/DC adapter. The front shows the input specifications and regulatory marks, while the side highlights the ribbed texture for grip and heat dissipation.




Image 2: This image illustrates the physical dimensions of the adapter, showing a length of 2.6 inches, width of 1.6 inches, and height of 1.2 inches. It also indicates a cable length of 76 inches.




Image 3: A diagram highlighting the internal construction of the adapter cable, showing the copper wire conductors and the protective PVC jacket, emphasizing the durable design.

3. Setup

1. **Verify Compatibility:** Ensure your device requires a 14V DC input and has a compatible charging port. This adapter is specifically designed for IRIS USA IC-H50, IC-H50-B, ICH50, IC-H50B handheld vacuum cleaners.
2. **Connect to Device:** Insert the DC output plug of the adapter firmly into the charging port of your handheld vacuum cleaner.
3. **Connect to Power Outlet:** Plug the AC input prongs of the adapter into a standard AC 100-240V wall outlet.
4. **Confirm Connection:** Once connected, your device should indicate that it is receiving power or charging, typically via an indicator light.



Image 4: The onerbl AC/DC adapter shown plugged into a power strip, illustrating a typical setup for charging a device. The compact design allows it to fit alongside other plugs.

4. Operating Instructions

The onerbl 14V AC/DC Adapter operates automatically once connected. It provides a stable 14V DC power output to your compatible device.

- Ensure the adapter is securely plugged into both the wall outlet and your device.
- The adapter is designed for continuous use within its specified voltage and current limits.
- Disconnect the adapter from the wall outlet when not in use for extended periods.

5. Maintenance

- **Cleaning:** Disconnect the adapter from power before cleaning. Use a dry, soft cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use. Avoid wrapping the cable too tightly.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as cuts, frayed wires, or bent prongs. If damage is found, discontinue use immediately.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device not charging/powering on.	• Adapter not properly connected. • Wall outlet not functioning. • Device compatibility issue. • Damaged adapter or cable.	• Ensure all connections are secure. • Test the wall outlet with another device. • Confirm the adapter is compatible with your device's voltage and connector type. • Inspect the adapter and cable for damage. If damaged, replace the adapter.
Adapter feels excessively hot.	• Overload or faulty device. • Poor ventilation.	• Disconnect immediately. Allow to cool. Ensure the device is not drawing excessive power. • Ensure the adapter is in a well-ventilated area. • If overheating persists, discontinue use and contact support.

7. Specifications

- **Brand:** onerbl
- **Model Number:** 1
- **Input Voltage:** AC 100-240V, 50/60Hz
- **Output Voltage:** DC 14V
- **Output Current:** 1.0A
- **Compatibility:** IRIS USA IC-H50, IC-H50-B, ICH50, IC-H50B Handheld Vacuum Cleaners
- **Cable Length:** Approximately 76 inches (6.3 feet)
- **Protection Features:** Over Voltage Protection, Over Heat Protection, Short-Circuit Protection, Over-Current Protection



Image 5: This graphic highlights the "SMART CHIP" and "Multiple Protection" features of the adapter, including icons for short-circuit protection, over-voltage protection, and over-current protection, ensuring electricity safety.

8. Safety Information

- Do not expose the adapter to water, rain, or excessive moisture.
- Do not disassemble or modify the adapter.
- Avoid dropping or subjecting the adapter to strong impacts.
- Keep out of reach of children.
- Ensure proper ventilation around the adapter during use to prevent overheating.

- Use only with compatible devices as specified.
- If the adapter emits smoke, unusual odors, or makes strange noises, unplug it immediately and discontinue use.

9. Warranty and Support

This onerbl product is designed for reliability and performance. For any issues or inquiries, please contact your retailer or the manufacturer's customer support. Please refer to your purchase documentation for specific warranty terms and conditions.

Manufacturer: Shenzhen Waweis Technology Co., Ltd

© 2023 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CS654XWJ

More documents and user manuals: **https://manuals.plus/**