Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl 24V AC/DC Adapter

onerbl 24V AC/DC Power Adapter Instruction Manual

For SUNSMAI SWLR0001 Smart Window Vacuum Cleaner Robot

Introduction

This manual provides essential instructions for the safe and effective use of your onerbl 24V AC/DC Power Adapter. This adapter is designed to provide power to compatible devices, specifically the SUNSMAI SWLR0001 Smart Window Vacuum Cleaner Robot. Please read this manual thoroughly before use and retain it for future reference.

Important Safety Instructions

- Ensure the power adapter is used with devices that match its voltage and wattage specifications (Input: AC 100-240V, 50/60Hz; Output: DC 24V, 80W).
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or modify the adapter. Refer all servicing to qualified personnel.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.
- This adapter features over voltage protection and over heat protection for safe operation.

Package Contents

Verify that all items are present in the package:

- onerbl 24V AC/DC Power Adapter
- AC Power Cord (2-pin)



Image Description: A black onerbl 24V AC/DC power adapter with its attached DC output cable, alongside a separate black AC power cord with a two-prong plug on one end and a two-hole connector on the other. The adapter has a small blue indicator light.

Setup Instructions

1. **Connect the AC Power Cord:** Insert the 2-pin connector of the AC power cord firmly into the corresponding port on the onerbl 24V AC/DC Power Adapter.
2. **Connect to Device:** Plug the DC output connector of the power adapter into the power input port of your SUNSMAI SWLR0001 Smart Window Vacuum Cleaner Robot. Ensure a secure connection.
3. **Connect to Power Outlet:** Insert the AC plug of the power cord into a standard wall power outlet (AC 100-240V, 50/60Hz).
4. **Verify Power:** The blue indicator light on the power adapter should illuminate, indicating that power is being supplied.



Image Description: The onerbl 24V AC/DC power adapter is shown plugged into a wall outlet, with its output cable connected to a device (likely the vacuum cleaner robot, though not fully visible) on a wooden table. A small blue light on the adapter is illuminated.

Operating Instructions

The onerbl 24V AC/DC Power Adapter functions as a power supply for your compatible device. Once properly connected and plugged into a power source, it will deliver the necessary power. Refer to your device's instruction manual for specific operating procedures.

- Ensure the adapter is always connected to a stable power source.
- Do not overload the adapter by connecting it to devices requiring more than 80W.
- The adapter is designed for continuous use within its specified parameters.

Care and Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to

wipe the surface of the adapter. Do not use liquid cleaners or abrasive materials.

- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly coiling the cables to prevent damage.
- **Inspection:** Periodically inspect the adapter and cables for any signs of damage, such as frayed wires or cracked casing. If damage is observed, discontinue use and replace the adapter.

Troubleshooting

Problem	Possible Cause	Solution
Adapter not supplying power (no indicator light).	No power from wall outlet. Loose connection. Damaged adapter or cable.	Test the wall outlet with another device. Ensure all connections (AC cord to adapter, adapter to device, AC plug to outlet) are secure. Inspect for visible damage. If damaged, replace the adapter.
Device not charging/powering on.	Incorrect adapter for the device. Device issue.	Verify the adapter specifications match your device's requirements (24V, 80W). Consult your device's manual for troubleshooting.
Adapter feels excessively hot.	Overload. Poor ventilation.	Ensure the connected device does not exceed 80W. Place the adapter in a well-ventilated area, away from heat sources. If overheating persists, discontinue use and replace.

Specifications

Brand	onerbl
Model	24V AC/DC Adapter
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	DC 24V
Wattage	80W
Compatible Devices	SUNSMAI SWLR0001 Smart Window Vacuum Cleaner Robot
Special Feature	Over Voltage Protection, Over Heat Protection, Travel-friendly
Cable Length	Approximately 127.8 inches (324.6 cm) total (AC cord: 79.3 inches, DC cord: 44.3 inches)




Image Description: A diagram illustrating the dimensions of the power adapter and its cables. The adapter measures 4.2 inches in length. The DC output cable is 44.3 inches long, and the AC input cable is 79.3 inches long, totaling 127.8 inches.

Warranty and Support

For warranty information or technical support, please refer to the seller's policy or contact the manufacturer directly. Details are typically available on the product packaging or the point of purchase.
Manufacturer: Shenzhen Waweis Technology Co., Ltd

© 2024 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CS679Y37

More documents and user manuals: **https://manuals.plus/**