

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [onerbl](#) /

› [onerbl AC/DC Adapter User Manual](#)

onerbl AC/DC Adapter for Vistefly S7/V15 Max/V15Max

onerbl AC/DC Adapter User Manual

Model: AC/DC Adapter for Vistefly S7/V15 Max/V15Max

1. INTRODUCTION

Thank you for choosing the onerbl AC/DC Adapter. This adapter is designed to provide reliable power for compatible devices, specifically the Vistefly Model S7, V15 Max, and V15Max cordless stick vacuum cleaners. This manual provides essential information for safe and effective use, including setup, operation, maintenance, and troubleshooting.



Image 1.1: The onerbl AC/DC Adapter, showing the main unit with the US plug and the DC output connector.

2. SAFETY INFORMATION

Please read all safety instructions carefully before using the adapter. Failure to follow these instructions may result in electric shock, fire, or damage to the product or connected devices.

- **Indoor Use Only:** This adapter is designed for indoor use in dry locations. Do not expose it to rain, moisture, or extreme temperatures.
- **Proper Voltage:** Ensure the input voltage of the adapter (AC 100-240V) matches the power outlet's voltage.
- **Overload Protection:** Do not overload the adapter. Connect only devices that are within the adapter's specified output ratings.
- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it or place it in an enclosed space.
- **Damage Inspection:** Before each use, inspect the adapter and its cable for any signs of damage. Do not use if damaged.
- **Disconnecting Power:** Always unplug the adapter from the power outlet before cleaning or if it will not be used for an extended period.
- **Children and Pets:** Keep the adapter out of reach of children and pets.



Image 2.1: Illustration of the adapter's built-in safety features, including short-circuit protection, over-voltage protection, and over-current protection, provided by a smart chip.

3. PRODUCT FEATURES

The onerbl AC/DC Adapter is engineered for reliability and performance, offering the following key features:

- **High Quality Replacement:** A brand new, high-quality replacement AC/DC power charger adapter.
- **Worldwide Compatibility:** Features an auto-sensing input of AC 100-240V 50/60Hz, allowing for worldwide use.
- **Advanced Safety:** Equipped with a smart chip providing multiple layers of protection, including:
 - Over Voltage Protection (OVP)

- Over Heat Protection (OHP)
- Short Circuit Protection (SCP)
- Over Current Protection (OCP)

- **Durable Construction:** Designed with quality control in mind, featuring copper wire and a robust PVC jacket for enhanced durability.
- **Tested Units:** Each unit is tested to ensure great working condition upon delivery.




Image 3.1: Details on the adapter's durable design, highlighting the copper wire and PVC jacket for longevity and safety.

4. SETUP INSTRUCTIONS

Follow these steps to set up your onerbl AC/DC Adapter:

1. **Verify Compatibility:** Ensure your device (e.g., Vistefly S7, V15 Max, V15Max vacuum cleaner) requires a 30V DC input and has a compatible power port.
2. **Inspect Adapter:** Before plugging in, visually inspect the adapter and its cable for any cuts, frayed wires, or bent pins. Do not use if any damage is observed.
3. **Connect to Device:** Carefully insert the DC output connector of the adapter into the power input port of your Vistefly vacuum cleaner. Ensure a snug and secure fit.
4. **Plug into Outlet:** Insert the AC plug of the adapter into a standard wall outlet (100-240V AC).
5. **Power On Device:** Once connected, you can power on your device as per its own operating instructions.



Image 4.1: The onerbl AC/DC Adapter plugged into a power strip, demonstrating a typical setup scenario.

5. OPERATING INSTRUCTIONS

The onerbl AC/DC Adapter operates automatically once connected. It converts the AC wall power to the required DC voltage for your compatible device.

- **Charging:** When connected to a Vistefly vacuum cleaner, the adapter will provide power for operation or charge the internal battery, depending on the vacuum cleaner's design. Refer to your vacuum cleaner's manual for specific charging indicators.
- **Continuous Power:** The adapter can provide continuous power for devices that require it, as long as it is plugged into a live outlet and the device is connected.
- **Disconnection:** To disconnect, first power off your device if applicable, then unplug the adapter from the wall outlet, and finally disconnect the DC connector from your device.

6. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your adapter.

- **Cleaning:** Disconnect the adapter from all power sources and devices before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly winding the cable to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cable excessively. Avoid placing heavy objects on the cable.

7. TROUBLESHOOTING

If you encounter issues with your onerbl AC/DC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Adapter not providing power.	<ul style="list-style-type: none"> • No power from outlet. • Loose connection. • Damaged adapter/cable. • Incompatible device. 	<ul style="list-style-type: none"> • Test outlet with another device. • Ensure all connections are secure. • Inspect for damage; replace if necessary. • Verify device voltage/current requirements.
Adapter feels hot during use.	<ul style="list-style-type: none"> • Normal operation (slight warmth). • Overload. • Poor ventilation. 	<ul style="list-style-type: none"> • If excessively hot, disconnect immediately. • Ensure device current draw is within limits. • Provide adequate airflow around the adapter.
Device not charging/operating correctly.	<ul style="list-style-type: none"> • Adapter issue. • Device issue. 	<ul style="list-style-type: none"> • Try another compatible adapter if available. • Consult your device's manual for troubleshooting.

8. SPECIFICATIONS

Detailed technical specifications for the onerbl AC/DC Adapter:

Brand	onerbl
Model Compatibility	Vistefly Model S7, V15 Max, V15Max (and other compatible 30V DC devices)
Input Voltage	AC 100-240V, 50/60Hz (Worldwide Auto Input)
Output Voltage	DC 30V
Cable Length	Approx. 76 inches (6.3 feet)
Color	Black
Protection Features	Over Voltage Protection (OVP), Over Heat Protection (OHP), Short Circuit Protection (SCP), Over Current Protection (OCP)



Image 8.1: Visual representation of the adapter's dimensions (2.6 x 1.6 x 1.2 inches) and cable length (76 inches).

9. WARRANTY AND SUPPORT

The onerbl AC/DC Adapter is backed by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the product packaging or contact the seller directly.

If you require technical assistance, have questions about the product, or need to claim warranty service, please contact the seller or manufacturer through the platform where you purchased the product. Please have your order number and product details ready when contacting support.

Thank you for choosing onerbl.