Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl BZ015-190060-AU

onerbl 19V AC/DC Power Adapter Instruction Manual

Model: BZ015-190060-AU

Compatible with ZCWA BR151, BR151BL, BR151-Z02, BR151-Z06 Robotic Vacuum Cleaners

1. Introduction

Thank you for choosing the onerbl 19V AC/DC Power Adapter. This manual provides essential information for the safe and efficient use of your new power adapter. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following precautions:

- Use the adapter only with compatible devices as specified.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to disassemble or modify the adapter.
- Ensure the power outlet voltage matches the adapter's input specifications.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.

3. Package Contents

Verify that all items are present in your package:

- 1 x onerbl 19V AC/DC Power Adapter (Model BZ015-190060-AU)

4. Product Overview

Familiarize yourself with the components of your power adapter.



Figure 4.1: onerbl 19V AC/DC Power Adapter



Figure 4.2: Front and Side Views of the Adapter




Figure 4.3: Adapter Dimensions (1.6 x 2.6 x 1.2 inches) and Cable Length (76 inches)



Figure 4.4: Integrated Protection Features (Short-circuit, Over-voltage, Over-current)




Figure 4.5: Durable Design with Copper Wire and PVC Jacket

5. Specifications

Feature	Specification
Model	BZ015-190060-AU
Input Voltage	AC 100-240V, 50/60Hz
Output Voltage	19V
Wattage	28W
Connector Type	Proprietary
Cable Length	76 inches (approx. 6.3 feet)
Dimensions (L x W x H)	2.6 x 1.6 x 1.2 inches
Weight	6.3 ounces
Protection Features	Over Voltage Protection, Over Heat Protection, Short-circuit Protection, Over-current Protection
Compatible Devices	ZCWA BR151, BR151BL, BR151-Z02, BR151-Z06 Robotic Vacuum Cleaners

6. Setup

Follow these steps to set up your power adapter:

1. **Inspect the Adapter:** Before use, visually inspect the adapter and its cable for any signs of damage. Do not use if damaged.
2. **Connect to Device:** Insert the proprietary connector of the adapter into the charging port of your compatible ZCWA robotic vacuum cleaner or its charging dock. Ensure a secure connection.
3. **Plug into Power Outlet:** Plug the AC prongs of the adapter into a standard AC 100-240V wall outlet.
4. **Verify Power:** Once connected, your device should indicate that it is receiving power or charging. Refer to your device's manual for specific charging indicators.



Figure 6.1: Adapter Connected to a Power Source and Device

7. Operation

The onerbl 19V AC/DC Power Adapter is designed for continuous power supply and charging of compatible devices. Once properly connected, it will automatically provide the necessary power.

- The adapter features automatic voltage detection (100-240V) for worldwide compatibility.
- Built-in protection mechanisms safeguard against over-voltage, over-heat, short-circuit, and over-current conditions.

8. Maintenance

Proper maintenance ensures the longevity and performance of your power adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cable excessively. Avoid placing heavy objects on the cable.

9. Troubleshooting

If you encounter issues with your power adapter, refer to the following common solutions:

- **No Power Output:**
  - Ensure the adapter is securely plugged into a working wall outlet.
  - Verify the adapter's connector is firmly inserted into the device's charging port.
  - Test the wall outlet with another device to confirm it is functional.
  - Check for any visible damage to the adapter or cable. If damaged, discontinue use.
- **Slow Charging:**
  - Ensure the adapter is the correct specification for your device.
  - Avoid using extension cords or power strips that may not provide sufficient power.
- **Adapter Overheating:**
  - Unplug the adapter immediately.
  - Ensure the adapter is used in a well-ventilated area.
  - Verify that the device being charged is compatible and not drawing excessive power.

If the issue persists after attempting these steps, please contact customer support.

10. Warranty and Support

This onerbl power adapter comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or contact your retailer.

For technical support or inquiries, please contact onerbl customer service through your purchase platform or the official onerbl website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CS69KSLV

More documents and user manuals: **https://manuals.plus/**