

[Manuals.plus](#) /

> [SoBuy](#) /

> SoBuy HFBT02-K-N Round Side Table Instruction Manual

SoBuy HFBT02-K-N

SoBuy HFBT02-K-N Round Side Table

INSTRUCTION MANUAL

Introduction

Thank you for choosing the SoBuy HFBT02-K-N Round Side Table. This versatile table features a unique C-shaped leg design and a natural wood finish, making it a stylish and functional addition to any living space. This manual provides essential information for safe assembly, proper use, and maintenance to ensure the longevity of your product.



Image: SoBuy HFBT02-K-N Round Side Table in a living room setting, showcasing its natural wood finish and C-shaped design next to a white sofa.

Safety Guidelines

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all components are securely connected before use.
- Do not exceed the maximum load capacity of 10 kg (22 lbs).
- Keep small parts away from children during assembly.
- Avoid placing hot items directly on the table surface without protection.
- This table is designed for indoor use. Protect it from direct sunlight and moisture.

Package Contents

Please verify that all parts are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- 1 x Round Tabletop (Diameter: 30 cm)
- 1 x C-shaped Leg Structure



Image: The individual components of the SoBuy HFBT02-K-N Round Side Table, including the round tabletop and the C-shaped leg structure, ready for assembly.

Assembly Instructions

The SoBuy HFBT02-K-N table is designed for easy, tool-free assembly using mortise and tenon joints. No screws are required.

1. **Unpack Components:** Carefully remove all parts from the packaging and place them on a soft, flat surface to prevent damage.
2. **Identify Tabletop:** Locate the round tabletop. Observe the cross-shaped slots on the underside, which are the mortise joints.



Image: Close-up of the tabletop, highlighting the precision-cut slots for the tenon joints.

3. **Position Leg Structure:** Take the C-shaped leg structure. The top part of this structure has corresponding tenon projections.
4. **Connect Leg to Tabletop:** Align the tenon projections of the C-shaped leg structure with the mortise slots on the underside of the tabletop. Gently press down until the pieces fit snugly together. Ensure a firm connection.



Image: Underside view of the tabletop, illustrating how the leg structure connects securely.

5. **Verify Stability:** Once assembled, gently shake the table to ensure it is stable and all connections are secure.

Operating and Usage

The SoBuy HFBT02-K-N table is designed for various uses:

- **Side Table:** Place next to a sofa or armchair to hold drinks, books, or remote controls.
- **Bedside Table:** Ideal for holding a lamp, alarm clock, or personal items next to your bed.
- **Balcony Table:** Suitable for small outdoor spaces, provided it is protected from direct weather exposure.
- **Decorative Accent:** Use to display plants, candles, or other decorative items.

The C-shaped leg allows the table to slide under furniture, bringing the tabletop closer to you for convenience.

Care and Maintenance

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the wood finish.
- **Spills:** Immediately wipe up any spills to prevent water damage or staining. Although the product is described as 'waterproof', prolonged exposure to liquids should be avoided.
- **Heat Protection:** Always use coasters or placemats under hot dishes or drinks to protect the surface.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or warping of the wood.
- **Stability Check:** Periodically check the joints to ensure they remain secure.

Troubleshooting

Issue	Possible Cause	Solution
Table is wobbly after assembly.	Joints not fully engaged.	Press down firmly on the tabletop and leg structure to ensure the mortise and tenon joints are fully seated.
Difficulty fitting parts together.	Misalignment of joints.	Ensure the tenon projections are perfectly aligned with the mortise slots before applying pressure. Do not force parts.
Surface scratches.	Rough handling or abrasive cleaning.	Use a soft cloth for cleaning and avoid dragging sharp objects across the surface. Minor scratches may be treated with wood repair kits.

Product Specifications

Feature	Detail
Model Number	HFBT02-K-N
Dimensions (L x W x H)	Approx. 37 x 37 x 38 cm (14.6 x 14.6 x 15 inches)
Tabletop Diameter	30 cm (11.8 inches)
Weight	Approx. 1.7 kg (3.7 lbs)
Maximum Load Capacity	10 kg (22 lbs)
Material	Wood, Cardboard (packaging)
Color	Natural
Assembly Required	Yes (Tool-free mortise and tenon assembly)
Special Features	Waterproof (surface), C-shaped leg, Round shape



Image: Detailed diagram illustrating the dimensions of the SoBuy HFBT02-K-N Round Side Table.

Warranty and Support

SoBuy is committed to providing high-quality products. If you encounter any issues or have questions regarding your SoBuy HFBT02-K-N Round Side Table, please refer to the following:

- **Missing/Damaged Parts:** If any parts are missing or damaged upon arrival, please contact SoBuy customer service for assistance.
- **Returns:** If you are not satisfied with the product or if there is a problem, you may be eligible for a free return. Please contact SoBuy for return instructions.
- **Contact:** For further support, please visit the official SoBuy store on Amazon or refer to the contact information provided with your purchase.

SoBuy aims to offer innovative and modern furniture solutions with high quality and attractive pricing.

