

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [VTech](#) /
- › [VTech Kidi Star Drum Pad Model 80-572635 User Manual](#)

### VTech 80-572635

# VTech Kidi Star Drum Pad (Model 80-572635) User Manual

Your guide to setting up and enjoying your Kidi Star Drum Pad.

## INTRODUCTION

The VTech Kidi Star Drum Pad is an electronic musical instrument designed for interactive play and learning. It features various drum styles, built-in songs, and interactive games to enhance musical creativity. This manual provides essential information for setup, operation, and maintenance of your device.



Image: The VTech Kidi Star Drum Pad in pink, shown with two drumsticks. The main unit features multiple drum pads, cymbals, and a central control

panel with a display screen.

## WHAT'S IN THE BOX

Please ensure all items are present upon unboxing:

- VTech Kidi Star Drum Pad
- 2 Drumsticks
- Quick Start Guide (refer to this manual for detailed instructions)

## SETUP

### 1. Battery Installation

The Kidi Star Drum Pad requires 4 AA batteries. Batteries are included for demonstration purposes only. For regular use, new alkaline batteries are recommended.

1. Locate the battery compartment on the underside of the drum pad.
2. Using a screwdriver, loosen the screw on the battery compartment cover.
3. Insert 4 new AA batteries, ensuring correct polarity (+/-).
4. Replace the cover and tighten the screw.

#### Important Battery Information:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries during long periods of non-use.
- Dispose of exhausted batteries properly.

### 2. Powering On

Press the **Power** button located on the control panel to turn the device on. The display will illuminate, indicating the device is ready for use.



Image: A top-down view of the Kidi Star Drum Pad, highlighting the control panel with various buttons, a volume knob, and the display screen.

## OPERATING INSTRUCTIONS

### Basic Play

Use the included drumsticks to strike the drum pads and cymbals. Each pad and cymbal produces a distinct sound. The light-up pads and cymbals provide visual feedback during play.



Image: The Kidi Star Drum Pad with its drum pads and cymbals illuminated, demonstrating the light-up feature during active play.

## Volume Control

Adjust the volume using the **Volume** knob located on the central control panel. Turn clockwise to increase volume and counter-clockwise to decrease.

## Headphone Jack

For private play, connect standard headphones (not included) to the headphone jack located on the side of the unit. This will mute the built-in speaker.





Image: A child wearing headphones while actively playing the VTech Kidi Star Drum Pad, illustrating the use of the headphone jack for quiet play.

## MODES AND FEATURES

### Drum Styles

Select from over 20 different drum styles, including rock, marching band, metal, and jazz. Use the dedicated buttons on the control panel to cycle through available styles and find your preferred sound.

### Create and Record

The Kidi Star Drum Pad allows you to create custom drum sounds and record your performances. Press the **Record** button to begin recording and **Replay** to listen to your recorded drum solos.

### Games

Engage in three interactive games, such as "Chase the Light," where you follow the illuminated drum pads and

cymbals to repeat rhythmic patterns.

### Coach Mode

Utilize Coach mode to learn about beats, fills, and rhythm techniques. The drum pad will guide you through various exercises.

### Free-Play Mode

In Free-Play mode, you can experiment with different sounds and create your own rhythms without specific guidance.

### Connect Your Own Music

The drum pad supports external music playback via **BLUETOOTH wireless technology** or a **line-in audio cable** (not included). Connect your music player to play along with your favorite songs.

- **Bluetooth:** Activate Bluetooth on your external device and pair with "Kidi Star Drum Pad".
- **Line-in Audio:** Connect a 3.5mm audio cable from your music player's headphone jack to the drum pad's line-in port.

## MAINTENANCE

### Cleaning

Wipe the drum pad with a slightly damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the device is powered off and disconnected from any external sources before cleaning.

### Storage

Store the drum pad in a cool, dry place away from direct sunlight and extreme temperatures. Remove batteries if the device will not be used for an extended period.

## TROUBLESHOOTING

Problem	Solution
Device does not turn on.	<ul style="list-style-type: none"><li>• Check if batteries are installed correctly with proper polarity.</li><li>• Replace with new AA alkaline batteries.</li><li>• Ensure the Power button is pressed firmly.</li></ul>
No sound or low sound.	<ul style="list-style-type: none"><li>• Adjust the Volume knob.</li><li>• If headphones are connected, disconnect them to enable the built-in speaker.</li><li>• Ensure external music source (if connected) is playing and its volume is up.</li></ul>

Problem	Solution
Bluetooth connection issues.	<ul style="list-style-type: none"><li>• Ensure Bluetooth is enabled on both the drum pad and your external device.</li><li>• Move the devices closer to each other.</li><li>• Try unpairing and re-pairing the devices.</li></ul>

### SPECIFICATIONS

**Model Number:** 80-572635

**Product Dimensions:** 11.06 x 18.46 x 5 inches

**Item Weight:** 3.97 pounds

**Batteries:** 4 AA batteries (included for demo, new recommended for regular use)

**Recommended Age:** 5 years and up

**Manufacturer:** VTech

**Release Date:** January 12, 2024

### WARRANTY AND SUPPORT

For detailed warranty information or technical support, please refer to the official VTech website or contact VTech customer service. The Quick Start Guide included with your product may also contain specific warranty details. You can also find additional resources, including a PDF version of the user manual, on the product's Amazon page or the VTech support portal.

For further assistance, please visit: [VTech Support](#)

### Related Documents - 80-572635

	<p><a href="#">VTech Kidi Star Drum Pad: Instruction Manual and Features</a></p> <p>Explore the VTech Kidi Star Drum Pad with this comprehensive instruction manual. Learn about its features, setup, activities, and troubleshooting for interactive musical fun for children.</p>
	<p><a href="#">VTech Kidi Star Drum Pad Instruction Manual</a></p> <p>Official instruction manual for the VTech Kidi Star Drum Pad, covering setup, features, activities, care, troubleshooting, and safety information.</p>
	<p><a href="#">VTech Kidi Star Drum Pad Instruction Manual</a></p> <p>This instruction manual provides details on how to set up, use, and maintain the VTech Kidi Star Drum Pad, including features, activities, and troubleshooting.</p>
	<p><a href="#">VTech Kidi Star Drum Pad 5726 Instruction Manual</a></p> <p>Comprehensive instruction manual for the VTech Kidi Star Drum Pad (Model 5726), covering setup, features, activities, troubleshooting, and safety information.</p>
	<p><a href="#">VTech Hooray Drum Set Instruction Manual for Kids</a></p> <p>Comprehensive instruction manual for the VTech Hooray Drum Set featuring Bluey. Includes setup, features, modes, care, troubleshooting, and warranty information.</p>





### [VTech Kidi Secrets Doodle Pad Instruction Manual](#)

Official instruction manual for the VTech Kidi Secrets Doodle Pad (Model 5324). Learn how to set up, use features, care for, and troubleshoot your Kidi Secrets Doodle Pad. Includes details on buttons, activities, battery information, and FCC compliance.