

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [DOLPHIN PLAYGROUND T](#) /

› DOLPHIN PLAYGROUND T Wood Swing Set with Monkey Bar and Trapeze Bar Instruction Manual

DOLPHIN PLAYGROUND T B0CS6FX285

DOLPHIN PLAYGROUND T Wood Swing Set with Monkey Bar and Trapeze Bar Instruction Manual

Model: B0CS6FX285

INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your DOLPHIN PLAYGROUND T Wood Swing Set. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Ensure all users understand the safety guidelines.

SAFETY INFORMATION

Your safety and the safety of others are paramount. Failure to follow these instructions can result in serious injury. This product is designed for residential outdoor use only.

General Safety Guidelines:

- Adult supervision is required at all times when children are using the swing set.
- Ensure the swing set is installed on level ground and securely anchored to prevent tipping.
- Maintain a safe clearance area around the swing set, free from obstacles such as fences, trees, or other structures.
- Do not allow children to wear loose clothing, scarves, or items that could get caught in moving parts.
- Maximum weight capacity per swing is 440 pounds. Do not exceed this limit.
- The pinch-free chains are designed to minimize finger injury and hair entanglement.
- Crack resistance bolts on the A-frame legs help prevent wood from breaking.

kids **SAFETY** Design



Figure 1: Safety Features. This image highlights key safety components: a strong swing hanger, a pinch-free chain, and crack resistance bolts integrated into the wooden structure.

SETUP AND ASSEMBLY

Assembly of the DOLPHIN PLAYGROUND T Wood Swing Set requires two adults. Please follow the detailed 3D building plan provided with your product. The hardware is organized by building steps to simplify the process. An additional 10% of spare parts are included in the hardware package.

Before You Begin:


- **Unpacking:** The product ships in two boxes. If you receive only one box, please allow 1-2 days for the second box to arrive.
- **Site Selection:** Choose a level outdoor area for installation. Ensure the area is clear of obstructions and provides adequate space for safe swinging and play. The fully assembled dimensions are approximately 115.8 inches (width) x 74.8 inches (depth) x 84.7 inches (height).
- **Tools Required:** A drill is recommended to expedite assembly. All necessary basic installation tools are included.

- **Parts Verification:** Before assembly, verify all parts are present against the packing list in your 3D building plan.

STEP PACKAGING

- To avoid the confusion when installing, we pack the hardware according to the **BUILDING STEPS**.
 - To avoid the parts missing issue, we add **10% MORE SPARE PARTS** into the hardware package.
 - To make the assemble procedure easier, detailed **3D BUILDING PLAN** provided with the product.
- ENJOY YOUR DIY.**

PARTS from STEP1 to STEP9



spare PARTS



Installation TOOLS



Figure 2: Organized Hardware Packaging. Hardware is packaged by assembly step, with spare parts and tools clearly labeled to facilitate installation.

Assembly Steps:

1. Follow the detailed 3D instructions provided with your product for step-by-step assembly.
2. Assemble the main A-frame structure, ensuring all bolts are tightened securely.
3. Attach the monkey bar section and ensure all rungs are firmly in place.
4. Install the swing hangers and attach the two belt swings and the trapeze bar.
5. Secure the swing set to the ground using the double ground anchors on each leg. These anchors are designed to fix the product strongly to the ground.
6. Perform a final inspection to ensure all connections are tight and the structure is stable.



Figure 3: Assembled Swing Set. This image shows the complete swing set structure, ready for use after assembly and anchoring.

OPERATING INSTRUCTIONS

The DOLPHIN PLAYGROUND T Wood Swing Set offers multiple play options:

- **Belt Swings:** Two classic belt swings are included for traditional swinging.
- **Trapeze Bar:** A trapeze bar provides an additional swinging and hanging activity.
- **Monkey Bar:** The integrated monkey bar allows children to climb and develop upper body strength and balance.

Usage Guidelines:

- Ensure only one child uses each swing or the trapeze bar at a time.
- Instruct children to hold firmly onto the swing chains or trapeze bar handles.
- Supervise children on the monkey bars to prevent falls.
- Do not allow children to stand on the swings or twist the chains excessively.



Figure 4: Children Enjoying the Swing Set. This image shows multiple children actively using the various components of the swing set, including the monkey bars, belt swings, and trapeze bar.



Figure 5: Trapeze Bar and Belt Swings. This image provides a detailed view of the trapeze bar and one of the belt swings, showing their design and how children interact with them.

MAINTENANCE

Regular maintenance is crucial to ensure the longevity and safety of your DOLPHIN PLAYGROUND T Wood Swing Set.

Routine Checks:

- **Monthly:** Inspect all nuts and bolts for tightness. Tighten as necessary. Check for any sharp edges or protruding bolts.
- **Seasonally:** Inspect all moving parts, including swing hangers, chains, and connections, for wear, rust, or damage. Replace any worn or damaged components immediately.
- **Wood Inspection:** Check the cedar wood frame for cracks, splinters, or signs of rot. While the cedar is weather-resistant, regular inspection helps identify potential issues. Sand down any splinters and apply a wood sealant if desired to prolong the wood's life.

- **Ground Anchors:** Verify that the ground anchors remain firmly embedded and the swing set is stable. Re-secure if any movement is detected.

Cleaning:

Clean the swing set with mild soap and water. Avoid harsh chemicals that could damage the wood or plastic components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Swing set feels unstable or wobbly.	Loose bolts or inadequate ground anchoring.	Tighten all bolts. Ensure ground anchors are fully secured and the set is on level ground. Consider additional anchoring if necessary.
Missing parts during assembly.	Parts may be in the second shipping box, or a component was overlooked.	Wait 1-2 days if only one box arrived. Double-check all packaging. Contact customer service if parts are genuinely missing.
Squeaking noises from swings.	Friction in swing hangers or chain connections.	Apply a small amount of lubricant (e.g., silicone spray) to the swing hangers and chain connection points.
Wood developing splinters or cracks.	Natural wood aging or exposure to elements.	Sand down splinters. Apply a wood sealant or stain to protect the wood and prevent further cracking.

SPECIFICATIONS

Brand: DOLPHIN PLAYGROUND T

Model: B0CS6FX285 (Monkey Bar Set)

Product Dimensions (L x W x H): 115.8" x 74.8" x 84.7" (294.1 cm x 189.9 cm x 215.1 cm)

Frame Material: Premium Cedar Wood

Assembly Required: Yes

Item Weight: 110 pounds (49.9 kg)

Maximum Weight Capacity per Swing: 440 pounds (199.5 kg)

Included Components: 1 Monkey Bar, 2 Belt Swings, 1 Trapeze Bar

UPC: 740907188530, 780374548376

Date First Available: January 12, 2024




Figure 6: Product Dimensions and Capacity. This diagram illustrates the overall dimensions of the swing set and specifies the maximum loading capacity per swing.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your DOLPHIN PLAYGROUND T Wood Swing Set, please contact our customer service team. We offer 24-hour customer service to ensure your satisfaction.

Contact Information: Please refer to the contact details provided in your product packaging or on the official DOLPHIN PLAYGROUND T website.

