

manuals.plus /

- › [VGR](#) /
- › [VGR V-737 Professional Rechargeable Lady Shaver User Manual](#)

VGR V-737

VGR V-737 Professional Rechargeable Lady Shaver User Manual

Model: V-737

PRODUCT OVERVIEW

The VGR V-737 Professional Lady Shaver is designed for efficient and gentle hair removal across various body areas, including legs, underarms, arms, and the bikini area. This device features a waterproof design (IPX5), a 500mAh rechargeable lithium battery, and convenient USB magnetic charging. It is engineered to provide a smooth shaving experience while minimizing skin irritation.

CONFIDENCE STARTS

with the Painless Shaving



Lady Trimmer
& Shaver



Led
Indicator



500mAh
Lithium Battery



90 Min
Runtime



5 Mintues
Auto Off



USB
Charging

Image: The VGR V-737 Lady Shaver, showcasing its compact design and key features such as the LED indicator, 500mAh lithium battery, 90-minute runtime, 5-minute auto-off, and USB charging.

IMPORTANT SAFETY INFORMATION

Please read all safety instructions before using the VGR V-737 Lady Shaver to ensure safe operation and prevent injury or damage.

- The VGR V-737 Lady Shaver is safe for sensitive areas and is waterproof (IPX5), meaning it can withstand splashes of water. **Do not submerge the device in water.**
- Charge the device only with the provided USB magnetic charging cable.
- Avoid overcharging the battery.
- Keep the device dry when not in use and store it in a cool, dry place.
- Clean the shaver regularly as instructed in the maintenance section.
- Keep the device out of reach of children.

- Do not use the shaver if the blades are damaged or if the device is malfunctioning.

PACKAGE CONTENTS

The VGR V-737 Professional Lady Shaver package includes the following items:

- 1x VGR V-737 Lady Shaver
- 1x Cleaning Brush
- 1x USB Magnetic Charging Cable
- 1x User Manual (this document)

SETUP AND CHARGING

Before first use, ensure the shaver is fully charged. Follow these steps:

1. Connect the USB magnetic charging cable to the shaver's charging port.
2. Plug the other end of the USB cable into a compatible power source (e.g., power bank, adapter, computer USB port).
3. The LED indicator light will show the charging status. Charge the device for approximately **2 hours** for a full charge.
4. Once fully charged, disconnect the charging cable.

The shaver is equipped with a 500mAh lithium battery, providing up to 90 minutes of continuous runtime on a full charge.



Image: Icons representing USB Magnetic Charging and the 500mAh Lithium Battery, indicating the shaver's power and charging features.

OPERATING INSTRUCTIONS

Follow these steps for effective and comfortable hair removal:

1. Ensure your skin is clean. The shaver can be used for both dry and wet shaving.
2. If desired, attach the appropriate comb or attachment (if included and applicable, though the product description doesn't explicitly mention combs for this model, it mentions "shaving head provides a close shave"). For this model, it seems to be a single shaving head.
3. Press the power button to turn on the shaver. The white indicator light will illuminate.
4. Gently press the shaver head against your skin and move it slowly against the direction of hair growth.
5. For longer hair, use the straight blades head. For short residual hair, use the floating foil head.
6. The shaver is IPX5 waterproof, allowing for use in the shower for convenience.
7. After use, press the power button to turn off the shaver. The device features an auto-off function that will power down the shaver if left unused for 5 minutes.



Image: The VGR V-737 Lady Shaver being used on different body areas, including legs, arms, underarms, and bikini area, demonstrating its versatility.

IPX5 WATERPROOF

Waterproof For Wet & Dry Use



Dry Shave



Wet Shave



Image: The VGR V-737 Lady Shaver submerged in water, illustrating its IPX5 waterproof capability for wet use.

MAINTENANCE AND CLEANING


Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your shaver.

1. **After Each Use:** Turn off the shaver. Remove the shaving head. Use the provided cleaning brush to remove any trapped hair from the blades and the shaver body.
2. **Rinsing:** Since the shaver is IPX5 waterproof, you can rinse the shaving head under running water to clean it thoroughly. Ensure the shaver is turned off before rinsing.
3. **Drying:** Allow the shaving head and shaver body to air dry completely before reattaching the head and storing the device.
4. **Lubrication:** Periodically apply a small drop of lubricating oil (not included, but commonly used for shavers) to the blades to maintain smooth operation.


5. **Storage:** Place the magnetic protection cap over the shaving head when not in use. This keeps the blades clean and protected from dust and damage. Store the shaver in a dry place.

PAINLESS SHAVING HEAD

Get A Close, Gentle Shave Without The Fear of Cuts



Shave the Longer Hair with the Straight Blades Head



Shave Short Residual Hair with the Floating Foil Head

3D Floating Foil Blade
Designed for Use
with Short Hair

Strong Magnets Hold
it Tight, Keeping Blades
Dust-Free

Image: Close-up view of the VGR V-737 shaving head, highlighting the 3D floating foil blade designed for short hair and the magnetic attachment for dust protection.

TROUBLESHOOTING

If you encounter any issues with your VGR V-737 Lady Shaver, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for 2 hours using the provided USB magnetic charging cable.

Problem	Possible Cause	Solution
Shaver stops during use.	Low battery.	Recharge the shaver. The white indicator light will flash when the battery is low.
Poor shaving performance or pulling hair.	Blades are dull or clogged with hair.	Clean the shaving head thoroughly. Consider lubricating the blades. If performance does not improve, the shaving head may need replacement.
Device not charging.	Charging cable or power source issue.	Ensure the USB magnetic charging cable is securely connected to both the shaver and a working power source. Try a different USB port or adapter.

If the problem persists after trying these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model Name	V-737 Professional Lady Shaver
Brand	VGR
Battery Type	500mAh Lithium Battery
Charging Time	Approximately 2 hours
Runtime	Up to 90 minutes
Waterproof Rating	IPX5 (Splash-proof, not submersible)
Power Source	Battery Powered (USB Magnetic Charging)
Auto-Off Feature	Yes, after 5 minutes of inactivity
Blade Material	Stainless Steel
Item Weight	93 Grams
Product Dimensions (LxWxH)	6 x 5.5 x 6 Centimeters
Country of Origin	China

WARRANTY INFORMATION

The VGR V-737 Professional Lady Shaver comes with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects and ensures product satisfaction. Please retain your proof of purchase for warranty claims. For warranty service or inquiries, please contact VGR customer support.

CUSTOMER SUPPORT

For any questions, assistance, or support regarding your VGR V-737 Lady Shaver, please reach out to VGR customer service:

- **Email:** customercare@vgrofficial.in
- **Phone:** 18002578939 (Available from 10:00 AM to 6:00 PM, Monday to Saturday)
- **Website:** www.vgrofficial.in

Manufacturer: Ningbo VGR Electric Appliance Co., Ltd.

