

- Manuals.plus /
- > MOTPK /
 - > MOTPK Gaming Desk with LED Lights & Power Outlet - User Manual

MOTPK MOTPK-39-CF-RMS-OB

MOTPK Gaming Desk with LED Lights & Power Outlet - User Manual

Model: MOTPK-39-CF-RMS-OB
Brand: MOTPK

PRODUCT OVERVIEW

The MOTPK Gaming Desk is designed to enhance your gaming and work experience with its versatile features and robust construction. This 40-inch desk includes integrated LED lighting, a convenient power outlet, an adjustable monitor stand, and reversible storage shelves, all crafted with a durable carbon fiber texture finish.



Figure 1: MOTPK Gaming Desk in a typical setup, showcasing its LED lighting and functional design.

PRODUCT FEATURES

- **Multifunctional LED Light Strip:** Features 10 colors and 20 dynamic modes. Customize color, brightness, and speed to create an immersive environment.
- **Built-in Power Outlet & Headphone Hook:** Equipped with 3 AC outlets and 2 USB ports for convenient device charging. A dedicated headphone hook helps keep your desktop organized.
- **Adjustable Monitor Stand:** A liftable monitor shelf with three adjustable heights (4.4", 5.6", and 6.8") to optimize viewing comfort and reduce neck strain.
- **Considerate & Reversible Storage Space:** Divides the desktop into two main parts: one with the monitor stand and one with shelves. The storage shelves are reversible, allowing installation on either the left or right side, and the middle board is adjustable to two different heights.
- **Carbon Fiber Texture:** The desktop surface features a sleek and durable carbon fiber texture.



Figure 2: Detail of the RGB LED light strip, highlighting its customizable color and mode options.



Figure 3: The integrated power outlet, providing convenient access to 3 AC and 2 USB charging ports.

Adjustable Monitor Stand




Figure 4: The adjustable monitor stand, illustrating its three height options for ergonomic positioning.



Figure 5: The versatile storage shelves, demonstrating their reversibility and adjustable height for various storage needs, including a computer tower.

SETUP AND ASSEMBLY

The MOTPK Gaming Desk is designed for straightforward assembly. All necessary tools and detailed instructions are included to ensure a smooth setup process. It is recommended for 1 person to assemble this desk.

Before You Begin:

- Unpack all components and verify against the parts list in the instruction manual.
- Ensure you have ample clear space for assembly.
- Keep small parts out of reach of children.

Assembly Steps:

1. Follow the step-by-step diagrams and instructions provided in the included manual.
2. Attach the main frame components securely.
3. Install the desktop and monitor stand.
4. Assemble and attach the reversible storage shelves according to your preferred orientation (left or right).
5. Connect the LED light strip and power outlet unit.
6. Attach the headphone hook.
7. Ensure all screws and connections are tightened for stability.




Figure 6: Detailed dimensions of the desk, useful for planning your setup space.

OPERATING INSTRUCTIONS

LED Light Strip Operation:

The LED light strip is controlled via a button panel located on the underside of the monitor stand. This panel allows you to power the lights on/off, cycle through modes, and select colors.

- **Power On/Off:** Press the "ON/OFF" button to turn the lights on or off.
- **Brightness Adjustment:** While the lights are on, repeatedly press the "ON/OFF" button to cycle through different brightness levels.
- **Mode Selection:** Press the "M" (Mode) button to cycle through 20 dynamic lighting modes.
- **Color Selection:** Press the "C" (Color) button to select from 10 static colors.

Power Outlet Usage:

The integrated power outlet provides convenient access to power for your electronic devices.

- Plug the desk's power cord (6.6-feet) into a standard wall outlet.
- Use the 3 AC outlets (125V/12A) for larger electronics and the 2 USB ports (5V-2A) for charging smaller devices like phones or tablets.
- Ensure devices are compatible with the provided power specifications.

Adjusting Monitor Stand:

The monitor stand can be adjusted to three different heights to suit your ergonomic needs.

- Carefully lift the monitor stand to disengage it from its current height setting.
- Adjust to one of the three available heights: 4.4", 5.6", or 6.8".
- Ensure the stand is securely seated in the desired position before placing any items on it.

Adjusting Storage Shelves:

The middle board of the storage rack can be adjusted to two different heights to accommodate various items, such as a computer tower.

- Remove any items from the shelf.
- Carefully lift and reposition the middle board to the desired height.
- Ensure the board is firmly in place before loading it.

MAINTENANCE

- **Cleaning:** Wipe the desk surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the carbon fiber texture.
- **Fasteners:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **LED Lights:** The LED strip is designed for long-term use. If issues arise, refer to the troubleshooting section. Do not attempt to disassemble the LED strip.
- **Power Outlet:** Keep the power outlet free from dust and debris. Do not overload the outlets.

TROUBLESHOOTING

Problem	Possible Cause	Solution
LED lights not turning on.	Power cord not plugged in; LED strip connection loose; LED strip malfunction.	Ensure power cord is securely plugged into wall outlet and desk. Check connection of LED strip to the control panel. If problem persists, contact customer support.
Power outlets not working.	Desk power cord not plugged in; circuit breaker tripped; device malfunction.	Verify the desk's power cord is fully inserted into a live wall outlet. Check your home's circuit breaker. Test with a different device. Avoid overloading the outlets.
Desk feels wobbly.	Loose screws or fasteners; uneven floor.	Check and tighten all assembly screws. Ensure the desk is on a flat, level surface. Adjust leveling feet if present.
Monitor stand not adjusting smoothly.	Obstruction; misaligned.	Ensure no items are obstructing the adjustment mechanism. Verify the stand is correctly aligned with its supports.

SPECIFICATIONS

Attribute	Detail
Brand	MOTPK

Attribute	Detail
Model Number	MOTPK-39-CF-RMS-OB
Product Dimensions	19.7"D x 39.4"W x 29.5"H
Color	Black
Style	Gaming
Top Material Type	Engineered Wood (Carbon Fiber Texture)
Base Material	Metal
Special Features	Reversible, Built-In USB Outlet, Gaming Style, Adjustable Monitor Stand, RGB LED Strip, Headphone Hook, Reversible Storage Shelves
Power Outlet	3 AC Outlets (125V/12A), 2 USB Ports (5V-2A)
Power Cord Length	6.6 Feet
Monitor Stand Heights	4.4", 5.6", 6.8"
Assembly Required	Yes (Tools Included)
Recommended Assembly People	1

Safety Information

Please read and adhere to the following safety guidelines to ensure safe use of your MOTPK Gaming Desk:

- Anchoring:** Ensure proper anchoring to prevent tipping, especially if the desk is placed on an uneven surface or in a high-traffic area.
- Weight Limit:** Do not exceed the specified weight limit for the desktop and shelves. Overloading can cause damage or instability. Refer to the assembly instructions for specific weight limits.
- Electronic Devices:** Exercise caution when using electronic devices with the built-in power outlet. Do not overload the outlets. Disconnect power during electrical storms or prolonged periods of non-use.
- Assembly:** Follow all assembly instructions carefully. Incorrect assembly can lead to instability and potential injury.
- Children and Pets:** Keep small parts and tools away from children and pets during assembly. Ensure the desk is stable and secure before allowing children near it.
- Placement:** Place the desk on a flat, stable surface. Avoid placing it near heat sources, direct sunlight, or in excessively humid environments.

Warranty and Support

Limited Warranty:

The MOTPK Gaming Desk comes with a limited warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration of coverage. This warranty typically covers manufacturing defects and material flaws under normal use.

Customer Support:

For any questions, concerns, or assistance with your MOTPK Gaming Desk, our responsive customer support team is available to help you. Please contact us via the following methods:

- **Email:** [Insert Customer Support Email Here - if available, otherwise omit]
- **Phone:** [Insert Customer Support Phone Number Here - if available, otherwise omit]
- **Online:** Visit the official MOTPK store on Amazon for FAQs and further assistance. Our team aims to respond within 24 hours.

Please have your model number (MOTPK-39-CF-RMS-OB) and purchase information ready when contacting support to expedite the process.

© 2024 MOTPK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0CS6LPGDT>

More documents and user manuals: <https://manuals.plus/>