Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Atomberg /
- > Atomberg Zenova Mixer Grinder Instruction Manual

Atomberg Zenova Mixer Grinder

Atomberg Zenova Mixer Grinder Instruction Manual

Model: Zenova Mixer Grinder Brand: Atomberg

1. Introduction

The Atomberg Zenova Mixer Grinder is designed to simplify your kitchen tasks with its intelligent BLDC motor, unique Coarse Mode, and versatile jar system. This manual provides essential information for safe and efficient operation, ensuring you get the best performance from your appliance.



Figure 1: The Atomberg Zenova Mixer Grinder with its base unit and four accompanying jars.

Your browser does not support the video tag.

Video 1: An overview of the Atomberg Zenova Mixer Grinder, showcasing its features and components.

2. PRODUCT COMPONENTS

Your Atomberg Zenova Mixer Grinder package includes the following items:

- Mixer Base Unit
- 1.5 Liter Liquidizing Jar
- 1 Liter Multipurpose Jar
- 0.5 Liter Chutney & Spice Grinding Jar
- 0.5 Liter Chopper Jar
- Spatula
- Instruction Manual with Warranty Card

Durable & sturdy jars with anti-gravity lid locks for hands-free operation Multipurpose Jar Liquidizing Jar 1.5 L Spices Wet Grinding Nuts Chutney Jar Dry Grinding **Smoothies** 0.5 L Tough Grinding Shakes Chutneys Thecha Salsa **Unique Chopper** Jar 0.5 L 里 Vegetables

Figure 2: The complete set of four jars included with the mixer grinder, each designed for specific tasks.

Your browser does not support the video tag.

Video 2: This video demonstrates the various jars that come with the Atomberg Mixer Grinder and their intended uses.

3. SETUP AND ASSEMBLY

Follow these steps to set up your mixer grinder for first use:

- 1. **Unpack:** Carefully remove all components from the packaging.
- 2. Clean Jars: Wash all jars and lids with mild soap and water, then dry thoroughly.
- 3. Place Base Unit: Position the mixer grinder base unit on a stable, flat, and dry surface.
- 4. Attach Jar: Place the desired jar onto the base unit. Ensure it is securely seated.
- 5. **Secure Lid:** Place the lid on the jar and engage the anti-gravity lid locks by pushing them down until they click into place.
- 6. Connect Power: Plug the power cord into a suitable electrical outlet.



Figure 3: A user demonstrating the secure placement of a jar onto the mixer grinder base unit.

4. OPERATING INSTRUCTIONS

Speed Control and Modes

The Atomberg Zenova Mixer Grinder features a knob control for adjusting speed and selecting modes:

- Pulse: Use for short bursts of power to chop or mix ingredients quickly.
- Speed Settings (1-3): Gradually increase speed for various grinding tasks.
- Coarse Mode: A unique setting designed for achieving a sil-batta-like coarse texture.

Coarse Mode Operation

The Coarse Mode is ideal for preparing chutneys, dips, and masalas that require a distinct, grainy texture. To activate, turn the knob to the 'Coarse' setting. This mode carefully grinds ingredients to prevent overprocessing, preserving authentic flavors and textures.

All-new Coarse Mode™ for silbatta-like coarse textures



Watery texture, Perfect grinding, coarse texture, poor taste magical taste

Figure 4: Visual comparison demonstrating the perfect coarse texture achieved by Atomberg's Coarse Mode, similar to traditional silbatta grinding.

Your browser does not support the video tag.

Video 3: This video highlights the unique Coarse Mode of the Atomberg Mixer Grinder and its benefits for achieving specific textures.

Jar Usage Guidelines

Each jar is designed for optimal performance in specific applications:

- 1.5L Liquidizing Jar: Ideal for wet grinding, making smoothies, shakes, and batters.
- 1L Multipurpose Jar: Suitable for dry grinding spices, nuts, and tough ingredients like turmeric.
- **0.5L Chutney & Spice Grinding Jar:** Perfect for small quantities of chutneys, pastes, and fine spice grinding.
- 0.5L Chopper Jar: Designed for quick and efficient chopping of vegetables like onions and other ingredients.

Grinds every ingredient that a 1000W mixer can



Figure 5: An illustration of the mixer grinder's versatility, showing different ingredients being processed for chopping, coarse grinding, wet grinding, and tough grinding.



Figure 6: The chopper jar in action, demonstrating its effectiveness in quickly chopping vegetables like onions.

5. SAFETY FEATURES

The Atomberg Zenova Mixer Grinder incorporates advanced safety features for a worry-free experience:

- Jar Lock Detection: The mixer will only operate when the jar is securely locked onto the base unit, preventing accidental starts.
- Fault LED Indication: An LED indicator alerts you to potential issues such as overloading, allowing you to take corrective action.
- No Auto-Restart After Power Cuts: The appliance will not automatically restart after a power interruption, enhancing safety.
- Anti-Gravity Lid Locks: These locks ensure the lids remain securely in place during operation, preventing spills and ensuring hands-free use.

Advanced safety features





Jar lock detection Starts only when securely locked



Fault indication Alerts overloading



No auto restart

Prevents accidental start post power-cuts

Figure 7: Visual representation of the advanced safety features, including jar lock detection and fault indication.

Your browser does not support the video tag.

Video 4: This video demonstrates the advanced safety features, including jar lock technology and fault indication, ensuring secure operation.

6. CARE AND MAINTENANCE

Proper care and maintenance will extend the life of your mixer grinder:

- Cleaning the Base Unit: Wipe the base unit with a damp cloth. Do not immerse it in water.
- Cleaning Jars and Lids: Wash jars and lids with mild detergent and water. Rinse thoroughly and dry immediately. Note: Jars are not dishwasher safe.
- Ventless Design: The ventless body design prevents dust, pests, and moisture from entering the
 motor, making cleaning hassle-free and improving durability.
- Storage: Store the mixer grinder and its accessories in a clean, dry place when not in use.



Figure 8: The sleek, ventless design of the mixer grinder, highlighting its ease of cleaning and modern aesthetic.

7. TROUBLESHOOTING

If you encounter any issues, refer to the table below for common problems and solutions:

Problem	Possible Cause	Solution
Mixer does not start	Power cord not plugged in, jar not locked, power outage.	Ensure power cord is securely plugged in. Lock the jar properly. Check power supply.
Motor stops during operation	Overloading, overheating.	Reduce quantity of ingredients. Allow motor to cool down for 15-20 minutes.
Ineffective grinding	Insufficient liquid (for wet grinding), blunt blades, incorrect speed setting.	Add more liquid. Contact customer care for blade replacement. Adjust speed setting.
Leakage from jar	Lid not properly secured, worn-out gasket.	Ensure lid is tightly closed and anti-gravity locks are engaged. Check and replace gasket if worn.

8. TECHNICAL SPECIFICATIONS

• Brand: Atomberg

• Model Name: Atomberg Zenova Mixer Grinder

• Colour: Black

• Product Dimensions: 36.5D x 33.5W x 29.1H Centimeters

• Special Features: Coarse Mode, Advanced Safety Features, Sleek Design, Adjustable Speed Control

• Capacity: 1.5 litres (Liquidizing Jar)

• Controls Type: Knob Control

• Is Dishwasher Safe: No

• Manufacturer: Atomberg Technologies Pvt. Ltd.

9. WARRANTY AND CUSTOMER SUPPORT

The Atomberg Zenova Mixer Grinder comes with a standard 2-year warranty. An additional 1-year warranty can be availed by registering your purchase on the Atomberg website, extending your total warranty to 3 years.

For any queries, service requests, or support, please contact Atomberg Customer Care:

• Email: support@atomberg.com

• Phone: 08448449442



Figure 9: Highlights of Atomberg's commitment to quality and customer satisfaction, including a 3-year warranty and robust service network.

© 2023 Atomberg Technologies Pvt. Ltd. All rights reserved.

Related Documents - Zenova Mixer Grinder



Atomberg Studio+ Ceiling Fan Instruction Manual

Comprehensive instruction manual for the Atomberg Studio+ Ceiling Fan, covering installation, operation, troubleshooting, and maintenance. Features energy savings and remote control functionality.



Atomberg Renesa Pedestal Fan Assembly and Warranty Information

This document provides assembly instructions and warranty details for the Atomberg Renesa Pedestal Fan. It includes a step-by-step guide for assembling the fan, product interface information, and comprehensive warranty registration and exclusion details.

BOSS



BOSS Nutri Pro with Chopper B-637: Instruction Manual & Technical Data

Comprehensive instruction manual for the BOSS Nutri Pro with Chopper (Model B-637), featuring 400W power. Learn how to use, clean, and maintain your appliance for blending, grinding, and chopping. Includes safety guidelines and technical specifications.

LAKELAND





Lakeland Mini Grind and Chop Instruction Booklet

Official instruction booklet for the Lakeland Mini Grind and Chop (Model 62167), providing details on product features, safety precautions, usage instructions, care, cleaning, and technical information for optimal performance.



Cuisinart Elemental Series 4-Cup Chopper/Grinder: Instruction & Recipe Booklet

Comprehensive instruction and recipe booklet for the Cuisinart Elemental Series 4-Cup Chopper/Grinder (ECH-4 Series), covering unpacking, safety, assembly, operation, cleaning, troubleshooting, techniques, recipes, and warranty information.