

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Numskull](#) /

> [Numskull Teenage Mutant Ninja Turtles Hard Shell Travel Case for Nintendo Switch and OLED Model Console Instruction Manual](#)

## Numskull NS4818

# Numskull Teenage Mutant Ninja Turtles Hard Shell Travel Case

## INSTRUCTION MANUAL

Brand: Numskull | Model: NS4818

### 1. Product Overview

This manual provides instructions for the Numskull Teenage Mutant Ninja Turtles Hard Shell Travel Case, designed to protect your Nintendo Switch or OLED Model console. This case offers reliable protection and organized storage for your gaming essentials, featuring a durable exterior and a soft interior.



## 2. Key Features

---

- **Reliable Protection:** The hard shell exterior shields your Nintendo Switch from scratches, drops, and impacts, ensuring console safety during travel or daily use.
- **Organized Storage:** Features custom compartments designed to securely hold up to 10 game cartridges. Additional space is provided for accessories such as cables or earbuds.
- **Compact and Portable:** Designed to be lightweight and compact, facilitating easy transport while maintaining robust protection for your console.
- **Screen Protection:** A soft inner lining is incorporated to prevent screen damage, and a durable zipper ensures all contents remain securely in place.
- **Thematic Design:** Available in various styles, including the Teenage Mutant Ninja Turtles theme, allowing users to express their preferences.

## 3. Setup and Usage

---

1. **Opening the Case:** Unzip the case using the durable zipper. The case will open flat, revealing the interior compartments.
2. **Inserting the Console:** Gently place your Nintendo Switch or OLED Model console into the main compartment. Ensure it fits snugly to prevent movement during transport. The soft inner lining will protect the screen.



*Image 3.1: Demonstrating how to place the Nintendo Switch console into the case.*

- 3. Storing Game Cartridges:** Utilize the dedicated elastic slots to securely hold up to 10 game cartridges. Insert each cartridge firmly into its designated slot.



*Image 3.2: Interior view showing game card slots and mesh accessory pocket.*

4. **Storing Accessories:** The mesh pocket with a zipper provides additional space for small accessories such as charging cables, earbuds, or extra Joy-Con straps. Ensure items are placed neatly to allow the case to close properly.
5. **Closing the Case:** Once all items are securely placed, close the case and zip it completely to ensure maximum protection.
6. **Carrying:** Use the integrated web handle for convenient and secure carrying.

## 4. Care and Maintenance

---

- **Cleaning:** To clean the exterior, wipe with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these may damage the material or design.
- **Interior Care:** The soft inner lining can be gently wiped with a dry, soft cloth if needed. Ensure no moisture remains inside before storing the console.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Avoid Overfilling:** Do not overfill the case, as this can put undue stress on the zippers and potentially damage the console or accessories.

## 5. Troubleshooting

---

This product is a protective case and has minimal operational components. Most issues relate to proper usage and storage.

- **Case Not Closing Properly:** Ensure all items inside are correctly positioned and not obstructing the zipper path. Avoid overfilling the case.
- **Console Not Fitting:** Verify that you are using a Nintendo Switch or OLED Model console. The case is specifically designed for these models.
- **Zipper Sticking:** Check for any fabric or debris caught in the zipper teeth. Gently clear any obstructions. Do not force the zipper.

## 6. Specifications

Feature	Detail
Brand	Numskull
Model Number	NS4818
Compatible Devices	Nintendo Switch, Nintendo Switch OLED Model
Shell Type	Hard
Closure Type	Zipper
Number of Compartments	2 (main console, mesh pocket)
Game Card Capacity	Up to 10
Material	Polyester
Item Weight	7.2 Ounces (approx. 204 grams)
Product Dimensions	10.6"L x 2.2"W x 5.3"H (approx. 26.9cm x 5.6cm x 13.5cm)

## 7. Warranty and Support

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Manufacturer: Rubber Road Ltd