

[Manuals.plus](#) /

› [Zulay Kitchen](#) /

› Zulay Froth N Go Milk Frother Rechargeable - 3-in-1 Frother Wand With Case & USB-C Charger - Comes With 3 Whisk Attachments for Latte, Cappuccino, Matcha, Protein Shakes - Black Rechargeable Frother Shadow Black

## Zulay Kitchen Froth N Go Rechargeable Milk Frother

# Zulay Froth N Go Milk Frother Instruction Manual

Model: Froth N Go Rechargeable Milk Frother

Brand: Zulay Kitchen

## 1. INTRODUCTION

---

Thank you for choosing the Zulay Froth N Go Milk Frother. This versatile and powerful handheld frother is designed to help you create perfect creamy foam for your favorite beverages and effortlessly mix various ingredients. Its rechargeable design and multiple attachments make it an essential tool for any kitchen.



Image: The Zulay Froth N Go Milk Frother, showcasing the main unit, protective case, and various whisk attachments.

## 2. WHAT'S IN THE BOX

- Zulay Froth N Go Rechargeable Frother Unit
- Single Whisk Frother Attachment
- Double Whisk Frother Attachment
- Egg Beater Attachment
- USB-C Charging Cable
- Protective Cover

## 3. SETUP

### Charging the Frother

The Zulay Froth N Go comes with a rechargeable 1200mAH lithium battery. Before first use, or when the battery indicator shows low power, charge the unit using the provided USB-C charging cable. A full charge can provide up to one hour of continuous use.

# FAST CHARGING LONG LASTING

USB RECHARGEABLE BATTERY TYPE C



WALL OUTLET



POWERBANK



LAPTOP



**BATTERY INDICATOR:**  
● FULLY CHARGED  
● EMPTY

Image: The frother connected via USB-C cable, illustrating charging from a wall outlet, power bank, or laptop. A green light indicates full charge, red indicates empty.

## Attaching Whisk Attachments

1. Select the desired whisk attachment (single, double, or egg beater).
2. Align the attachment with the opening at the bottom of the frother unit.
3. Gently push the attachment into place until it clicks securely.
4. To remove, pull the attachment firmly but gently from the unit.



Image: Detailed view of the three interchangeable whisk attachments: single coil, double coil, and balloon whisk.

## 4. OPERATING INSTRUCTIONS

The Zulay Froth N Go is operated with a simple one-button control. Press the button once to turn it on, and press it again to turn it off.

### Frothing Milk

- For best results, use cold milk (dairy or non-dairy like soy, almond, cashew, hazelnut, coconut, whole milk).
- Insert the single or double whisk attachment into the milk.
- Press the power button to activate the frother.
- Move the frother up and down in the milk until desired foam consistency is achieved.
- Turn off the frother and enjoy your creamy beverage.

**VELVETY  
CREAMY  
FROTH**  
ANYWHERE,  
ANYTIME



Image: The frother in action, creating velvety creamy froth in a cup of coffee, emphasizing its portability.

### Mixing Drinks and Whisking Eggs

- Use the single or double whisk for mixing protein shakes, matcha, or other powdered drinks.
- Attach the egg beater for whisking eggs for omelets or scrambled eggs.
- Insert the appropriate attachment into your ingredients and press the power button.
- Mix until thoroughly combined.



Image: A collage demonstrating the frother's versatility for frothy coffee, matcha, whisking eggs, and mixing protein powder.

### Official Product Video

Your browser does not support the video tag.

Video: Official product video demonstrating the Zuly Kitchen Froth N Go in use, highlighting its features and ease of use.

## 5. MAINTENANCE AND CLEANING

To ensure the longevity of your Zuly Froth N Go, proper cleaning is essential.

- **Removable Attachments:** The whisk and egg beater attachments can be easily removed and cleaned under running water. Hand wash only.
- **Frother Handle:** Wipe the handle of the frother unit with a damp cloth. Do not submerge the main unit in water.
- **Storage:** Use the protective cover to keep the frother clean and dust-free when not in use, or for convenient carrying in your bag or kitchen drawer.

## 6. TROUBLESHOOTING

If you encounter any issues with your Zulay Froth N Go Milk Frother, please refer to the warranty and support section for assistance. Ensure the unit is fully charged and attachments are correctly installed before use.

## 7. SPECIFICATIONS

| Feature                   | Detail                                                          |
|---------------------------|-----------------------------------------------------------------|
| Brand                     | Zulay Kitchen                                                   |
| Model Name                | Froth N Go Rechargeable Milk Frother                            |
| Color                     | Shadow Black                                                    |
| Material                  | Stainless Steel                                                 |
| Special Feature           | Rechargeable                                                    |
| Power Source              | Rechargeable                                                    |
| Number of Settings        | 1                                                               |
| Included Components       | Rechargeable Frother (with 3 whisk attachments and USB-C cable) |
| Product Care Instructions | Hand Wash Only                                                  |
| Item Weight               | 9.2 ounces                                                      |
| Package Dimensions        | 11.26 x 3.07 x 1.73 inches                                      |

## 8. WARRANTY & SUPPORT

Zulay Kitchen stands behind the quality of the Froth N Go Milk Frother with **Lifetime Warranty**. We take pride in our products and are committed to your satisfaction.

If you experience any issues or have questions regarding your frother, please do not hesitate to contact Zulay Kitchen customer support. We are here to help and will ensure any concerns are addressed promptly.

For support, please visit the official Zulay Kitchen store or contact us through the platform where you purchased the product.

© 2024 Zulay Kitchen. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**