

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Baby Born](#) /

> [Baby Born Learn to Walk Baby Doll Annabell - Instruction Manual](#)

Baby Born 919787

Baby Born Learn to Walk Baby Doll Annabell - Instruction Manual

Model: 919787 | Brand: Baby Born

INTRODUCTION

The Baby Born Learn to Walk Baby Doll Annabell is designed to provide an interactive and nurturing play experience. This doll features realistic movements and sounds, mimicking a baby's developmental stages from crawling to taking first steps. It encourages imaginative role-play and helps children develop nurturing skills. Recommended for children ages 36 months - 8 years.

WHAT'S INCLUDED

- BABY born My First Steps Doll - Annabell (blue eyes)

SETUP & BATTERY INSTALLATION

1. **Battery Requirements:** The doll requires 3 x AA alkaline batteries (not included).
2. **Locate Battery Compartment:** The battery compartment is located on the doll's back, usually secured with a small screw. Use a Phillips head screwdriver to open it.
3. **Insert Batteries:** Insert 3 fresh AA alkaline batteries, ensuring correct polarity (+/-).
4. **Secure Compartment:** Replace the cover and tighten the screw.
5. **Power On:** Locate the ON/OFF switch on the doll's back (near the battery compartment) and slide it to the "ON" position.

Makes baby sounds



Image: Back of the Baby Born doll, illustrating the location of the battery compartment and ON/OFF switch.

OPERATING INSTRUCTIONS

1. Crawling

To make the doll crawl, gently place her in a crawling position on a flat surface. She will begin to crawl on her own, mimicking a real baby's movements and sounds. If she struggles or makes crying sounds, gently pat her back to soothe her.

Crawls on her own



Image: The Baby Born doll positioned on all fours, ready to crawl.

2. First Steps (Walking)

Help the doll take her first steps by carefully clicking her legs into a standing position and pulling her arms up. Hold her hands, and she will start to walk with your assistance. This feature simulates a baby learning to walk, providing an interactive experience.

Hold hands to walk





Image: A child's hands supporting the Baby Born doll in an upright position, assisting her in taking her first steps.

3. Arm & Leg Movements (Sitting)

When the doll is sitting upright, gently tilt her backwards slightly. She will kick her legs and move her arms while making cute baby sounds. Press her belly button to activate additional sounds and movements.

Arms move and legs kick



Image: The Baby Born doll sitting, demonstrating its ability to move its arms and kick its legs.

4. Lifelike Baby Sounds

The doll produces various lifelike baby sounds:

- **Giggles:** Press her tummy button to hear her giggle.
- **Yawning & Sleeping Sounds:** Rock her gently, and she will make yawning and sleeping sounds.
- **Baby Sounds:** Adorable baby sounds accompany her arm and leg movements.

Makes baby sounds



Image: Close-up of the Baby Born doll's face, with speech bubbles indicating "weee" and "heehee" sounds.

5. Eyes Open & Close

The doll's eyes will close when she is laid down for bed, simulating a sleeping baby. Her eyes will open when she is picked up or placed in an upright position.

Eyes open and close



Image: Two images of the Baby Born doll's face, one with eyes open and one with eyes closed, illustrating the open and close eye feature.

6. Official Product Video

Your browser does not support the video tag.

Video: Official demonstration of the BABY born Learn to Walk Dolls by MGA Entertainment, showcasing various features and movements.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the doll's surface with a damp cloth. Do not immerse the doll in water.
- **Storage:** Store the doll in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Remove batteries if the doll will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

Problem	Solution
Doll not responding or making sounds.	Check if the ON/OFF switch is in the "ON" position. Ensure batteries are correctly installed and replace them if they are depleted.

Problem	Solution
Doll not crawling or walking properly.	Ensure the doll is placed on a flat, smooth surface. Check battery levels. Verify that the doll's limbs are correctly positioned for the desired action.
Doll cries frequently.	Gently pat the doll's back to soothe her. This is part of her realistic features.

SPECIFICATIONS

- **Product Dimensions:** 8.75 x 6 x 15.5 inches
- **Item Weight:** 1 pound
- **Item Model Number:** 919787
- **Manufacturer Recommended Age:** 36 months - 8 years
- **Batteries:** 3 x AA alkaline batteries (not included)
- **Manufacturer:** MGA Entertainment

SAFETY INFORMATION

Please refer to the full owner's manual for comprehensive safety information. Always supervise children during play. Keep small parts away from young children to prevent choking hazards.

WARRANTY & SUPPORT

For warranty information or customer support, please contact MGA Entertainment directly through their official website or customer service channels. Retain your proof of purchase for any warranty claims.