

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PRITOM](#) /

› [PRITOM L8 8-inch Android Wi-Fi Tablet User Manual](#)

## PRITOM L8

# PRITOM L8 8-inch Android Wi-Fi Tablet User Manual

Model: L8

## 1. INTRODUCTION

This manual provides essential information for setting up and operating your PRITOM L8 8-inch Android Wi-Fi Tablet. Please read it thoroughly before use to ensure proper functionality and to maximize your device's potential.

## 2. PACKAGE CONTENTS

Verify that all items are present in the package:

- PRITOM L8 8-inch Android Tablet
- Protective Cover
- Screen Protector (pre-applied)
- Power Adapter
- USB Type-C Cable
- User Manual (Japanese, but this document serves as the English version)

僅か330g、ポータブルな8インチタブレット



An image showing the PRITOM L8 tablet, a protective cover, a USB cable, and an AC adapter, illustrating the typical package contents.


### 3. PRODUCT OVERVIEW

#### 3.1 Physical Features

The PRITOM L8 tablet features an 8-inch IPS display with a resolution of 1280x800 pixels. It is designed to be lightweight and portable, weighing approximately 319g (420g with the protective case).




A close-up image of the PRITOM L8 tablet highlighting its key specifications: Android 13 Go, 320g weight, 2GB RAM, GMS certification, 8-inch 1280x800 IPS display, 5000mAh battery, 64GB ROM, and 2.4G Wi-Fi 6 support.



An image showing the slim profile of the PRITOM L8 tablet next to a ruler, emphasizing its lightweight design and portability.

### 3.2 Dimensions

The tablet measures approximately 20.8 cm in length, 12.2 cm in width, and 0.8 cm in thickness.



An image illustrating the dimensions of the PRITOM L8 tablet, showing its length as 20.8cm and width as 12.2cm.

## 4. SETUP

### 4.1 Initial Power On

Press and hold the power button located on the side of the tablet until the screen lights up. Follow the on-screen prompts to complete the initial setup.

### 4.2 Language Settings

During the initial setup, you will be prompted to select your preferred language. If you need to change the language later, navigate to **Settings > System > Languages & input > Languages**

---

This video demonstrates how to change the system language on the PRITOM L8 tablet. It shows navigating through the settings menu to select and apply a new language.

### **4.3 Wi-Fi Connection**

To connect to a Wi-Fi network, go to **Settings > Network & internet > Wi-Fi**. Select your desired network and enter the password if required. The tablet supports 2.4GHz Wi-Fi only.

## **5. OPERATING INSTRUCTIONS**

### **5.1 Basic Navigation**

- **Home Screen:** Swipe left or right to access different app pages.
- **Notifications:** Swipe down from the top of the screen to view notifications and quick settings.
- **App Drawer:** Swipe up from the bottom of the screen to access all installed applications.

### **5.2 Installing Applications**

The tablet comes with Google Mobile Services (GMS) certification, allowing you to download applications like Facebook, YouTube, and Netflix from the Google Play Store.

### **5.3 Storage Management**

The tablet has 64GB of internal storage (ROM) and 4GB of RAM (2GB physical + 2GB extended). Storage can be expanded up to 256GB using a microSD card (not included).

# お気に入りをすべて保存

**2GB**  
RAM

**64GB**  
ROM

**256GB**  
Expandable



An image displaying the PRITOM L8 tablet's storage capabilities, showing 2GB RAM, 64GB ROM, and the option for 256GB expandable storage.

## 5.4 Battery Management


The 5000mAh battery provides up to 4 hours of mixed usage, including reading, video playback, music, and light gaming. To optimize battery life, adjust screen brightness, close unused applications, and enable battery saver mode when needed.



An image of the PRITOM L8 tablet with an overlay indicating its 5000mAh battery, capable of 5 hours of web browsing and 3 hours of video playback.

### 5.5 Eye-Care Mode

The tablet features an eye-care mode that optimizes backlight for a more comfortable reading experience. This can be enabled in the display settings.



A person holding the PRITOM L8 tablet, engaged in web browsing, demonstrating the tablet's use for reading and general content consumption.

### 5.6 GPS Functionality

The tablet supports GPS for route searching via applications like Google Maps. Please note that its navigation capabilities are limited and not intended for primary navigation use.

## 6. SPECIFICATIONS

Feature	Description
Model Name	L8
Brand	PRITOM
Operating System	Android 13 Go
Screen Size	8 inches
Display Resolution	1280x800 IPS
Processor	Unisoc Quad-core, 1.3 GHz

<b>RAM</b>	2 GB (4GB total with 2GB extended)
<b>Internal Storage (ROM)</b>	64 GB
<b>Expandable Storage</b>	Up to 256 GB via microSD card
<b>Battery Capacity</b>	5000 mAh
<b>Battery Life</b>	Approx. 4 hours (mixed use)
<b>Connectivity</b>	2.4GHz Wi-Fi, Bluetooth 4.0
<b>Front Camera</b>	2 MP
<b>Weight</b>	320 g (tablet only), 420 g (with case)
<b>Certifications</b>	TELEC, GMS

## 7. TROUBLESHOOTING

### 7.1 Device is Slow or Unresponsive

- Close unnecessary background applications.
- Clear cache for frequently used apps.
- Restart the tablet.
- Ensure sufficient free storage space.

### 7.2 Wi-Fi Connection Issues

- Verify that your router is broadcasting a 2.4GHz signal. This tablet does not support 5GHz Wi-Fi.
- Restart your Wi-Fi router and the tablet.
- Check if the Wi-Fi password is entered correctly.

### 7.3 Battery Drains Quickly

- Reduce screen brightness.
- Disable Wi-Fi or Bluetooth when not in use.
- Limit background app activity.
- Ensure the tablet is fully charged using the provided adapter and cable.

## 8. MAINTENANCE

- Keep the tablet clean using a soft, dry cloth.
- Avoid exposing the tablet to extreme temperatures or direct sunlight.
- Protect the screen with the pre-applied screen protector and the included protective cover.
- Regularly back up important data.

## 9. WARRANTY AND SUPPORT

The PRITOM L8 tablet comes with a 3-month manufacturer's warranty, extendable by an additional 3 months, totaling 6 months of warranty coverage. This warranty covers defects in materials and workmanship under normal use.

For warranty claims or technical support, please contact the seller, VASOUN-Tech, through your Amazon

order history:

1. Go to your Amazon "Order History".
2. Locate the relevant order for your PRITOM L8 tablet.
3. Click on "Sold by: VASOUN-Tech" and then select "Ask a question".

Please provide your order number when contacting support for faster assistance.