

Manuals.plus /

› AOLIKES /

› AOLIKES 1500mAh Battery Replacement User Manual

## AOLIKES 802080

# AOLIKES 1500mAh Battery Replacement User Manual

Model: 802080 | Brand: AOLIKES

## INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your AOLIKES 1500mAh Battery Replacement. This battery is designed for compatibility with Logitech Wireless Illuminated Keyboard K800 (YR0065) and Logitech MX Keys Wireless Keyboard (YR0073), as well as other models using battery part numbers 533-000177, 533-000221, 533-000141, and Ln1906.

The packing list includes: 1500mAh battery pack x1.

## SAFETY INFORMATION

Your 3.7V rechargeable Lithium Polymer battery is manufactured with high-quality materials and incorporates built-in protection mechanisms against overcharging, overheating, and short circuits. These features ensure optimal battery operation and minimize potential hazards. Always handle the battery with care and avoid puncturing, disassembling, or exposing it to extreme temperatures or liquids.

## SETUP AND INSTALLATION

Replacing the battery in your Logitech keyboard requires careful handling. The following steps provide a general guide. Specific models may have slight variations, and it is recommended to consult online video tutorials for your exact keyboard model (e.g., Logitech K800 or MX Keys) for visual guidance.

- 1. Prepare the Keyboard:** Ensure your keyboard is powered off and disconnected from any charging cables.
- 2. Locate Battery Compartment:** For many Logitech keyboards, the battery is located under a removable panel or a section of the casing. Often, this involves peeling back a sticker (e.g., the serial number sticker) to reveal screws.
- 3. Remove Screws:** Carefully remove any screws securing the battery compartment or casing. A small Phillips head screwdriver is typically required.
- 4. Access Old Battery:** Gently open the keyboard casing or panel to expose the old battery. Be mindful of any ribbon cables or connectors.
- 5. Disconnect Old Battery:** Carefully disconnect the old battery's connector from the keyboard's circuit board. Do

not pull on the wires; grasp the connector itself.

6. **Insert New Battery:** Connect the new AOLIKES 1500mAh battery to the circuit board, ensuring the connector is securely seated.
7. **Position Battery:** Place the new battery into its designated slot. *Note: Some users have reported that the cable leads on replacement batteries can be slightly shorter than the original. If this occurs, carefully route the cable to ensure it fits without strain.*
8. **Reassemble Keyboard:** Carefully reassemble the keyboard casing, ensuring all screws are replaced and tightened appropriately.
9. **Test Functionality:** Power on your keyboard and test its functionality, including charging and wireless connectivity.




Figure 1: Front view of the AOLIKES 1500mAh replacement battery with its connector and wires.

## Battery fits Logitech Wireless Illuminated Keyboard K800



Figure 2: The AOLIKES 1500mAh replacement battery, indicating compatibility with Logitech Wireless Illuminated Keyboard K800.




Figure 3: Side profile of the AOLIKES 1500mAh battery, showing its slim design.




Figure 4: Rear view of the AOLIKES 1500mAh battery, highlighting the connection point.

## OPERATING INSTRUCTIONS

Once installed, the AOLIKES 1500mAh battery operates identically to the original battery in your Logitech keyboard. Charge the keyboard using its standard charging method (e.g., USB cable). The 1500mAh capacity provides extended usage time compared to lower capacity original batteries, potentially allowing for several days to weeks of use depending on keyboard model and usage patterns (e.g., RGB lighting settings).

## MAINTENANCE

To maximize the lifespan of your AOLIKES replacement battery:

- Avoid fully discharging the battery frequently.
- Store the keyboard in a cool, dry place when not in use for extended periods.
- Do not expose the battery to extreme heat or cold.
- Use only the charging accessories provided with your Logitech keyboard.

## TROUBLESHOOTING

If you encounter issues after installing the new battery, consider the following:

- **Battery Not Charging / Keyboard Not Powering On:**
  - Ensure the battery connector is fully and correctly seated on the circuit board.
  - Verify the charging cable and power source are functional.
  - Confirm the keyboard's power switch is in the 'On' position.
- **Battery Drains Quickly:**

- Check if high-power features like keyboard backlighting (RGB) are constantly active. Reduce brightness or turn off if not needed.
  - Ensure the keyboard is not constantly searching for a connection if it's out of range of its receiver.
  - If the issue persists, the battery may be faulty. Contact customer support.
- **Battery Does Not Fit Properly:**
    - Double-check that you have the correct battery model for your specific keyboard.
    - Carefully re-route the battery wires to ensure they are not obstructing the fit. Some users have noted slight variations in wire length compared to original batteries.

## SPECIFICATIONS

Feature	Detail
Battery Type	Polymer Lithium Ion Rechargeable Battery
Battery Capacity	1500mAh
Rated Voltage	3.7V
Fully Charged Voltage	4.2V
Power	5.55Wh
Shutdown Voltage	2.85V
Model Number	802080
Item Weight	0.704 ounces
Package Dimensions	3.7 x 1.97 x 0.35 inches
Country of Origin	China

## WARRANTY INFORMATION

Specific warranty details for the AOLIKES 1500mAh Battery Replacement are provided by the manufacturer or seller at the time of purchase. Please retain your proof of purchase for any warranty claims. For detailed information regarding warranty coverage, terms, and conditions, please refer to the product packaging or contact the seller directly.

## SUPPORT

For further assistance, technical support, or inquiries regarding your AOLIKES product, please visit the official AOLIKES Store or contact their customer service. You can find more information and contact details at the AOLIKES Store on Amazon.