



Manuals.plus /

› NQEUEPN /

› NQEUEPN Rubber Lid Latch Strap (Model 133104) - Instruction Manual

## NQEUEPN 133104

# NQEUEPN Rubber Lid Latch Strap (Model 133104)

Instruction Manual

## 1. INTRODUCTION

---

This manual provides instructions for the proper use and maintenance of your NQEUEPN Rubber Lid Latch Strap. This product is designed to secure the lids of slow cookers and crockpots during transport, preventing spills and maintaining food temperature. Please read these instructions carefully before use.

## 2. PRODUCT FEATURES

---

- **Material:** Made from food-grade silicone, ensuring safety and durability.
- **Durability:** Heat-resistant and tear-resistant for long-term use.
- **Flexibility:** Designed with appropriate stretchability to fit various pot sizes.
- **Function:** Secures sliding lids and maintains a tight seal to prevent leaks during transport.

# Sturdy

Perfectly fit, more sturdy



# Strong density

Lasting seal and keep tight



Image: Visual representation of the product's key features, including food-grade silicone, reliability, heat resistance, tear resistance, stretchability, and long service life.

### 3. PACKAGE CONTENTS

---

- 2 x NQEUEPN Rubber Lid Latch Straps (Black)

# Product Size




Image: A pair of black silicone lid latch straps, as included in the package.

## 4. COMPATIBILITY

The NQEUEPN Rubber Lid Latch Strap is designed to fit many 6, 7, and 8-quart slow cooker and crockpot models. Compatible models may include, but are not limited to, Hamilton Beach models such as 33167, 33172, and 33176. Ensure your slow cooker has handles suitable for securing the strap.

## 5. SETUP

No assembly is required for the lid latch strap. Before first use, wash the strap with warm, soapy water and rinse thoroughly. Ensure the strap is dry before use.

## 6. OPERATING INSTRUCTIONS

1. **Prepare your slow cooker:** Ensure the lid is properly seated on your slow cooker or crockpot.
2. **Position the strap:** Place the rubber lid latch strap over the lid, ensuring it encircles the entire pot.
3. **Secure the strap:** Hook each side of the strap under the handles of your slow cooker. The strap should be taut, holding the lid firmly in place.

4. **Verify security:** Gently lift the slow cooker by its handles to confirm the lid is securely fastened and will not shift during transport.



Image: The lid latch strap in use, securing a slow cooker lid to prevent spills and maintain a tight seal.

## 7. CARE AND MAINTENANCE

- **Cleaning:** Wash the strap by hand with warm water and mild dish soap. Rinse thoroughly and allow to air dry completely before storing.
- **Storage:** Store the strap in a clean, dry place away from direct sunlight and extreme temperatures to prolong its lifespan.
- **Inspection:** Periodically inspect the strap for any signs of wear, tears, or damage. Discontinue use if damage is observed.



## Reduce messy leaks With special lid lock strap

Image: A close-up view of the silicone strap, highlighting its sturdy and dense construction, which contributes to its durability.

### 8. TROUBLESHOOTING

---

- **Strap feels too tight or not stretchy enough:** Ensure the strap is correctly positioned around the pot and under the handles. While designed to be taut for security, some initial stiffness is normal. Over time, the silicone may exhibit slight flexibility with use.
- **Strap does not fit my slow cooker handles:** This strap is designed for slow cookers with handles that allow the strap to hook underneath. If your slow cooker has a different handle design, the strap may not be compatible. Verify your slow cooker's handle type before use.
- **Lid still shifts or leaks:** Ensure the strap is properly secured and taut. The lid should be firmly pressed down by the strap. If the lid itself is damaged or does not form a good seal with the pot, the strap may not fully prevent leaks.

### 9. SPECIFICATIONS

---

<b>Brand</b>	NQEUEPN
<b>Model</b>	133104
<b>Material</b>	Food-grade Silicone
<b>Color</b>	Black
<b>Dimensions (approx.)</b>	23.37 cm (9.2 in) diameter, 0.51 cm (0.2 in) thickness
<b>Weight (per strap)</b>	Approximately 41 grams

## Product Features

Our product has the following features



Image: Detailed diagram illustrating the precise dimensions of the lid latch strap in both centimeters and inches.

### 10. WARRANTY AND SUPPORT

Specific warranty information for this product is not provided in the available data. For any product-related inquiries or support, please refer to the seller or retailer from whom the product was purchased.