

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Outsunny](#) /

› [Outsunny Folding Patio Chairs \(Model: 84B-811GY\) Instruction Manual](#)

Outsunny 84B-811GY

Outsunny Folding Patio Chairs (Model: 84B-811GY) Instruction Manual

Your guide to setting up, using, and maintaining your Outsunny patio chairs.

[Instructions](#) [Safety Information](#) [Product Overview](#) [Setup](#) [Operating](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. SAFETY INFORMATION

Please read and understand all safety warnings before using this product.

- **Maximum Weight Capacity:** Each chair supports a maximum weight of 264 lbs (120 kg). Do not exceed this limit to prevent injury or damage.
- **Folding:** Fold chairs carefully to avoid pinching fingers or other body parts. Ensure hands and feet are clear of moving parts during folding and unfolding.
- **Weather Conditions:** Do not leave chairs exposed to extreme weather conditions (e.g., heavy rain, strong winds, prolonged direct sunlight, freezing temperatures) for extended periods. This can reduce product lifespan and cause damage.
- **Stable Surface:** Always place the chairs on a flat, stable, and level surface to prevent tipping.
- **Children:** Keep children away from the chairs during setup and folding. Supervise children when they are using the chairs.
- **Inspection:** Before each use, inspect the chairs for any signs of damage, loose parts, or wear. Do not use if damaged.

2. PRODUCT OVERVIEW

The Outsunny Folding Patio Chairs are designed for comfortable outdoor seating. This set includes two portable chairs, ideal for various outdoor settings such as patios, gardens, pools, beaches, and camping trips.

Key Features:

- **Double Lawn Chair Set:** Comes as a set of two chairs for convenient outdoor seating.
- **Comfortable Design:** Features ergonomic curved armrests, form-fitting bungee suspensions, and a breathable mesh fabric backrest for enhanced comfort.

- **Folding and Portable:** Lightweight and designed to fold flat for easy transport and storage, making them suitable for travel.
- **Durable Construction:** Crafted from powder-coated steel for a water-safe build and increased weight capacity. The mesh fabric is breathable and dries quickly.



Figure 2.1: Two Outsunny folding patio chairs on a wooden deck, ready for use.

3. SETUP INSTRUCTIONS

The Outsunny Folding Patio Chairs require no assembly. Follow these simple steps to unfold and set up your chairs:

1. Unfolding the Chair:

Hold the folded chair by the top of the backrest and the front of the seat. Gently pull the two sides apart to begin unfolding.



FOLDING DESIGN

Folding design makes these chairs easy to carry to your next outing



Camping



Beach



Park

Figure 3.1: The chair in its folded, compact state, demonstrating ease of transport.

2. Securing the Chair:

Continue to open the chair until the seat and backrest are fully extended. Ensure that the back support bars lock into place. You may need to gently push down on the armrests or seat to fully engage the locking mechanism.

3. Final Check:

Before sitting, gently test the chair to ensure it is stable and all parts are securely in position. The chair should not wobble or show any signs of instability.



SET OF 2

Perfect for relaxing with your good friend



Figure 3.2: Detailed dimensions of the chair when upright and folded, highlighting its compact design.


4. OPERATING INSTRUCTIONS

Once set up, your Outsunny Folding Patio Chair is ready for use. These chairs are designed for comfortable lounging and relaxation.

- **Sitting:** Sit gently into the chair, distributing your weight evenly. The bungee suspension system will conform to your body for comfort.
- **Armrests:** Utilize the ergonomic armrests for support and added comfort.
- **Movement:** Avoid sudden movements or rocking vigorously in the chair, as this may compromise stability.



THOUGHTFUL WORKMANSHIP



Weather-resistant
Mesh Fabric



Sturdy Steel Frame

Figure 4.1: Close-up view of the chair's weather-resistant mesh fabric and sturdy steel frame construction.

5. MAINTENANCE

Proper care will extend the life of your Outsunny Folding Patio Chairs.

- **Cleaning:** Wipe clean with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners, which can damage the fabric or frame finish.
- **Drying:** Allow the chairs to air dry completely before folding and storing, especially after cleaning or exposure to rain. The mesh fabric is designed to dry quickly.
- **Storage:** When not in use for extended periods, or during inclement weather, fold the chairs and store them in a dry, protected area to prevent rust or fabric degradation.
- **Frame Inspection:** Periodically check the steel frame for any signs of rust or damage. Touch up any scratches on the powder-coated finish to prevent rust.
- **Bungee Cords:** Inspect the bungee cords for fraying or loss of elasticity. While durable, extreme wear may necessitate replacement over time.



Figure 5.1: Detail of the bungee cord suspension system, which provides comfort and support.



Figure 5.2: Detail of the chair's sturdy steel leg and protective foot cap.

6. TROUBLESHOOTING

If you encounter any issues with your Outsunny Folding Patio Chairs, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair feels unstable or wobbly.	Not fully unfolded or placed on an uneven surface.	Ensure the chair is fully unfolded and the back support bars are locked. Move the chair to a flat, level surface.
Difficulty folding/unfolding.	Mechanism may be stiff or obstructed.	Apply gentle, even pressure. Check for any obstructions in the folding mechanism. Lubricate moving parts if necessary with a silicone-based spray.

Problem	Possible Cause	Solution
Fabric appears loose or stretched.	Normal wear and tear, or excessive weight.	The bungee system is designed to be flexible. Ensure weight capacity is not exceeded. If bungee cords are damaged, contact support for possible replacement.

7. SPECIFICATIONS

Feature	Detail
Brand	Outsunny
Model Number	84B-811GY
Color	Grey
Material	Alloy Steel frame, Mesh fabric
Overall Dimensions (Upright)	24.75" L x 24" W x 35.75" H
Folded Dimensions	33.75" L x 24" W x 3.5" T
Seat Height	17.25 Inches
Seat Depth	17.75 Inches
Seat Length	15.25 Inches
Maximum Weight Recommendation	264 lbs (per chair)
Item Weight	20 pounds (per chair)
Assembly Required	No
Included Components	2 Chairs

8. WARRANTY AND SUPPORT

For warranty information or product support, please contact the manufacturer, Aosom LLC, directly. Details regarding specific warranty periods and terms are typically provided with your purchase documentation or can be obtained by contacting their customer service.

Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: Aosom LLC

For further assistance, please visit the Outsunny brand store or contact their customer service department.

