

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Hotsmtbang](#) /

› [Hotsmtbang Replacement Remote Control for Adjustable Bed Base \(MLILY M200F\) - Instruction Manual](#)

Hotsmtbang MLILY M200F

Instruction Manual for Hotsmtbang Replacement Remote Control

Model: MLILY M200F

1. INTRODUCTION

This manual provides comprehensive instructions for the Hotsmtbang replacement remote control, specifically designed for adjustable bed bases. This remote is compatible with the MLILY M200F model and serves as a direct replacement for your original remote. It is essential to follow the pairing instructions to ensure proper functionality with your adjustable bed base.

2. COMPATIBILITY

This remote control is engineered as a dedicated replacement for specific adjustable bed bases. To confirm compatibility, your existing remote control must be visually identical to the remote depicted in this manual. It is compatible with the **MLILY M200F** adjustable bed base model. Furthermore, the control box of your adjustable bed base must be from the **Richmat** brand. Known compatible Richmat control box model numbers include: **HJK02**, **NH200-TSI**, and **NH200B-U 127780K020004**.

If your bed base model or control box model is not explicitly listed, or if you are uncertain about compatibility, please contact Hotsmtbang customer support for verification before attempting to use this remote.

3. PACKAGE CONTENTS

The package for your Hotsmtbang Replacement Remote Control includes the following item:

- 1 x Hotsmtbang Replacement Remote Control

Please note: Batteries (2 x AAA) and a printed instruction manual are not included in the package.

4. SETUP

Battery Installation

The remote control requires two (2) AAA batteries for operation. These batteries are not supplied with the remote.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect battery orientation will prevent the remote from functioning.
4. Slide the battery cover back into place until it clicks securely, indicating it is properly closed.



Image: Rear view of the remote control with the battery compartment open, illustrating the correct placement for two AAA batteries.

5. PAIRING INSTRUCTIONS

Before the remote control can operate your adjustable bed base, it must be paired. The exact pairing method can vary slightly between different bed base models, but a common procedure is outlined below:

Standard Pairing Procedure

1. Ensure your adjustable bed base is properly plugged into a working electrical outlet and is powered on.
2. On the remote control, simultaneously press and hold the 'Head Up' button (the button that raises the

head section of the bed) and the 'Foot Up' button (the button that raises the foot section of the bed).

3. Continue to hold both buttons. Observe your bed base's control box or motor for any indication of pairing, such as a flashing light or a slight movement from the bed. This typically signifies a successful pairing.
4. Once pairing is confirmed, release both buttons.
5. Test the remote control by pressing various function buttons (e.g., Head Up, Flat) to ensure full functionality and proper communication with your bed base.

If the pairing process is unsuccessful, please consult the original instruction manual for your specific adjustable bed base model for alternative pairing methods, or contact Hotsmtbang customer support for further assistance.

6. OPERATION

The Hotsmtbang replacement remote control features clearly labeled buttons for intuitive operation of your adjustable bed base.



Image: Front view of the remote control, displaying the primary function buttons.

- **Head Up/Down Buttons:** These buttons control the elevation and lowering of the head section of your adjustable bed.
- **Foot Up/Down Buttons:** These buttons control the elevation and lowering of the foot section of your adjustable bed.
- **Flat Button:** Pressing this button will return your adjustable bed to a completely flat, horizontal position.

Depending on your specific adjustable bed base model, there may be additional buttons for features such as massage, pre-set positions, or under-bed lighting. For detailed instructions on these advanced functions, please refer to the original instruction manual provided with your adjustable bed base.

7. MAINTENANCE

To ensure the longevity and optimal performance of your remote control, please follow these simple maintenance guidelines:

- **Cleaning:** Wipe the remote control regularly with a soft, dry cloth to remove dust and smudges. Avoid using liquid cleaners, abrasive materials, or chemical solvents, as these can damage the remote's surface or internal components.
- **Protection:** Keep the remote control away from direct sunlight, extreme temperatures (both hot and cold), and high humidity. Do not expose it to water or other liquids.
- **Battery Care:** If the remote control will not be used for an extended period (e.g., several weeks or months), it is recommended to remove the AAA batteries to prevent potential battery leakage, which can cause damage to the remote's circuitry.

8. TROUBLESHOOTING

If you encounter issues with your Hotsmtbang replacement remote control, please refer to the table below for common problems and their solutions.

Problem	Possible Cause	Solution
Remote not responding to button presses.	Low or dead batteries.	Replace the AAA batteries with new ones, ensuring correct polarity.
Remote not controlling the bed base after battery replacement.	Remote is not paired with the bed base.	Repeat the pairing procedure as detailed in Section 5: 'Pairing Instructions'.
Remote is paired but only some buttons work, or functions are incorrect.	Incorrect remote for the specific bed base model or control box.	Verify that your bed base model (MLILY M200F) and control box (Richmat HJK02, NH200-TSI, NH200B-U 127780K020004) are compatible. The remote must visually match your original.
Buttons feel sticky or are difficult to press.	Debris or liquid under the buttons.	Clean the remote's surface carefully with a dry cloth. Do not attempt to disassemble the remote. If damage is suspected, replacement may be necessary.

If the problem persists after attempting these solutions, please contact Hotsmtbang customer support for further assistance.

9. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	MLILY M200F
Manufacturer	Hotsmtbang
Power Source	2 x AAA Batteries (not included)
Special Feature	No additional programming required (after initial pairing)
Compatible Control Box	Richmat (e.g., HJK02, NH200-TSI, NH200B-U 127780K020004)
Connectivity Technology	Wireless (Radio Frequency)
Country of Origin	China

10. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the specific policies provided by the seller on the product's purchase page. Alternatively, you may contact Hotsmtbang directly through the retailer from whom the product was acquired.

It is important to ensure the compatibility of this replacement remote control with your adjustable bed base model and control box before purchase to avoid any inconvenience.