Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AMOROM AM-P1

AMOROM Indoor Security Camera User Manual

Model: AM-P1

Brand: AMOROM

1. Introduction

Thank you for choosing the AMOROM Indoor Security Camera. This manual provides detailed instructions for setting up, operating, and maintaining your camera to ensure optimal performance and security for your home. The AMOROM camera offers 360-degree coverage, advanced night vision, two-way audio communication, AI-powered motion detection, and seamless integration with smart home systems like Amazon Alexa and Google Assistant.



Image: The AMOROM Indoor Security Camera provides comprehensive home monitoring.

2. What's in the Box

Please verify that all components are present in your package:

- Indoor Camera × 2
- Power Adapter × 2
- Type-C Charging Cable × 2
- Screw Bags × 2
- Camera Mount × 2
- User Manual × 1

3. Product Overview

3.1 Key Features

360° Coverage & Night Vision

The camera features 360° pan/tilt/zoom functionality, allowing you to monitor an entire room. Its integrated infrared system provides clear night vision up to 30 feet, ensuring continuous surveillance even in low-light conditions.



Image: 360° All Direction Coverage.

Voice Control & 2-Way Audio

Communicate directly through the camera using its built-in microphone and speaker. The camera is compatible with Amazon Alexa and Google Assistant, enabling voice commands for live feed access.



Image: Two-Way Audio functionality.



Image: Works with Amazon Alexa and Google Assistant.

AI Motion Detection & Instant Alerts

Advanced AI motion detection sends immediate alerts to your smartphone upon detecting movement or unusual activity, providing real-time security monitoring.



Image: Smart Motion Detection sends notifications.

Privacy Mode

For enhanced privacy, the camera features a privacy mode that automatically turns off the camera and points it downward with a single tap in the AMOROM app, without needing to unplug the device.



Image: Intimate Privacy Mode for user privacy.

Multi-User Access & Multiple Views

The AMOROM app supports unlimited users, allowing multiple family members to access the live feed simultaneously. You can also add up to 16 cameras and view their live feeds on one screen.



Image: Multiple Users Sharing and Multiple Views.

Two Storage Options

Recordings can be stored locally on a MicroSD card (up to 128GB, sold separately) or securely in the cloud via the AMOROM app. All cloud videos are encrypted and protected with AWS Cloud.



Image: Two Storage Options: MicroSD Card and Free Cloud Storage.

AI Fire Detection

The camera incorporates advanced AI algorithms to immediately recognize flames, providing a mobile alarm system for 24/7 support to protect your safety and property.



Image: Artificial Intelligence Fire Detection.

4. Setup Guide

4.1 Download the AMOROM App

Search for "AMOROM" in your smartphone's app store (iOS or Android) and download the official application. Create an account or log in if you already have one.




Image: AMOROM App - Access Anywhere.

4.2 Powering On and Initial Connection

1. Connect the camera to a power source using the provided power adapter and Type-C charging cable.
2. Wait for the camera's indicator light to flash, indicating it's ready for pairing.
3. Open the AMOROM app and follow the on-screen instructions to add a new device.
4. Ensure your smartphone is connected to a **2.4GHz Wi-Fi network**. This camera model only supports 2.4GHz Wi-Fi.
5. Scan the QR code displayed on your phone with the camera lens, or follow alternative pairing methods provided in the app.
6. Once connected, the camera's indicator light will turn solid.

4.3 Mounting the Camera

The camera can be placed on a flat surface or mounted to a wall using the included camera mount and screws.

1. Choose a suitable location for optimal viewing coverage.
2. If wall-mounting, use the camera mount as a template to mark drill holes.
3. Drill holes and insert wall anchors if necessary.
4. Secure the camera mount to the wall using the provided screws.
5. Attach the camera to the mount.

5. Operating Instructions

5.1 Live View and Pan/Tilt Control

From the AMOROM app, select your camera to access the live feed. Use the on-screen controls to pan (horizontal movement), tilt (vertical movement), and zoom to adjust the viewing angle.



Image: 360° Full View Capture Everything.

5.2 Two-Way Audio Communication

Tap the microphone icon in the live view interface to speak through the camera. Tap the speaker icon to listen to audio from the camera's surroundings.

5.3 Motion Detection and Alerts

Configure motion detection sensitivity and alert preferences within the app's settings. You will receive instant notifications on your phone when motion is detected.

5.4 Privacy Mode Activation

To activate privacy mode, navigate to the camera settings in the AMOROM app and select "Privacy Mode." The camera lens will automatically rotate downwards, disabling video and audio recording.

5.5 Storage Management

Insert a MicroSD card (up to 128GB) into the designated slot for local storage. Alternatively, subscribe to the cloud storage service via the app for secure, encrypted online storage. Note that playback of recorded video may require a cloud storage subscription.

5.6 Voice Assistant Integration

Link your AMOROM account with Amazon Alexa or Google Assistant through their respective apps. Once linked, you can use voice commands like "Alexa, show me the baby's room" to view the live feed on compatible smart displays.

6. Maintenance

- **Cleaning:** Gently wipe the camera lens and body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Software Updates:** Regularly check the AMOROM app for firmware updates. Keeping your camera's software up-to-date ensures optimal performance, security, and access to new features.
- **Placement:** Ensure the camera is placed in a stable location, away from direct sunlight, extreme temperatures, and high humidity.

7. Troubleshooting

Problem	Possible Cause / Solution
Camera won't connect to Wi-Fi.	◦ Ensure your Wi-Fi network is **2.4GHz**. This camera does not support 5GHz Wi-Fi. ◦ Check Wi-Fi password accuracy. ◦ Move the camera closer to the Wi-Fi router. ◦ Restart your router and the camera.
No video playback from MicroSD card.	◦ Ensure the MicroSD card is correctly inserted and formatted (FAT32). ◦ Verify the card is not full. ◦ Some features, including video playback history, may require a cloud storage subscription.
Two-way audio is unclear or distorted.	◦ Ensure there is no obstruction near the microphone or speaker. ◦ Check your internet connection stability. ◦ Reduce background noise in the environment.
Motion detection alerts are not received.	◦ Check app notification settings on your phone. ◦ Verify motion detection is enabled in the AMOROM app. ◦ Adjust motion detection sensitivity.

8. Specifications

Feature	Detail

Feature	Detail
Model Number	AM-P1
Indoor/Outdoor Usage	Indoor
Connectivity Protocol	Wi-Fi (2.4GHz Only)
Power Source	Corded Electric
Video Capture Resolution	1080p
Viewing Angle	360 Degrees (Pan/Tilt)
Night Vision Range	30 Feet
Storage Options	MicroSD (up to 128GB), Cloud Storage
Compatible Devices	Smartphone
Controller Type	Google Assistant, Amazon Alexa
Dimensions (L x W x H)	3.15 x 1.97 x 2.36 inches
Item Weight	1.19 pounds
Material	Plastic
Included Components	Indoor Camera × 2, Power Adapter × 2, Type-C Charging Cable × 2, Screw Bags × 2, Camera Mount × 2, User Manual × 1

9. Warranty and Support

AMOROM is committed to providing excellent customer service. If you encounter any issues or have questions regarding your camera, please do not hesitate to contact our 24/7 customer support team. We are here to ensure you have the best possible experience with your product.
For support, please refer to the contact information provided on the product packaging or within the AMOROM app.



Image: 24/7 Customer Support.

© 2024 AMOROM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CSD3GXW8

More documents and user manuals: **https://manuals.plus/**