



[Manuals.plus](#) /

› [Beyution](#) /

› Beyution AXD7710 Replacement Remote Control User Manual for Pioneer Home Theater Systems

Beyution AXD7710

Beyution AXD7710 Replacement Remote Control User Manual

For Pioneer Home Theater Systems

1. INTRODUCTION

This manual provides instructions for the Beyution AXD7710 Replacement Remote Control. This remote is designed to function as a direct replacement for the original remote controls of various Pioneer Home Theater Systems, requiring no programming or setup.



Image 1.1: Front view of the Beyution AXD7710 Replacement Remote Control.

2. PRODUCT FEATURES

- **Model:** AXD7710
- **Connectivity:** Infrared (IR)
- **Material:** Durable ABS Plastic
- **Operating Distance:** Up to 10 meters (approximately 33 feet)
- **Setup:** No programming or pairing required; functions immediately upon battery insertion.
- **Design:** Lightweight and ergonomic for comfortable handling.
- **Button Response:** Buttons are designed for good elasticity and responsive feedback.

3. SETUP: BATTERY INSTALLATION

The remote control requires two (2) AA size batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Remove batteries if the remote control will not be used for an extended period.





Image 3.1: Battery compartment for AA batteries.

4. OPERATING INSTRUCTIONS

Once batteries are installed, the Beyution AXD7710 remote control is ready for immediate use with compatible Pioneer Home Theater Systems. No additional programming or setup is required.

1. **Point the Remote:** Aim the remote control directly at the infrared receiver on your Pioneer Home Theater System.
2. **Press Buttons:** Press the desired function button (e.g., Power, Volume, Input, Play) to control your device.
3. **Response:** The device should respond to the commands sent by the remote control.

For specific functions of your Pioneer Home Theater System, refer to the original user manual of your audio system.

5. COMPATIBLE MODELS

This replacement remote control is compatible with, but not limited to, the following Pioneer Home Theater System models:

- X-HM21
- X-HM211
- XH-HM31
- X-HM41
- X-HM21V-K
- X-HM21V-S
- X-HM41V-S
- X-HM211V-S
- X-CM31-K
- X-CM31-W
- X-HM31V-K
- X-HM31V-S
- X-HM32V-K
- X-HM32V-S
- X-HM32VD-K
- X-HM31DAB-K

If your specific model is not listed, please contact customer support for compatibility verification.

6. SPECIFICATIONS

Feature	Specification
Product Dimensions	6.3 x 1.57 x 0.39 inches
Item Weight	2.47 ounces
Model Number	AXD7710
Brand	Beyution
Special Feature	Ergonomic design
Color	Black
Max Number of Supported Devices	1 (Pioneer Home Theater System)

7. TROUBLESHOOTING

If the remote control is not functioning as expected, consider the following troubleshooting steps:

- **Check Batteries:** Ensure that the batteries are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh AA batteries if necessary.
- **Line of Sight:** Verify that there is a clear line of sight between the remote control and the infrared

receiver on your Pioneer Home Theater System. Obstructions can block the signal.

- **Distance:** Ensure you are within the effective operating range of 10 meters.
- **Remote Damage:** Inspect the remote for any visible damage. If the remote control is damaged or does not work after checking the above, please contact customer support.

8. MAINTENANCE

To ensure the longevity and proper functioning of your remote control:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the remote will not be used for an extended period to prevent leakage.

9. WARRANTY AND SUPPORT

This Beyution AXD7710 Replacement Remote Control comes with a **6-month warranty period** from the date of purchase.

If you encounter any issues with your remote control, or if it arrives damaged or ceases to function correctly, please contact our customer service team. We are committed to providing a satisfactory solution within 24 hours.

For support, please refer to the contact information provided by your retailer or on the product packaging.