

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GOCKERA](#) /

› [GOCKERA F01 Portable Fan User Manual](#)

## GOCKERA F01

# GOCKERA F01 Portable Fan User Manual

Model: F01-Pink

## INTRODUCTION

Thank you for choosing the GOCKERA F01 Portable Fan. This versatile 3-in-1 fan is designed to provide powerful and quiet cooling wherever you go. With its 5-speed settings, smart digital display, and foldable design, it's an ideal companion for both indoor and outdoor activities. Please read this manual carefully before using the product to ensure proper operation and maintenance.

## PRODUCT FEATURES

- 5 Speed & Strong Wind Power:** Equipped with an upgraded brushless motor, offering powerful airflow with 5 adjustable speed settings to suit your cooling needs.
- Smart Digital Display:** An intelligent LED display shows the current fan speed and remaining battery percentage in real-time.
- Portable Design:** Compact and lightweight (145g), making it easy to carry in a handbag or backpack for travel, shopping, camping, or daily use.
- 180° Foldable Fan:** The fan head can be folded 180 degrees, allowing flexible adjustment of airflow direction and compact storage.
- Long Battery Life:** Built-in 4200 mAh rechargeable battery provides up to 20-24 hours of use on a full charge (2.5-3 hours charging time).
- Ultra Quiet Operation:** Designed for minimal noise, with maximum wind speed noise below 25dB and minimum below 7dB, ensuring it won't disturb you during work, study, sleep, or makeup application.
- Multi-functional Use:** Can be used as a handheld fan, neck fan (with included lanyard), or desk fan with its stable non-slip base that also functions as a phone stand.



Image: The GOCKERA F01 Portable Fan showcasing its versatility in handheld, neck, and desk configurations. The digital display is visible on the handle.

# GOCKERA Foldable Handheld Fan

Innovative Motor Powerful and Higher Wind Speed  
5 Speeds Adjustable, Comfortable All Day Long!



Image: An exploded view of the GOCKERA F01 fan, highlighting its innovative motor and fan blades, capable of up to 13500 RPM for strong airflow.

# High-Performance Battery Longer Working Time

Charging Time: 2.5-3 Hours

Working Time: 8-24 Hours (Fully Charged)

8-24  
Hours



Image: A close-up of the GOCKERA F01 fan's internal 4200mAh battery, illustrating its long working time of 8-24 hours and a charging time of 2.5-3 hours.

# *Intelligent Digital Display*

Real-time battery level and gear level



*Battery Power*




*Wind Speed Gear*

Image: The intelligent digital display of the GOCKERA F01 fan, showing real-time battery level and wind speed gear.

# GOCKERA Stand Fan

Stable base & Easy to use



mobile phone holder

Image: The GOCKERA F01 fan positioned on its stable base, demonstrating its use as a desk fan and a mobile phone holder.

*Ultra Quiet and Comfortable*

*Noise<25db*



Image: The GOCKERA F01 fan operating quietly in a bedroom setting, emphasizing its low noise level (less than 25dB).

## SETUP

- Unboxing:** Carefully remove the fan, Type-C data cable, and lanyard from the packaging.
- Initial Charge:** Before first use, fully charge the fan. Connect the provided Type-C cable to the fan's charging port and plug the other end into a USB power source (e.g., computer, wall adapter). The digital display will show charging progress. A full charge takes approximately 2.5-3 hours.
- Attach Lanyard (Optional):** If you plan to use it as a neck fan, attach the included lanyard to the designated loop on the fan's handle.

## OPERATING INSTRUCTIONS

- Power On/Off:** Press the power button located on the side of the handle to turn the fan on. Press and hold the button to turn it off.

2. **Adjusting Fan Speed:** Once powered on, the fan will start at speed 1. Press the power button repeatedly to cycle through the 5 available speed settings. The digital display will show the current speed (1-5).
3. **Checking Battery Level:** The digital display continuously shows the remaining battery percentage.
4. **Folding Mechanism:** The fan head can be folded 180 degrees. Gently push or pull the fan head to adjust its angle or fold it completely for compact storage or desk mode.
5. **Using as a Desk Fan:** Fold the fan head back onto its base. Place the fan on a flat surface. The non-slip base ensures stability and can also serve as a mobile phone stand.
6. **Using as a Neck Fan:** Attach the lanyard to the fan and wear it around your neck for hands-free cooling.



Image: The GOCKERA F01 fan being easily stored in a handbag, demonstrating its compact and portable design.



Image: The GOCKERA F01 fan used on a vanity table, providing cooling during makeup application.



Image: The GOCKERA F01 fan used on a desk in an office environment, providing personal cooling while working.



*The perfect summer gift for family and friends*

Image: The GOCKERA F01 fan being used by a person while traveling, highlighting its convenience for on-the-go cooling.

## Maintenance

- **Cleaning:** Ensure the fan is turned off and unplugged before cleaning. Use a soft, dry cloth to wipe the exterior of the fan. Do not use harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to fully charge the battery before storing.

- **Battery Care:** To prolong battery life, avoid completely draining the battery frequently. Recharge the fan when the battery level is low.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	Low or no battery charge.	Charge the fan using the provided Type-C cable.
Weak airflow.	Fan is on a low speed setting.	Press the power button to increase the speed setting.
Digital display is off or not showing correctly.	Battery is completely drained or a temporary glitch.	Charge the fan. If the issue persists, try restarting the fan by turning it off and on again.
Fan makes unusual noise.	Obstruction in the fan blades or internal issue.	Turn off the fan immediately. Check for any obstructions and carefully remove them. If the noise continues, discontinue use and contact customer support.

## SPECIFICATIONS

Feature	Detail
Brand	GOCKERA
Model Name	F01
Color	Blue
Power Source	Battery Powered
Battery Capacity	4200 mAh Lithium Ion (included)
Charging Time	2.5-3 hours
Max Usage Time	20-24 hours (on lowest speed)
Number of Speeds	5
Noise Level	7 dB (minimum) to <25dB (maximum)
Product Dimensions	1.38"D x 3.62"W x 7.67"H
Item Weight	5.1 ounces (145g)
Control Method	Touch
Connector Type	USB Type C
Included Components	Personal fan, Instructions, Type-C cable, Lanyard

## WARRANTY AND SUPPORT

GOCKERA stands behind the quality of its products. For warranty information, technical support, or any inquiries regarding your F01 Portable Fan, please refer to the contact information provided on the product packaging or visit the official GOCKERA website. Please retain your proof of purchase for warranty claims.

© 2024 GOCKERA. All rights reserved.