

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [TenCloud](#) /

› [TenCloud Smart Watch Band for Anyloop ALW7 Instruction Manual](#)

## TenCloud Anyloop ALW7 Smart Watch Band

# TenCloud Smart Watch Band for Anyloop ALW7 Instruction Manual

Model: Anyloop ALW7 Smart Watch Band

## 1. INTRODUCTION

---

This manual provides detailed instructions for the installation, operation, and maintenance of your TenCloud Solid Stainless Steel Smart Watch Band, designed specifically for compatibility with the Anyloop ALW7 smartwatch. Please read this manual thoroughly before use to ensure proper handling and longevity of your watch band.

The TenCloud watch band is crafted from durable solid stainless steel, featuring a double folding clasp for secure wear. It is designed for both men and women, offering a classic and elegant look suitable for various occasions.

**Compatibility:** This watch band is exclusively compatible with the Anyloop ALW7 smartwatch. It is not intended for use with other smartwatch models.

## 2. PACKAGE CONTENTS

---

- 1 x TenCloud Smart Watch Band
- 1 x Link Removal Tool
- 3 x Extra Quick Release Pins
- 1 x Instruction Manual (this document)

*Note: The Anyloop ALW7 smartwatch is not included in this package.*

## 3. SETUP AND INSTALLATION

---

### 3.1 Attaching the Watch Band to Your Smartwatch

The TenCloud watch band uses quick-release pins for easy attachment to your Anyloop ALW7 smartwatch. Follow these steps:

1. Locate the quick-release pins on each end of the watch band.
2. Insert one end of the pin into the lug hole on your smartwatch.

3. Pull the spring lever on the pin inwards, then align the other end of the pin with the opposite lug hole.
4. Release the spring lever to secure the pin in place. Gently tug on the band to ensure it is firmly attached.
5. Repeat for the other side of the watch band.



*Image: The TenCloud Smart Watch Band securely attached to an Anyloop ALW7 smartwatch, illustrating how the quick-release pins connect the band to the watch lugs.*

### **3.2 Adjusting the Band Length**

Your watch band can be adjusted to fit wrist sizes from 5.5 inches to 8.5 inches in circumference. Use the provided link removal tool to customize the length.

1. Place the watch band on the link removal tool with the arrow on the band pointing downwards towards the pin pusher.
2. Align the pin pusher with the pin you wish to remove.
3. Slowly turn the screw on the tool to push the pin out.
4. Remove the desired number of links. Remember to remove an equal number of links from both sides of the clasp for a balanced fit.
5. To reassemble, align the links and insert the pin in the opposite direction of the arrow, gently tapping it back into place if necessary.



*Image: The TenCloud Smart Watch Band in its full length, displaying the individual links that can be removed or added to adjust the band's size.*

## 4. OPERATING THE CLASP

---

The watch band features a double folding clasp for secure and convenient wearing.

1. **To Open:** Press the two small buttons on the sides of the clasp simultaneously. The clasp will release, allowing you to put on or take off the watch.
2. **To Close:** Fold the two parts of the clasp together until you hear a click. Ensure both sides are securely fastened to prevent accidental opening.



*Image: A detailed view of the double folding clasp, highlighting the release buttons on the sides for opening and closing the band.*

## 5. MAINTENANCE AND CARE

---

To maintain the appearance and longevity of your stainless steel watch band, follow these care instructions:

- **Cleaning:** Wipe the band regularly with a soft, damp cloth to remove dirt, sweat, and oils. For deeper cleaning, use a mild soap solution and a soft brush, then rinse thoroughly with clean water and dry immediately.
- **Avoid Harsh Chemicals:** Do not expose the band to harsh chemicals, solvents, or abrasive cleaners, as these can damage the finish.
- **Storage:** When not in use, store the watch band in a clean, dry place, away from direct sunlight and extreme temperatures.
- **Scratch Prevention:** While stainless steel is durable, it can still scratch. Avoid contact with sharp objects or abrasive surfaces.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your watch band, please refer to the following common solutions:

- **Difficulty Attaching Band:** Ensure the quick-release pins are fully retracted and properly aligned with the smartwatch lugs. If pins are bent, use one of the extra pins provided.
- **Difficulty Removing Links:** Ensure the link removal tool's pin pusher is correctly aligned with the band pin and that you are pushing in the direction of the arrow on the band. Apply steady, gentle pressure.
- **Clasp Not Closing Securely:** Check for any debris or obstructions in the clasp mechanism. Ensure both sides of the clasp are fully engaged until a click is heard.

## 7. SPECIFICATIONS

---

<b>Product Name</b>	TenCloud Smart Watch Band
<b>Model Compatibility</b>	Anyloop ALW7 Smartwatch
<b>Material</b>	Solid Stainless Steel
<b>Clasp Type</b>	Double Folding Clasp
<b>Band Length</b>	180 mm (total length)
<b>Wrist Circumference</b>	5.5" - 8.5" (adjustable)

## 8. WARRANTY AND SUPPORT

---

For any questions, concerns, or support regarding your TenCloud Smart Watch Band, please contact TenCloud customer service through the retailer where the product was purchased or visit the official TenCloud store page. Please retain your proof of purchase for warranty claims.

**Manufacturer:** TenCloud

---

