



[Manuals.plus](#) /

> [JIVOIT](#) /

> JIVOIT Rattan TV Stand (Model: TV Stand) Instruction Manual

JIVOIT TV Stand

JIVOIT Rattan TV Stand Instruction Manual

Model: TV Stand

Brand: JIVOIT

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your JIVOIT Rattan TV Stand. Please read this manual thoroughly before assembly and use to ensure safe and correct operation. Keep this manual for future reference.



Image: The JIVOIT Rattan TV Stand in a living room, showcasing its design and capacity for a television.

SAFETY INFORMATION

Important Safety Warnings:

- Do not leave the product unsupervised, especially with children or pets nearby.
- Secure the TV stand to a wall to prevent tipping. Wall anchoring hardware may be required and is often included or recommended for purchase separately.
- Ensure all components are correctly assembled and tightened before use. Periodically check and re-tighten all fasteners.
- Do not exceed the maximum weight capacity for the top panel or drawers.
- Keep small parts and packaging materials away from children to prevent choking hazards.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed in the assembly instruction guide are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

Typically, the package includes:

- Cabinet panels (MDF)
- Solid wood legs and door components
- Metal hardware (screws, connectors, drawer slides)
- Rattan drawer fronts
- Assembly instruction guide
- Necessary tools for assembly (e.g., Allen wrench)

SPECIFICATIONS

Overall Product Dimensions	66.93" (L) x 15.55" (W) x 18.11" (H)
Overall Product Weight	65.26 lbs
Weight Capacity (Overall)	110.23 lbs
Weight Capacity (Drawer)	22.05 lbs
Weight Capacity (Panel)	33.07 lbs
Material	MDF, Solid Wood, Metal, Rattan
Color	Natural Wood + Brown & Rattan
TV Size Compatibility	Up to 75 inches





Image: Dimensional overview of the TV stand, including measurements for overall size and internal compartments.

SETUP AND ASSEMBLY

Assembly is required for this TV stand. Follow the included detailed assembly instruction guide step-by-step. All necessary tools are provided. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out. Verify against the parts list in the instruction guide.
2. **Assemble Frame:** Begin by connecting the main frame components using the provided hardware. Ensure all connections are secure but do not overtighten until the unit is fully assembled.
3. **Install Drawers:** Assemble the drawers according to the instructions. Install the drawer slides onto the cabinet frame and then insert the assembled drawers. The rattan detail should face outwards.
4. **Attach Legs:** Securely attach the solid wood legs to the base of the TV stand.
5. **Install Sliding Doors:** Position and install the sliding doors into their tracks. Test their movement to ensure smooth operation.
6. **Final Tightening:** Once all components are in place, carefully tighten all screws and fasteners.
7. **Wall Anchoring:** For safety, attach the TV stand to a wall using the provided anti-tip hardware. This prevents accidental tipping, especially important in households with children or pets.

EXQUISITE HANDLES



WITH BEAUTIFUL
INTERWOVEN
RATTAN DRAWERS

SOLID WOOD
CABINET LEGS
AND DOORS



Image: Details of the TV stand's construction, including handles, rattan drawers, and solid wood elements.



Image: View of the TV stand with drawers pulled out and sliding doors open, illustrating storage capacity.

OPERATING INSTRUCTIONS

The JIVOIT Rattan TV Stand is designed for convenient storage and display of your media equipment.

- **Placing a TV:** Position your television centrally on the top surface. Ensure the TV base fits securely within the dimensions of the stand. This stand supports TVs up to 75 inches.
- **Using Drawers:** The two central drawers with rattan fronts provide enclosed storage. Pull the wooden knobs to open and push to close.
- **Using Sliding Doors:** The side compartments feature sliding doors. Gently slide the doors left or right to access the storage space behind them.
- **Cable Management:** Utilize the integrated cable holes (if present, typically on the back panel) to route and organize power cords and media cables, keeping them tidy and out of sight.



SMOOTH AND WATERPROOF TABLETOP

Easy-to-maintain tabletop that combines smoothness and waterproof features.

SLIDING DOORS

Conveniently retrieve items with easy-to-open sliding doors.



Image: Features of the TV stand, highlighting the smooth tabletop and sliding door functionality.

MULTIFUNCTIONAL STORAGE

Transform your living space with our Multifunctional TV Cabinet—stylish, space-efficient, enhancing your home entertainment experience.



Image: The TV stand used for multifunctional storage, holding a TV, game console, records, and other items.

MAINTENANCE

To maintain the appearance and longevity of your TV stand:

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Immediately wipe up any spills with a dry or slightly damp cloth to prevent staining or water damage. The tabletop is designed to be waterproof.
- **Inspection:** Periodically inspect all hardware and connections to ensure they remain tight. Re-tighten as necessary.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the wood and rattan components.

TROUBLESHOOTING

If you encounter any issues with your JIVOIT Rattan TV Stand, refer to the following common solutions:

- **Wobbly Stand:** Ensure all screws and fasteners are fully tightened. Check that the stand is on a level surface. Adjust leg levelers if present.
- **Drawers Not Sliding Smoothly:** Check that the drawer slides are correctly installed and free of obstructions. Ensure the drawers are not overloaded.
- **Doors Sticking:** Verify that the sliding door tracks are clean and free of debris. Ensure the doors are properly seated in their tracks.
- **Missing Parts:** If parts were missing upon delivery, do not attempt to substitute with non-original parts. Contact customer support for replacements.

CUSTOMER SUPPORT

For further assistance, missing parts, or warranty inquiries, please contact JIVOIT customer support. Refer to your purchase documentation for specific contact details or visit the official JIVOIT website.

When contacting support, please have your model number (TV Stand) and ASIN (B0CSDQZFLP) ready.