



Manuals.plus /

› CHEF iQ /

› CHEF iQ Smart Wireless Meat Thermometer Replacement Hub (2 Probe Hub) - Instruction Manual

## CHEF iQ CQ60-2-SET-V2

# CHEF iQ Smart Wireless Meat Thermometer Replacement Hub (2 Probe Hub) - Instruction Manual

## INTRODUCTION

---

This manual provides comprehensive instructions for the setup, operation, and maintenance of your CHEF iQ Smart Wireless Meat Thermometer Replacement Hub. This hub is designed to seamlessly integrate with your existing CHEF iQ Probes (not included) to expand your cooking capabilities, allowing you to monitor multiple food items simultaneously.

The CHEF iQ Smart Wireless Meat Thermometer Hub is compatible with CHEF iQ Probes and connects to your smart device via Bluetooth, providing real-time temperature monitoring and cooking guidance through the CHEF iQ app.

## WHAT'S IN THE BOX

---

Your CHEF iQ Smart Wireless Meat Thermometer Replacement Hub package includes:

- 1 x CHEF iQ Smart Wireless Meat Thermometer 2 Probe Hub
- 1 x USB Charging Cable (Type-C to Type-A)
- 1 x Quick Start Guide
- 1 x Safety Guide

*Note: CHEF iQ Probes are not included with this replacement hub.*



Image: The CHEF iQ Smart Wireless Meat Thermometer 2 Probe Hub, a sleek black oval device with a clear top cover, designed to hold and charge two meat probes. The hub features a power button and charging port.



Image: A black USB charging cable with a USB-A connector on one end and a USB-C connector on the other, coiled neatly.

## SETUP

---

### 1. Initial Charging

Before first use, fully charge your CHEF iQ Hub. Connect the USB-C end of the charging cable to the hub's charging port and the USB-A end to a compatible USB power adapter (not included). The power indicator light on the hub will illuminate to show charging status.

For optimal performance, charge the hub for at least 3 hours before its first use.

### 2. Downloading the CHEF iQ App

Download the free CHEF iQ App from the Apple App Store (for iOS devices) or Google Play Store (for Android devices). Search for "CHEF iQ" and install the application on your smart device.

### 3. Pairing the Hub with Your Smart Device

Ensure your CHEF iQ Hub is charged and powered on. Open the CHEF iQ App on your smart device. Follow the on-screen prompts to connect your hub via Bluetooth. The app will guide you through the pairing process. Once connected, the app will display the hub's status and allow you to manage your probes.

Your browser does not support the video tag.

Video: This video demonstrates the unboxing, charging, and app pairing process for the CHEF iQ Smart Thermometer. It shows how to connect the hub to power, download the app, and establish a Bluetooth connection for initial setup and firmware updates.

## OPERATING INSTRUCTIONS

---

### 1. Inserting Probes

Carefully insert your CHEF iQ Probes (sold separately) into the designated slots on the hub. Ensure they are seated correctly for charging and recognition by the app.

### 2. Monitoring Temperature

Once probes are inserted into your food and the hub is connected to the app, you can monitor real-time internal and ambient temperatures. The app provides intuitive graphs and estimated cooking times.

### 3. Cooking Guidance

The CHEF iQ App offers chef-tested guides and recipes for various meats and doneness levels. Select your food type, thickness, and desired doneness, and the app will provide step-by-step instructions, including when to flip or remove food from heat.

The hub also features an integrated speaker that provides audible alerts and notifications, allowing you to monitor your cooking even when your smart device is not immediately accessible.

## MAINTENANCE

---

### Cleaning the Hub

To clean the hub, wipe it with a damp cloth. Do not submerge the hub in water or other liquids. Ensure the hub is completely dry before storing.

### Cleaning the Probes

CHEF iQ Probes are waterproof and dishwasher-safe. For best results, hand wash probes with warm, soapy water, rinse, and dry them thoroughly after each use. Ensure probes are completely dry before storing them in the hub.

## TROUBLESHOOTING

---

### Connectivity Issues

- Ensure the hub is fully charged.
- Verify Bluetooth is enabled on your smart device.
- Make sure the hub is within range of your smart device.
- Restart the CHEF iQ App and attempt to reconnect.
- If issues persist, try unpairing and re-pairing the hub through the app's settings.

### Inaccurate Temperature Readings

- Ensure probes are inserted correctly into the thickest part of the food, avoiding bones or gristle.
- Verify that the thinner portion of the probe is fully inserted into the food and not visible.
- Clean probes thoroughly after each use to prevent residue buildup that could affect accuracy.

## SPECIFICATIONS

---

<b>Feature</b>	<b>Detail</b>
Brand	CHEF iQ
Model Name	CQ60-2-SET-V2
Connectivity Technology	Bluetooth
Power Source	Battery Powered
Outer Material	Plastic
Product Care Instructions	Wipe Clean
Item Length	6.24 Inches

## **WARRANTY & SUPPORT**

The CHEF iQ Smart Wireless Meat Thermometer Replacement Hub comes with a standard manufacturer's warranty. For detailed warranty information, product support, or to purchase additional probes, please visit the official CHEF iQ website or contact their customer service.

For additional probes, search for B0B52JJWXJ (Probe #2) and B0B52HQTDN (Probe #3).