

[Manuals.plus](#) /

> [Prinsel](#) /

> [Prinsel Cuna Colecho Baby Crib and Co-sleeper \(Model B0CSDYK1QZ\) Instruction Manual](#)

## Prinsel B0CSDYK1QZ

# Prinsel Cuna Colecho Baby Crib and Co-sleeper (Model B0CSDYK1QZ) Instruction Manual

Your guide to safe and effective use of your Prinsel Cuna Colecho.

## INTRODUCTION

---

This Prinsel Cuna Colecho is a versatile baby crib designed for comfort and convenience. It features a reinforced structure and an umbrella-fold system for quick assembly. This unit functions as a crib, a co-sleeper with four adjustable levels, and a rocking bassinet. It includes a padded base and wheels for easy mobility.

Key features include:

- Umbrella-fold system for quick assembly.
- Travel bag for convenient portability.
- No tools required for assembly.
- Easily detachable second level.
- Movable side rail for co-sleeping functionality.



Image: The Prinsel Cuna Colecho in full crib mode with the mosquito net installed, showcasing its design and features.

## SAFETY INFORMATION

---

Always prioritize your child's safety. Ensure the crib is assembled and used in a stable and secure manner, strictly following the manufacturer's instructions for assembly and maintenance. Regularly inspect all components for damage or wear.

## SETUP AND ASSEMBLY

---

The Prinsel Cuna Colecho is designed for quick and tool-free assembly using its umbrella-fold system.

1. **Unfold the Frame:** Remove the crib from its travel bag. Stand the folded crib upright and pull the short sides upwards until they lock into place.
2. **Lock Long Sides:** Once the short sides are locked, pull the long sides upwards until they also lock securely. Ensure all four top rails are rigid and locked.
3. **Secure the Base:** Push down the center base of the crib firmly until it lies flat and is fully secured. If the sides do not lock, lift the center base slightly and try locking the sides again.

4. **Install Padded Base:** Place the provided padded base into the crib.
5. **Attach Second Level (Optional):** If using the elevated second level for infants, attach it according to the instructions provided in the packaging, ensuring all clips or zippers are securely fastened.
6. **Mosquito Net Installation (Optional):** Attach the mosquito net frame to the designated points on the crib and drape the net over.



Image: Front view of the Prinsel Cuna Colecho, highlighting the decorative elephant design and mesh side panels.

## OPERATING INSTRUCTIONS

## Crib Mode

In standard crib mode, ensure all side rails are locked in the upright position. The padded base should be securely in place. Always use the crib on a flat, stable surface.

## Co-sleeper Mode

To use the co-sleeper function, lower the movable side rail. Adjust the crib height to one of the four available levels to match the height of your adult bed. Securely position the crib next to your bed, ensuring there are no gaps between the crib and the mattress of your bed.



Image: Side view of the Prinsel Cuna Colecho, illustrating the breathable mesh panel and the mechanism for height adjustment, essential for co-sleeping.

## Rocking Mode

To engage the rocking function, ensure the wheels are retracted or locked. Activate the rocking bars located at the base of the crib. This allows for a gentle, soothing rocking motion.



Image: The Prinsel Cuna Colecho without the mosquito net, clearly showing the rocking bars at the base for gentle motion.

### **Mobility**

The crib is equipped with wheels for easy movement. To move the crib, unlock the wheels. To keep the crib stationary, ensure the wheels are locked.



Image: Back view of the Prinsel Cuna Colecho, featuring a convenient storage pocket for essentials.

## MAINTENANCE

- **Regular Inspection:** Before each use, inspect all parts, including the frame, fabric, and locking mechanisms, for any signs of wear, damage, or loose components.
- **Cleaning:** Clean fabric components with a mild soap and water solution. Do not use harsh chemicals or abrasive cleaners. Allow all parts to air dry completely before reassembly or storage.
- **Second Level:** The second level is designed to be easily detached for cleaning or when transitioning to the lower crib position.
- **Storage:** When not in use, fold the crib using the umbrella-fold system and store it in its travel bag in a dry, safe place.

## TROUBLESHOOTING

- **Difficulty Assembling/Disassembling:** If the crib is difficult to assemble or disassemble, ensure the center base is fully raised before attempting to fold the sides, and fully lowered to lock the sides in place during assembly. Sometimes, lifting the center slightly can help release side mechanisms.

- **Instability:** If the crib feels unstable, recheck all connections and locking mechanisms to ensure they are fully engaged. Ensure the crib is placed on a flat, level surface.
- **Rocking Mechanism Not Engaging:** Verify that the rocking bars are properly extended and that the wheels are retracted or locked to allow for rocking motion.

## SPECIFICATIONS

---

- **Shape:** Rectangular
- **Item Depth:** 100 centimeters
- **Material:** Alloy Steel (Frame: Aluminum structure)
- **Manufacturer:** Prinsel
- **Maximum Weight Recommendation:** 18 Kilograms
- **Batteries Required:** No
- **Package Dimensions:** 77 x 24 x 23 cm; 10.52 kg
- **ASIN:** B0CSDYK1QZ
- **Color:** Unisex
- **Size:** Crib
- **Style:** Modern
- **Assembly Required:** Yes

## WARRANTY AND SUPPORT

---

For warranty information, customer service, or to purchase replacement parts, please refer to the documentation included with your original purchase or visit the official Prinsel website. Keep your purchase receipt as proof of purchase for warranty claims.