

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Heiniger](#) /

› [Heiniger Wide Pet Grooming Guard Attachment \(16mm\) Instruction Manual](#)

Heiniger 707-703

Heiniger Wide Pet Grooming Guard Attachment Instruction Manual

Model: 707-703

PRODUCT OVERVIEW

The Heiniger Wide Pet Grooming Guard Attachment is designed to enhance grooming precision, providing consistent and uniform cuts. This attachment is crafted from high-quality stainless steel for durability and features a robust yellow plastic mounting system for secure attachment. It is intended for use with compatible professional clippers to achieve desired coat lengths.



Image: Heiniger Wide Pet Grooming Guard Attachment. This image displays the guard attachment, highlighting its stainless steel comb and yellow plastic base.

SETUP INSTRUCTIONS

- 1. Compatibility Check:** Ensure your clipper is equipped with an A5 detachable #30 WIDE blade or an A5 detachable #10 WIDE blade. This guard attachment is specifically designed to fit over these wide blade types.
- 2. Blade Preparation:** Before attaching the guard, ensure your clipper blade is clean and properly oiled according to your clipper's instructions.
- 3. Attaching the Guard:** Align the Heiniger Wide Pet Grooming Guard Attachment with the teeth of the clipper blade. Gently slide the guard over the blade until it clicks securely into place. Ensure the guard is firmly seated and does not wobble.
- 4. Verification:** Once attached, lightly tug on the guard to confirm it is securely fastened to the blade. A properly attached guard will not easily detach.



Image: Attaching the Heiniger Wide Pet Grooming Guard Attachment. This image illustrates the process of sliding the yellow guard attachment onto a clipper blade.

OPERATING INSTRUCTIONS

This guard attachment provides a precise 5/8 inch (16mm) cut length, ensuring consistent and even grooming results across the animal's coat.

- 1. Coat Preparation:** Ensure the animal's coat is clean, dry, and free of tangles or mats before grooming. Brushing the coat thoroughly will help achieve a smoother cut.
- 2. Grooming Technique:** Hold the clipper with the attached guard flat against the animal's skin. Move the clipper smoothly and steadily in the direction of hair growth. Avoid pressing too hard, as this can cause uneven cuts or discomfort.
- 3. Consistent Strokes:** Use overlapping strokes to ensure all areas of the coat are trimmed evenly. The wide design of the comb attachment helps cover more surface area efficiently.
- 4. Monitoring:** Periodically check the blade and guard for hair buildup, which can affect cutting performance. Turn off the clipper before clearing any obstructions.



Image: Heiniger Wide Pet Grooming Guard Attachment during grooming. This image depicts the guard attachment being used on a pet's coat, demonstrating proper technique.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Heiniger Wide Pet Grooming Guard Attachment.

- 1. Cleaning After Each Use:** After each grooming session, remove the guard attachment from the clipper blade. Use a small brush to remove any trapped hair from both the guard and the clipper blade.
- 2. Washing:** The stainless steel construction of the guard attachment allows for easy cleaning. You may rinse the guard under running water to remove fine hair and debris. Ensure to dry it thoroughly immediately after washing to prevent water spots or mineral buildup.
- 3. Drying:** Use a clean, dry cloth to wipe down the guard. Allow it to air dry completely before storing. The stainless steel composition resists rust and corrosion, but proper drying is still recommended.
- 4. Storage:** Store the guard attachment in a clean, dry place, away from direct sunlight and extreme temperatures. Keeping it in its original packaging or a protective case can prevent damage.



Image: Cleaning the Heiniger Wide Pet Grooming Guard Attachment. This image shows the guard attachment being rinsed under water, emphasizing its easy-to-clean design.

TROUBLESHOOTING

- **Guard Not Attaching Securely:** Ensure the clipper blade is correctly installed and that you are using a compatible A5 #30 WIDE or #10 WIDE blade. Check for any debris obstructing the attachment mechanism on both the guard and the blade.
- **Uneven Cut:** This can be caused by an improperly cleaned or oiled blade, dull blades, or incorrect grooming technique. Ensure the animal's coat is clean and tangle-free. Move the clipper smoothly and consistently against the direction of hair growth for best results.
- **Hair Snagging:** If hair is snagging, the blade might be dull, or there might be hair buildup between the blade and the guard. Clean the blade and guard thoroughly. Consider replacing the clipper blade if it is old or damaged.

SPECIFICATIONS

- **Model Name:** Widce Clip Comb #5
- **Item Model Number:** 707-703

- **Brand:** Heiniger
- **Blade Material:** Stainless Steel
- **Cut Length:** 5/8 inch (16mm)
- **Compatibility:** A5 detachable #30 WIDE blade or #10 WIDE blade
- **Item Weight:** 3.52 ounces (0.1 Kilograms)
- **Item Package Dimensions:** 2.76 x 2.76 x 1.18 inches
- **Included Components:** Wide Guard Attachment
- **Specific Uses:** Animal Hair Cutting, Pet Grooming

WARRANTY INFORMATION

This product does not include a manufacturer's warranty. Please refer to the retailer's return policy for any issues upon purchase.

SUPPORT

For further assistance or inquiries regarding your Heiniger Wide Pet Grooming Guard Attachment, please contact the retailer from whom you purchased the product. They can provide guidance on product usage, returns, or direct you to appropriate support channels.