

Thule 10101978

Thule Urban Glide 3 Double Stroller Instruction Manual

Model: 10101978

1. Introduction

Welcome to the Thule Urban Glide 3 Double Stroller instruction manual. This guide provides essential information for the safe and effective use, assembly, maintenance, and troubleshooting of your stroller. Please read this manual thoroughly before using the product and retain it for future reference.

The Thule Urban Glide 3 Double Stroller is designed as a full-size, all-terrain solution for transporting two children, suitable for both newborns (with compatible accessories) and toddlers. It features a full-suspension system, air-filled tires, and an upright seat with adjustable recline and built-in legrest, ensuring a comfortable experience across various terrains.

2. Safety Information

Always prioritize the safety of your children. Adhere to all warnings and instructions provided in this manual.

- Ensure both children are properly secured with the padded, secure 5-point harness system in each seat.
- Always engage the integrated twist hand brake when the stroller is stationary to prevent unintended movement.
- Do not exceed the maximum weight recommendation of 49 pounds per child (100 pounds total for both children).
- This stroller can be used from birth with a compatible Thule Bassinet or Infant Car Seat Adapter (sold separately). Ensure proper installation of all accessories.
- The large canopy with full coverage and ventilation is designed for comfort and sun protection.
- Regularly inspect the stroller for any loose parts, damage, or wear before each use.

3. Components

Familiarize yourself with the main components of your Thule Urban Glide 3 Double Stroller:

- **Frame:** Lightweight aluminum frame providing stability and durability.
- **Wheels:** Two large 16-inch air-filled rear wheels and a 12-inch air-filled swivel front wheel for all-terrain maneuverability.
- **Handlebar:** Foam-covered, ergonomic, and adjustable for comfortable pushing by users of varying heights.
- **Seats:** Two independent, padded seats with adjustable recline and built-in legrests. Each seat includes a

5-point harness and mesh side pockets.

- **Canopies:** Two independent large canopies with pop-out sun visors for ample coverage and ventilation.
- **Storage Basket:** A large, water-resistant storage compartment with a zippered lid located underneath the seats.
- **Suspension System:** Rear wheel suspension to absorb shocks and provide a smooth ride.
- **Brake System:** Integrated twist hand brake for speed control and a foot-operated parking brake.



Figure 3.1: Front view of the Thule Urban Glide 3 Double Stroller.



Figure 3.2: Close-up view of the large, water-resistant storage basket with zippered lid.

4. Setup

Follow these steps to set up your Thule Urban Glide 3 Double Stroller:

- 1. Unfolding the Stroller:** The stroller features a one-hand unfold mechanism. Ensure the manual strap lock is disengaged. Lift the handlebar and allow the frame to extend until it locks into place.
- 2. Attaching Wheels:** If not pre-attached, slide the rear wheels onto their axles until they click securely. The front wheel can be attached by aligning it with the front fork and pushing it into place.
- 3. Adjusting the Handlebar:** The ergonomic handlebar is adjustable. Locate the adjustment buttons on the sides of the handlebar and press them to raise or lower the handle to your desired height. Release the buttons to lock it in position.
- 4. Locking the Front Wheel:** For jogging or rough terrain, the front swivel wheel can be locked straight. Locate the blue knob near the front wheel and rotate it to engage the lock. Unlock for everyday maneuverability.



Figure 4.1: Adjusting the ergonomic handlebar for user comfort.

5. Operating

Instructions for daily use of your stroller:

- 1. Securing Your Child:** Place your child in the seat. Fasten the 5-point harness by connecting the shoulder and waist straps into the buckle. Adjust the straps to ensure a snug and secure fit.

2. **Reclining the Seat:** Each seat features a one-handed strap recline system. To recline, squeeze the buckle on the strap behind the seat and gently lower the seatback. To raise, pull the strap upwards. The deep recline is suitable for naps.
3. **Using the Canopy:** Extend the large canopy to provide shade and protection. The pop-out sun visor offers additional coverage.
4. **Braking:** The integrated twist hand brake on the handlebar provides smooth speed control, especially useful on inclines or during jogging. To engage the parking brake, press down on the foot-operated lever located near the rear wheels until it clicks. Ensure the brake is fully engaged before releasing the stroller.
5. **Folding the Stroller:** The stroller features an easy one-hand compact fold with a self-stand feature. Locate the blue handle near the footrest. Slide it over and twist to initiate the fold. The stroller will collapse into a compact, standing position. For transport, you can use the manual strap lock to keep it securely folded.



Figure 5.1: The stroller in its compact, folded position.

6. Maintenance

Proper maintenance ensures the longevity and safety of your stroller:

- **Cleaning:** Clean the fabric parts with a damp cloth and mild soap. The aluminum frame can be wiped clean with a soft cloth. Avoid harsh chemicals.
- **Tires:** The air-filled tires require regular inflation. Check tire pressure periodically and inflate to the recommended PSI (refer to tire sidewall for details). Inspect tires for punctures or excessive wear.
- **Moving Parts:** Lubricate moving parts such as wheel axles and folding mechanisms periodically with a silicone-based lubricant to ensure smooth operation.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight when not in use.

7. Troubleshooting

Common issues and their potential solutions:


- **Stroller difficult to fold/unfold:** Ensure all locks are disengaged. Check for any obstructions in the folding mechanism. Lubricate moving parts if necessary.
- **Wheels not swiveling smoothly:** Check if the front wheel lock is engaged. Clean any debris from around the wheel mechanism. Lubricate the swivel joint.
- **Brake not engaging/disengaging:** Inspect the brake cable for damage or kinks. Ensure no debris is obstructing the brake mechanism.

- **Uneven ride:** Check tire pressure on all wheels. Ensure the suspension system is free of obstructions.

8. Specifications

Brand	Thule
Model Number	10101978
Color	Black
Material	Aluminum (Frame), Polyester (Fabric), Rubber (Tires)
Age Range Description	Baby
Maximum Weight Recommendation	49 Pounds per child
Seating Capacity	2
Item Dimensions (L x W x H)	48.8"L x 31.1"W x 44.5"H
Folded Size (W x D x H)	34.6"W x 31.1"D x 13.4"H
Item Weight	16 Kilograms (approx. 35.3 lbs)
Front Wheel Diameter	16 Inches
Back Wheel Diameter	16 Inches
Harness Type	5 Point
Is Car Seat Compatible	Yes (with adapter, sold separately)
Manufacturer Warranty	Limited Lifetime

Dimensions:



Stroller weight: 35.3 lbs

Max child weight: 49 lbs (each)

Max stroller capacity 100 lbs

Figure 8.1: Detailed dimensions of the Thule Urban Glide 3 Double Stroller.

9. Warranty and Support

Thule offers a Limited Lifetime Manufacturer Warranty for the Urban Glide 3 Double Stroller, covering defects in materials and workmanship. For detailed warranty terms and conditions, please refer to the official Thule website or contact customer support.

For any questions, technical assistance, or warranty claims, please contact Thule Customer Support. You can find contact information on the official Thule website or through your retailer.

Note: This manual is for informational purposes only. Always refer to the latest official documentation from Thule for the most up-to-date information and safety guidelines.