

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [IKG](#) /
- › [IKG Portable Bluetooth Speaker M9 User Manual](#)

IKG M9

IKG Portable Bluetooth Speaker M9 User Manual

Model: M9 | Brand: IKG

[Introduction](#)

[What's in the Box](#)

[Features](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

Thank you for purchasing the IKG Portable Bluetooth Speaker M9. This manual provides detailed instructions on how to set up, operate, and maintain your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product and retain it for future reference.



Image: The IKG Portable Bluetooth Speaker M9, showcasing its sleek black design and water splash resistance.

2. WHAT'S IN THE BOX

Please check the package contents upon unboxing to ensure all items are present:

- IKG Portable Bluetooth Speaker (Model M9)
- USB-C Charging Cable
- Instruction Manual

3. KEY FEATURES



Astonishing Stereo Sound

The speaker utilizes TWS technology and two 10W high-sensitivity drivers to deliver true double-enhanced stereo surround sound with deep bass, ensuring exceptionally clear audio with zero distortion.

Image: A detailed view of the speaker's internal components, highlighting the drivers responsible for 20W loud stereo sound.



IPX7 Waterproof Rating

An IPX7-rated enclosure provides robust waterproof protection, and silicone port covers enhance airtightness, making the speaker resistant to rain and splashes. Ideal for outdoor use.


Image: The IKG speaker positioned outdoors in light rain, demonstrating its IPX7 waterproof capability.



Extended 24-Hour Playtime

Equipped with a high-efficiency 2600mAh Li-Ion battery, the speaker offers up to 24 hours of continuous playback on a single charge. A low battery indicator signals when recharging is needed, which takes approximately 3 hours via USB-C.

Image: The speaker alongside icons representing its 2600mAh battery and Type-C fast charging capability, emphasizing its long playtime.



Versatile Four Play Modes

The speaker supports multiple audio input options: Bluetooth mode, TF card mode, 3.5mm AUX input mode, and USB mode. This versatility allows adaptation to various scenarios, including home use, bathing, parties, outdoor activities, or travel.

Image: The speaker displayed with icons representing its four play modes: Bluetooth, TF Card, Aux-in Cable, and USB Mode.



Dynamic RGB Colored Lights

Enhance your listening experience with unique night-time themed lights. Cycle through 5 different theme colors by pressing the on/off button. Lights can be turned off or adjusted to complement the party atmosphere.

Image: The speaker emitting vibrant RGB lights in a low-light setting with people in the background, illustrating its party ambiance feature.



Bluetooth 5.3 and TWS Pairing

Equipped with an advanced Bluetooth 5.3 chip, the speaker offers faster pairing, stable connections, and an extended wireless range of up to 50 feet. True Wireless Stereo (TWS) technology allows you to connect two M9 speakers for an immersive, enhanced stereo sound experience.

Image: Two IKG speakers wirelessly connected, demonstrating the TWS pairing feature for a wider stereo soundstage.

4. SETUP GUIDE

4.1 Charging the Speaker

1. Locate the USB-C charging port on the speaker.
2. Connect the provided USB-C charging cable to the speaker's port.
3. Connect the other end of the USB-C cable to a compatible USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate during charging and turn off when fully charged. A full charge takes approximately 3 hours.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button () for 2-3 seconds until you hear an audible prompt and the

indicator lights illuminate.

- **To Power Off:** Press and hold the Power button () for 2-3 seconds until you hear an audible prompt and the indicator lights turn off.

4.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a blinking blue light). If not, briefly press the 'M' (Mode) button to switch to Bluetooth mode.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "IKG M9" from the list of found devices.
4. Once paired, you will hear a confirmation sound, and the blue indicator light will become solid.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device is within range and Bluetooth is enabled.

4.4 True Wireless Stereo (TWS) Pairing

To achieve a true stereo sound experience, you can pair two IKG M9 speakers together:

1. Ensure both IKG M9 speakers are powered on and not connected to any Bluetooth device.
2. On one of the speakers (this will be the primary speaker), double-press the Power button (). You will hear a prompt indicating it's searching for another speaker.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation sound.
4. Now, connect your device to the primary speaker via Bluetooth as described in Section 4.3. The audio will play through both speakers in stereo.



Image: Two IKG M9 speakers wirelessly connected to a laptop, illustrating the True Wireless Stereo (TWS) pairing setup.

5. OPERATING INSTRUCTIONS

5.1 Button Functions

Button	Function
--------	----------

Button	Function
(Power Button)	Press and hold for 2-3 seconds: Power On/Off Double-press (in Bluetooth mode, not connected): Initiate TWS Pairing (primary speaker) Single press: Change RGB light mode (5 modes + off)
▶ (Play/Pause Button)	Single press: Play/Pause music Single press (during incoming call): Answer/End call Press and hold: Reject incoming call
+ (Volume Up / Next Track)	Single press: Increase volume Press and hold: Next track
- (Volume Down / Previous Track)	Single press: Decrease volume Press and hold: Previous track
M (Mode Button)	Single press: Switch between Bluetooth, TF Card, AUX, and USB modes.

5.2 Using Different Play Modes

- **Bluetooth Mode:** (Default) Follow Section 4.3 for pairing.
- **TF Card Mode:** Insert a TF (microSD) card with audio files into the designated slot. The speaker will automatically switch to TF card mode and begin playback. If not, press the 'M' button.
- **AUX Input Mode:** Connect an audio device using a 3.5mm AUX cable (not included) to the speaker's AUX port. The speaker will automatically switch to AUX mode. If not, press the 'M' button.
- **USB Mode:** Insert a USB flash drive with audio files into the USB port. The speaker will automatically switch to USB mode and begin playback. If not, press the 'M' button.

5.3 RGB Light Control

The speaker features dynamic RGB lighting. To cycle through the light modes or turn them off, single-press the Power button ().

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. For stubborn dirt, a slightly damp cloth can be used, but ensure no water enters the ports. Do not use abrasive cleaners or solvents.
- **Water Resistance:** While IPX7 waterproof, avoid prolonged submersion. Ensure the silicone port covers are securely closed before exposing the speaker to water. After exposure to water, wipe the speaker dry before charging.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to about 50% every few months to preserve battery life.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge the speaker regularly to maintain battery health.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker for at least 30 minutes.
No sound from speaker.	Volume too low; Incorrect mode; Device not connected.	Increase speaker and device volume; Press 'M' to select correct mode; Re-pair Bluetooth or check cable connection.
Bluetooth pairing fails.	Speaker not in pairing mode; Device Bluetooth off; Too far from device.	Ensure speaker is blinking blue; Turn on device Bluetooth; Move speaker closer to device (within 50 feet); Forget "IKG M9" on device and re-pair.
TWS pairing fails.	Speakers already connected to a device; Too far apart.	Disconnect both speakers from any Bluetooth devices; Ensure speakers are within close proximity (e.g., 1-2 meters) during TWS pairing.
Sound distortion.	Volume too high; Low battery; Interference.	Reduce volume; Charge speaker; Move away from other electronic devices.
Lights not working.	Lights turned off.	Single-press the Power button () to cycle through light modes.

8. SPECIFICATIONS

Feature	Detail
Model Name	M9
Brand	IKG
Speaker Type	Outdoor
Connectivity Technology	Bluetooth 5.3, USB, Auxiliary, TF Card
Wireless Range	Up to 15 meters (50 feet)
Audio Output Mode	Stereo
Speaker Maximum Output Power	20 Watts (2*10W)
Battery Capacity	2600mAh Li-Ion
Playtime	Up to 24 hours (varies with volume and light usage)
Charging Time	Approximately 3 hours
Water Resistance Level	IPX7
Special Features	Built-in Microphone, Portable, RGB Colored Light, TWS Pairing

Feature	Detail
Product Dimensions	3"D x 3"W x 6.7"H
Item Weight	0.004 ounces (approx. 0.1 grams)
Material	Plastic
Included Components	Bluetooth speaker, USB-C Charging Cable, instruction manual

9. WARRANTY & SUPPORT

9.1 Warranty Information

The IKG Portable Bluetooth Speaker M9 comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the warranty period and coverage details. This warranty typically covers manufacturing defects but does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

9.2 Customer Support

If you encounter any issues or have questions regarding your IKG M9 speaker that are not addressed in this manual, please contact IKG customer support. For the most up-to-date contact information, please visit the official IKG website or refer to the contact details provided on your product packaging or purchase receipt.

You can also visit the [IKG Store on Amazon](#) for more product information and support resources.

