

vidaXL 836726

vidaXL Sideboard Instruction Manual

Model: 836726

1. INTRODUCTION

Thank you for purchasing the vidaXL Sideboard. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

This sideboard features a grey sonoma engineered wood construction with glass shelves and integrated LED lighting, designed for indoor use.

2. SAFETY INFORMATION

- **Read all instructions:** Ensure you understand all assembly steps before proceeding.
- **Adult assembly required:** This product should be assembled by adults.
- **Use appropriate tools:** Ensure you have the correct tools for assembly.
- **Wall mounting:** For stability and safety, it is highly recommended to secure the sideboard to a wall using appropriate fixtures. Wall/ceiling fixtures (e.g., specific screws or wall plugs) are **not included** and must be selected based on your wall material. Consult a professional if unsure.
- **Weight limits:** Do not overload shelves. Distribute weight evenly.
- **Children safety:** Keep small parts away from children during assembly. Do not allow children to climb on or play with the sideboard.
- **Electrical safety (LED):** Ensure the USB power source for the LED lights is appropriate and used in a dry environment. Do not expose LED components to water.

3. PACKAGE CONTENTS

Please verify that all components are present before starting assembly. If any parts are missing or damaged, contact vidaXL customer support.

- Engineered wood panels (top, bottom, sides, back, internal dividers)
- Glass shelves (quantity as per design)
- Assembly hardware (screws, dowels, connectors, shelf pins)
- LED light strip with controller and USB cable
- Instruction manual

4. SETUP AND ASSEMBLY

Recommended Number of People for Assembly: 1

Lay out all components on a soft, clean surface to prevent scratches. Follow the numbered steps in the included assembly diagram.

1. **Identify Components:** Match each panel and hardware piece to the corresponding labels in the assembly diagram.
2. **Assemble Frame:** Connect the side panels to the bottom and top panels using the provided dowels and screws. Ensure all connections are secure.
3. **Install Back Panel:** Secure the back panel to the assembled frame.
4. **Insert Shelf Pins:** Place the shelf pins into the pre-drilled holes at your desired height for the glass shelves.
5. **Place Glass Shelves:** Carefully slide the glass shelves onto the installed shelf pins. Ensure they are seated securely.
6. **Install LED Strip:** Attach the LED light strip along the designated area, typically along the back edge of the interior, ensuring the adhesive is firm. Connect the LED strip to the controller and then to the USB cable.
7. **Position Sideboard:** Move the assembled sideboard to its final location.
8. **Secure to Wall (Recommended):** Use appropriate wall mounting hardware (not included) to secure the sideboard to the wall. This prevents tipping and ensures stability.




Figure 1: Detailed diagram illustrating the overall dimensions of the sideboard (Width: 41 cm / 16.1 inches, Depth: 37 cm / 14.6 inches, Height: 67 cm / 26.4 inches) and internal shelf spacing.



Figure 2: Close-up of the sideboard's interior, highlighting the placement of the glass shelves and the integrated LED light strip along the back edge, with wiring visible.

5. OPERATING INSTRUCTIONS (LED LIGHTS)

The integrated LED lighting system enhances the aesthetic of your sideboard. It is powered via a USB connection.

1. **Connect Power:** Plug the USB connector into a compatible USB power source (e.g., a USB wall

adapter, computer USB port, or power bank).

2. **Use Controller:** The inline controller allows you to adjust the lighting.

- **MODE/DEMO:** Press to cycle through different lighting modes and effects.
- **SPEED:** Adjust the speed of dynamic lighting effects.
- **COLOR:** Change the color of the LED lights.



Figure 3: The flexible LED light strip, designed for installation within the sideboard.



Figure 4: The inline RGB LED controller, featuring buttons to adjust lighting mode, speed, and color settings.



Figure 5: The USB connector used to power the LED lighting system.

6. MAINTENANCE

- **Cleaning Wood Surfaces:** Wipe engineered wood surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that can damage the finish. Dry immediately with a clean cloth.
- **Cleaning Glass Shelves:** Use a standard glass cleaner and a soft, lint-free cloth.
- **Dusting:** Regularly dust all surfaces with a dry, soft cloth.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.
- **Check Connections:** Periodically check all screws and fittings to ensure they remain tight. Retighten as necessary.
- **LED Care:** Do not attempt to disassemble the LED strip or controller. If the LED lights malfunction, contact customer support.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Sideboard is wobbly/unstable	Loose screws or uneven floor. Not secured to wall.	Check and tighten all assembly screws. Ensure the sideboard is on a level surface. Secure the sideboard to the wall using appropriate hardware.
LED lights do not turn on	No power, loose connection, or faulty component.	Ensure the USB cable is securely plugged into a working power source. Check all connections between the LED strip, controller, and USB cable. Try a different USB power source. If issues persist, contact customer support.
LED remote control not working	Controller malfunction.	Ensure the controller is properly connected. If the controller is integrated into the cable, ensure the buttons are pressed firmly.
Glass shelves are difficult to insert	Shelf pins not aligned or inserted correctly.	Ensure shelf pins are fully inserted and aligned horizontally. Do not force glass shelves; gently guide them into place.

8. SPECIFICATIONS

- **Brand:** vidaXL
- **Model Number:** 836726
- **Color:** Grey Sonoma
- **Material:** Engineered wood, Glass
- **Finish:** Matte
- **Dimensions (W x D x H):** 41 cm x 37 cm x 67 cm (16.1 in. x 14.6 in. x 26.4 in.)
- **Item Weight:** Approximately 15.64 kg (34.4 lbs)
- **Mounting Type:** Floor Mount (Wall mounting recommended for stability)
- **Assembly Required:** Yes
- **Power Source (LED):** USB (5V)
- **Indoor/Outdoor:** Indoor Only

9. WARRANTY AND SUPPORT

For warranty information, missing parts, or technical support, please refer to the vidaXL website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

vidaXL Customer Service: Please visit the official vidaXL website for contact details and support resources.