



[Manuals.plus](#) /

› [EROMMY](#) /

› [EROMMY 11' x 13' Louvered Pergola Instruction Manual](#)

EROMMY 11x13 Louvered Pergola

EROMMY 11' x 13' Louvered Pergola Instruction Manual

Model: 11x13 Louvered Pergola

1. INTRODUCTION

Thank you for choosing the EROMMY 11' x 13' Louvered Pergola. This product is designed to enhance your outdoor living space with its adjustable louvered roof, durable aluminum frame, and integrated curtains and netting. This manual provides essential information for safe assembly, proper operation, and effective maintenance to ensure long-lasting enjoyment of your pergola. Please read all instructions carefully before beginning assembly or use.



Image 1.1: EROMMY 11' x 13' Louvered Pergola in an outdoor setting.

2. SAFETY INFORMATION

Your safety is paramount. Please adhere to the following guidelines:

- Ensure the pergola is securely assembled and anchored to a stable foundation.
- Regularly inspect for any damage or wear to components.
- Do not exceed the weight limit for any attached accessories or decorations.
- Keep children and pets away from the assembly area during installation.
- Exercise caution when adjusting the louvered roof to prevent pinching.
- In extreme weather conditions (e.g., heavy snow, strong winds), it is recommended to open the louvers to prevent accumulation and reduce wind resistance.

3. PACKAGE CONTENTS

The EROMMY Louvered Pergola is shipped in multiple boxes. Please verify that all components are present and undamaged before beginning assembly. Refer to the packing list provided in Box A for a complete inventory.

Product Detail Description

Humanized Straps

Straps are included on the upper, middle, and lower sections of the curtain and mesh to prevent them from flapping around during strong winds.



Image 3.1: The pergola is typically shipped in 6 separate boxes.

If any parts are missing or damaged, please contact EROMMY customer service immediately for assistance.

4. ASSEMBLY INSTRUCTIONS

Assembly typically requires 3-4 people and takes approximately 2-3 hours. Follow the detailed steps in the included assembly manual. Ensure you have adequate space and the necessary tools before starting.

4.1. Preparation

- Clear the assembly area of any obstructions.
- Lay out all parts and hardware, matching them against the packing list.
- Gather necessary tools (e.g., wrenches, screwdrivers, ladder).

4.2. Frame Assembly

1. Assemble the main support posts and crossbeams according to the diagrams.
2. Ensure all connections are secure but do not fully tighten bolts until the entire frame is upright.
3. Carefully raise the frame and position it in the desired location.
4. Anchor the base stands to a stable surface using the provided expansion screws.



Product Detail Description



Aluminum Alloy Roof Panel



Stable Structure



Humanized Straps



Durable Anchor Frame

Image 4.1: Details of the stable structure and durable anchor frame.

4.3. Louvered Roof Installation

1. Install the louvered roof panels onto the frame, ensuring proper alignment.
2. Connect the operating mechanism for the louvers.
3. Apply sealant to all joints as instructed to ensure waterproofing, especially in areas prone to rain.

4.4. Curtains and Netting Attachment

1. Attach the curtains and netting to the designated tracks on the pergola frame.
2. Ensure the humanized straps are used to secure the curtains and netting when not in use, preventing flapping in windy conditions.

5. OPERATING INSTRUCTIONS

5.1. Adjusting the Louvered Roof

The pergola features an adjustable louvered roof, allowing you to control sunlight and shade. The roof is typically divided into sections that can be operated independently using a handle mechanism.

- To **open** the louvers: Turn the handle to rotate the slats, allowing sunlight and ventilation.
- To **close** the louvers: Turn the handle in the opposite direction to fully close the slats, providing shade and rain protection.



Image 5.1: Adjusting the louvered roof for desired light and shade.

5.2. Using Curtains and Netting

The included curtains and netting provide privacy, sun protection, and insect deterrence.

- To **deploy**: Unfasten the straps and slide the curtains/netting along their tracks.
- To **retract**: Gather the curtains/netting and secure them to the posts using the humanized straps.

CUSTOMIZE SIDE SHADE ●



Privacy



Anti-mosquito



FULLY OPEN



Ventilation



360° View Scenery

FULLY CLOSE



Suitable for



Waterproof



Image 5.2: The curtains and netting offer customizable privacy and protection.

6. MAINTENANCE


Regular maintenance will extend the lifespan and preserve the appearance of your EROMMY pergola.

- **Cleaning the Frame:** Wipe the aluminum frame with a soft cloth and mild soap and water. Rinse thoroughly and dry to prevent water spots. Avoid abrasive cleaners.
- **Louver Care:** Periodically clean the louver slats to remove debris such as leaves or dirt, which can impede their movement or drainage.
- **Gutter System:** Ensure the integrated gutter system and drainage channels in the posts are free of blockages to prevent water accumulation.
- **Curtains and Netting:** These polyester components can be spot cleaned with mild soap and water. For deeper cleaning, follow care instructions on the fabric tags. Ensure they are dry before storing or retracting for extended periods to prevent mildew.
- **Hardware Inspection:** Annually check all bolts and screws for tightness. Re-tighten as necessary. Inspect for any signs of corrosion or wear.

IN-BUILT GUTTER SYSTEM

Allows rainwater to collect into the gutters and finally drain out of the posts.

Adjustable Louvered Pergola



● Rain-collecting



● Water-guiding



● Drain Out

Image 6.1: The integrated gutter system requires periodic cleaning to ensure proper drainage.

7. TROUBLESHOOTING

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Louvers not adjusting smoothly	Debris in mechanism, loose connections, or lack of lubrication.	Clean slats and mechanism. Check and tighten connections. Apply a silicone-based lubricant if necessary.
Water leakage from roof	Sealant not properly applied, gutter blockage, or extreme rainfall.	Inspect sealant application and reapply if needed. Clear gutters. Ensure louvers are fully closed during rain.

Problem	Possible Cause	Solution
Curtains/Netting snagging or difficult to move	Debris in tracks, bent hooks, or fabric obstruction.	Clean tracks. Straighten or replace bent hooks. Ensure fabric is not caught.
Pergola feels unstable	Anchoring not secure, loose frame connections.	Verify base stands are securely anchored to the ground. Check and tighten all frame bolts.

8. SPECIFICATIONS

Detailed specifications for the EROMMY 11' x 13' Louvered Pergola:


- **Brand:** EROMMY
- **Model:** 11x13 Louvered Pergola
- **Product Dimensions:** 153.6"L x 133"W x 88.98"H (11' x 13' nominal)
- **Material:** Aluminum (Frame and Louvered Roof), Polyester (Curtains and Netting)
- **Color:** Gray-Black, with Curtain and Netting
- **Item Weight:** 315 Pounds
- **Water Resistance Level:** Water Resistant (when louvers are closed)
- **Ultraviolet Light Protection:** 99%
- **Assembly Required:** Yes

PRODUCT DIMENSION

Suitable for parties of at least 6 people



With Outdoor Sofa



With Patio Dining Sets

11x13 Louvered Pergola



Image 8.1: Dimensional overview of the EROMMY 11' x 13' Louvered Pergola.

9. WARRANTY AND SUPPORT

EROMMY is committed to providing high-quality products and customer satisfaction. While specific warranty details are provided with your purchase documentation, our service team is available to assist with any issues or questions you may have regarding your pergola.

For support, please contact EROMMY customer service through the retailer where you purchased the product or visit the official EROMMY website for contact information. Please have your model number (11x13 Louvered Pergola) and purchase date ready when contacting support.