

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [FUNLIO](#) /

> [FUNLIO Baby Door Jumper Instruction Manual \(Model B0CSFNG3DL\)](#)

FUNLIO B0CSFNG3DL

FUNLIO Baby Door Jumper Instruction Manual

Model: B0CSFNG3DL

1. INTRODUCTION AND OVERVIEW

The FUNLIO Baby Door Jumper is designed to provide a fun and engaging bouncing experience for infants aged 6 to 24 months, with a maximum weight capacity of 40 lbs (18 kg). This product helps babies improve balance and exercise muscles in a safe and controlled environment. Its adjustable features and secure design ensure comfort and safety for your child.

This manual contains essential information for the correct assembly, safe operation, and proper maintenance of your FUNLIO Baby Door Jumper. Please read all instructions carefully before use and retain this manual for future reference.

2. IMPORTANT SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in serious injury or death.

- For use only by children aged 6-24 months, weighing a maximum of 40 lbs (18 kg).
- Always ensure the door clamp is securely attached to a compatible door frame.
- Compatible Door Frames: Rectangular door frames only, solid frames, door frame thickness greater than 0.5 inches (13 mm); wall thickness 4-12 inches (10-30 cm); height less than 95 inches.
- NOT suitable for: Thin plastic, hollow metal, round, glass, or damaged frames.
- Never leave a child unattended in the door jumper. Constant supervision is required.
- Ensure all straps and buckles are properly fastened and adjusted for a snug fit before each use.
- Regularly inspect the product for any signs of wear, damage, or loose components. Discontinue use if any damage is found.
- Keep children away from the door frame during installation and removal to prevent injury.
- This product has passed CPSC and ASTM certifications in the US, and European Standard EN 71 in the EU.

90 Days Return Policy & 1 Year Quality Commitment



Image: Certifications for the FUNLIO Baby Door Jumper, including CPSC, ASTM, and EN 71.

3. PACKAGE CONTENTS

Upon opening your FUNLIO Baby Door Jumper package, please ensure all the following components are present:

- 1 x Baby Jumper Seat
- 1 x Sturdy Door Clamp with Spring Mechanism
- Adjustable Nylon Rope and Straps



Baby Door Jumper for 6-24 Months

Enjoy Endless Hours of Fun



Image: The complete FUNLIO Baby Door Jumper, showing the seat, adjustable straps, and door clamp.

4. SETUP AND ASSEMBLY

Follow these steps to safely assemble and install your FUNLIO Baby Door Jumper:

- 1. Attach the Jumper Seat to the Door Clamp:** Connect the adjustable nylon rope from the jumper seat to the spring mechanism on the door clamp. Ensure the carabiners are securely locked.
- 2. Install the Door Clamp:** Position the door clamp on a suitable door frame. The clamp should fit snugly and securely over the top of the door frame. Verify that the door frame meets the thickness and wall thickness requirements specified in the safety section.
- 3. Adjust Height:** Use the adjustable strap on the nylon rope to set the appropriate height for your baby. Your baby's toes should just touch the floor when placed in the jumper. The adjustable height range is 2.8 inches (7 cm) to 27.6 inches (70 cm).
- 4. Secure the Baby:** Place your baby into the jumper seat, ensuring their legs are through the leg openings. Fasten the adjustable seat belt and secure the wide and firm Velcro straps around your baby for a snug and safe fit.

We Care About Every Safety Detail



2 Safety Lock Carabiners



Adjustable Seat Belt



Wide & Firm Velcro Seat Belt

Image: Close-up of the two safety lock carabiners, adjustable seat belt, and wide Velcro seat belt for secure fitting.

For Different Doorframes & Baby Heights

Ours



Others



Image: Illustration showing the adjustable rope length from 2.8 to 27.6 inches (7-70 cm) to adapt to different doorframes and baby heights.

Your browser does not support the video tag. Please update your browser to view this content.

Video: A detailed demonstration of how to assemble the FUNLIO Baby Door Jumper, including attaching the seat to the clamp and adjusting the straps.

5. OPERATING INSTRUCTIONS

Once the FUNLIO Baby Door Jumper is securely installed and your baby is safely fastened:

- Encourage your baby to gently push off the floor with their feet to initiate bouncing.
- Always supervise your baby during use. Do not leave them unattended.
- Limit play sessions to short periods to prevent over-stimulation and fatigue.
- Ensure there are no obstacles or hazards within your baby's reach while they are bouncing.

Your browser does not support the video tag. Please update your browser to view this content.

Video: A baby enjoying the FUNLIO Door Jumper, demonstrating typical use and the bouncing motion.

6. MAINTENANCE

Proper maintenance ensures the longevity and safety of your door jumper:

- **Cleaning:** The fabric seat can be easily removed and is machine washable. Use a gentle cycle with cold water and mild detergent. Air dry or tumble dry on low heat.
- **Inspection:** Regularly check all straps, buckles, springs, and the door clamp for any signs of wear, fraying, cracks, or damage.
- **Storage:** The door jumper is portable and can be easily folded for storage. Store in a clean, dry place away from direct sunlight when not in use.

7. TROUBLESHOOTING

If you encounter any issues with your FUNLIO Baby Door Jumper, refer to the following common solutions:

- **Jumper feels unstable or clamp slips:** Ensure the door frame meets the specified thickness and material requirements. Re-tighten the clamp firmly. If the issue persists, discontinue use and contact customer support.
- **Baby's feet don't touch the floor or are too high:** Adjust the length of the nylon rope using the adjustable strap until your baby's toes just touch the floor.
- **Spring feels too stiff or baby isn't bouncing much:** Ensure the height is correctly adjusted. The spring is designed to be sturdy and flexible. If the baby is within the recommended weight range and height is correct, they should be able to bounce effectively.
- **Difficulty getting baby in/out:** Ensure the seat belt and Velcro straps are fully loosened before attempting to place or remove your baby. Practice the process to become more familiar.

8. SPECIFICATIONS

Feature	Specification
Product Dimensions	16.93 x 8.66 x 3.94 inches
Maximum Weight Recommendation	40 Pounds (18 kg)
Age Range	6-24 Months
Material Type	Cotton, Nylon, Stainless Steel
Material Composition	Carbon steel and Cotton fabric
Adjustable Rope Length	2.8 - 27.6 inches (7 - 70 cm)
Item Weight	2.97 pounds
Portability	Yes
Color	Grey

Have Fun Anywhere & Easy to Store




Image: Visual representation of the product dimensions, weight capacity, and recommended age range.

9. WARRANTY AND SUPPORT

FUNLIO is dedicated to providing high-quality products and customer satisfaction. Your FUNLIO Baby Door Jumper comes with:

- **90-Day Return Policy:** If you are not satisfied with your purchase for any reason, you may return it within 90 days.
- **1-Year Quality Service:** We offer a 1-year quality service commitment.

In case any parts are missing or damaged during transportation, or if you have any questions or concerns about your product, please contact FUNLIO customer service immediately. We are committed to assisting you by sending replacement parts or exchanging the product within 2 business days.

For further assistance, please visit the official FUNLIO store: [FUNLIO Store on Amazon](#)

