

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Monster Jam](#) /

› [Monster Jam Marvel Iron Man RC Monster Truck \(Model 6070373\) Instruction Manual](#)

Monster Jam 6070373

Monster Jam Marvel Iron Man RC Monster Truck (Model 6070373) Instruction Manual

INTRODUCTION

Welcome to the exciting world of Monster Jam with your new Marvel Iron Man RC Monster Truck! This 1:24 scale remote control truck is designed for thrilling indoor and outdoor adventures. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new toy to ensure a fun and safe experience.

Included in the Box:

- 1 Monster Jam 1:24 Scale RC Truck (Marvel Iron Man)
- 1 Remote Control
- 1 Instruction Guide (this document)



Image: The Monster Jam Marvel Iron Man RC Monster Truck with its remote control.

SAFETY INFORMATION

Please read all safety instructions before operating the Monster Truck. Failure to follow these instructions may result in injury or damage.

- **Age Recommendation:** This product is suitable for ages 4 to 14 years.
- **Battery Safety:** Always use fresh batteries of the recommended type. Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity. Remove batteries if the toy will not be used for an extended period.
- **Supervision:** Adult supervision is recommended during play.
- **Choking Hazard:** Keep small parts and batteries away from young children.
- **Operating Environment:** Avoid operating the truck near water, heat sources, or electrical outlets. Do not operate in crowded areas to prevent collisions.

SETUP

1. Unboxing and Inspection

Carefully remove all components from the packaging. Inspect the truck and remote control for any signs of damage. Ensure all listed items are present.



Image: The Monster Jam Marvel Iron Man RC Monster Truck shown in its retail packaging.

2. Battery Installation

The Monster Jam Marvel Iron Man RC Monster Truck requires 5 AAA batteries (not included). It is recommended to use 3 AAA batteries for the truck and 2 AAA batteries for the remote control.

- **For the RC Truck:**

1. Locate the battery compartment on the underside of the truck.
2. Using a Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 3 AAA batteries, ensuring correct polarity (+/-).
4. Replace the cover and tighten the screw.

- **For the Remote Control:**

1. Locate the battery compartment on the back of the remote control.
2. Using a Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
4. Replace the cover and tighten the screw.



Image: A close-up view of the remote control, showing the joystick controls.

3. Pairing the Remote Control

Once batteries are installed in both the truck and the remote, turn on the truck using the ON/OFF switch located on its underside. Then, turn on the remote control. The truck and remote should automatically pair. If they do not pair, turn both devices off and then on again.

OPERATING INSTRUCTIONS

1. Basic Controls

The remote control features simple joystick controls for easy operation:

- **Left Joystick:** Controls forward and backward movement. Push forward to move the truck forward, pull back to move it backward.
- **Right Joystick:** Controls steering (left and right). Push left to turn left, push right to turn right.



EASY TO CONTROL

Image: A child's hands are shown holding the remote control, operating the Monster Jam Marvel Iron Man RC Monster Truck on a wooden floor.

2. Driving Tips

- **Indoor Use:** The truck is suitable for indoor use on smooth surfaces.
- **Outdoor Use:** It can also be used outdoors on various terrains. Its oversized BKT tires are designed to handle obstacles.
- **Range:** The remote control has a range of up to 100 feet.
- **Obstacles:** The robust design allows the truck to drive over small obstacles.



DRIVE OVER OBSTACLES

Image: The Monster Jam Marvel Iron Man RC Monster Truck is depicted driving over a stack of binders, demonstrating its ability to clear obstacles.

MAINTENANCE

1. Cleaning

To keep your Monster Truck in optimal condition:

- Wipe the truck and remote with a damp cloth to remove dirt and dust.
- Do not immerse the truck or remote control in water.
- Avoid using harsh chemicals or abrasive cleaners.

2. Battery Care

- Replace batteries when the truck's performance decreases or the remote becomes unresponsive.
- Always dispose of used batteries responsibly.

3. Storage

When not in use, store the truck and remote control in a cool, dry place away from direct sunlight. Remove batteries if storing for extended periods.

TROUBLESHOOTING

- **Truck Not Moving:**

- Check if the truck and remote are turned ON.
- Ensure batteries are correctly installed and not depleted. Replace if necessary.
- Verify that the truck and remote are properly paired.

- **Poor Range or Intermittent Control:**

- Ensure there are no obstructions between the remote and the truck.
- Replace batteries in both devices.
- Avoid operating near other radio-controlled devices that may cause interference.

- **Wheels Not Turning:**

- Check for any debris or hair caught in the wheels or axles.
- Ensure the steering trim on the remote (if applicable) is centered.

SPECIFICATIONS

Product Dimensions	11.25 x 5.81 x 5.5 inches
Item Weight	1.06 pounds
Item Model Number	6070373
Manufacturer Recommended Age	4 - 14 years
Batteries	5 AAA batteries required (3 for truck, 2 for remote)
Manufacturer	Spin Master



Image: The Monster Jam Marvel Iron Man RC Monster Truck on a wooden floor, with text indicating its length is over 8 inches.

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided on the product packaging or visit the official Monster Jam website. Keep your purchase receipt as proof of purchase.