

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Beko](#) /
- › [Beko 60cm Wall-Mounted Hood BHCA66641BFBHSE User Manual](#)

Beko BHCA66641BFBHSE

Beko 60cm Wall-Mounted Hood BHCA66641BFBHSE User Manual

Model: BHCA66641BFBHSE | Brand: Beko

1. PRODUCT OVERVIEW

The Beko BHCA66641BFBHSE is a 60cm wall-mounted kitchen hood designed to efficiently remove smoke, steam, and cooking odors from your kitchen. It features a sleek black glass design, touch controls, and multiple functionalities for enhanced air quality.

Key Features:

- Touch Control Interface
- Dishwasher-Safe Glass Carbon Filter
- 3 Speed Levels for Ventilation
- Filter Saturation Indicator
- Air Cleaning Function
- Automatic Shut-off
- LED Lighting

2. SAFETY INFORMATION

Please read all safety instructions carefully before installation and use to prevent injury or damage. Keep this manual for future reference.

- Ensure the electrical supply matches the voltage specified on the rating plate.
- Installation must be performed by a qualified technician in accordance with local regulations.
- Do not operate the hood without filters properly installed.
- Regularly clean filters to maintain optimal performance and prevent fire hazards.
- Do not flambé under the range hood.
- Keep children away from the appliance during operation.
- Disconnect the appliance from the power supply before any cleaning or maintenance.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove the hood from its packaging. Inspect for any damage during transit. Retain packaging materials for potential future transport or service.

3.2 Mounting

This hood is designed for wall-mounted installation. Ensure the wall structure can support the weight of the appliance (22 kg). Maintain the minimum required distance between the cooking surface and the bottom of the hood as specified in local building codes and the installation template.



Image 1: Beko 60cm Wall-Mounted Hood BHCA66641BFBHSE. This image shows the overall design of the hood, including its black glass panel and touch control interface.

3.3 Electrical Connection

Connect the hood to a grounded electrical outlet. The appliance operates on 220 Volts. Ensure the connection is secure and complies with all electrical safety standards.

4. OPERATING INSTRUCTIONS

4.1 Control Panel

The hood features a touch control panel located on the front glass surface. Gently press the icons to activate functions.

4.2 Speed Settings

The hood offers 3 speed levels for ventilation. Press the fan speed icon repeatedly to cycle through low, medium, and high settings. Select a higher speed for intense cooking or a lower speed for lighter tasks.

4.3 Lighting

Press the light icon to turn the LED lighting on or off. The LED lights provide illumination for your cooking area.

4.4 Air Cleaning Function

Activate the air cleaning function to periodically refresh the kitchen air. Refer to the specific icon on the control panel for this feature.

4.5 Automatic Shut-off

The hood is equipped with an automatic shut-off feature. This function will turn off the hood after a preset time, helping to save energy. Consult the full product manual for details on setting or disabling this feature.

5. MAINTENANCE

5.1 Filter Cleaning

The hood features a dishwasher-safe glass carbon filter. The filter saturation indicator will alert you when cleaning is required. To clean, remove the filter and place it in a dishwasher or wash by hand with warm, soapy water. Ensure the filter is completely dry before re-installing.

5.2 Carbon Filter Replacement

While the glass carbon filter is washable, its effectiveness may diminish over time. Replace the carbon filter periodically, typically every 3-6 months depending on usage. Refer to the full manual for specific replacement instructions and compatible filter models.

5.3 General Cleaning

Clean the exterior surfaces of the hood with a soft cloth and a mild, non-abrasive cleaner. Do not use harsh chemicals or abrasive pads, especially on the black glass surface, to avoid scratches.

6. TROUBLESHOOTING

If you encounter issues with your Beko hood, consult the table below for common problems and solutions.

| Problem | Possible Cause | Solution |
|-----------------------|---------------------------------|--|
| Hood does not turn on | No power supply | Check power cord connection and circuit breaker. |
| Low suction power | Clogged filters | Clean or replace the filters. |
| Excessive noise | Loose components or obstruction | Check for loose parts or objects in the fan. Ensure proper installation. |

| Problem | Possible Cause | Solution |
|--------------------|-------------------|---|
| Lights not working | Faulty LED module | Contact customer service for LED replacement. |

7. SPECIFICATIONS

| Specification | Value |
|--------------------------------|----------------------------|
| Model | BHCA66641BFBHSE |
| Voltage | 220 Volts |
| Number of Speeds | 3 |
| Item Weight | 22 Kilograms |
| Light Source | LED |
| Filter Type | Glass Carbon |
| Product Shape | Wall Mounted |
| Ventilation Type | Ducted/Vented |
| Ventilation Device Design | Wall-mounted Canopy Hood |
| Manufacturer | Beko |
| Product Dimensions (D x W x H) | 41.9 x 59.8 x 113 cm |
| Efficiency Class | A+ |
| Annual Energy Consumption | 500 Watt-hours |
| Special Features | Touch Control |
| Airflow Capacity | 1000 cubic meters per hour |
| Material Type | Stainless Steel |
| Batteries Required | No |
| Noise Level | 14.4 Decibels |
| Installation Type | Wall Mount |
| Included Components | Hood Assembly |
| Control Type | Touch |

8. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official Beko website. Keep your purchase receipt as proof of purchase for any warranty claims.

For technical support, spare parts, or service inquiries, please contact Beko customer service. Contact details can typically be found on the Beko official website or in the product documentation.

Online resources and FAQs may also be available on the Beko support portal: www.beko.com